# 전환을 위한 케이블 정보를 수집하는 중입니다

## ONTAP 7-Mode Transition

NetApp
May 03, 2022

This PDF was generated from https://docs.netapp.com/ko-kr/ontap-7mode-transition/copy-free/reference_copy_free_transition_cabling_worksheet.html on May 03, 2022. Always check docs.netapp.com for the latest.

# 목차

전환을 위한 케이블 정보를 수집하는 중입니다 . . . . . 1
복사 없는 전환 케이블링 워크시트 . . . . . 2

# 전환을 위한 케이블 정보를 수집하는 중입니다

복사를 사용하지 않는 전환을 시작하기 전에 7-Mode 컨트롤러의 어댑터, 포트, 디스크 쉘프 및 스토리지 연결에 대한 정보를 수집한 다음 7-Mode 디스크 쉘프를 타겟 클러스터 노드에 연결하는 방법을 계획해야 합니다.

복사를 사용하지 않는 전환 케이블링 워크시트를 인쇄해야 합니다.

복사 없는 전환 케이블링 워크시트

1. Config Advisor를 사용하여 7-Mode 스토리지 및 케이블 연결 상태 점검을 수행하고 케이블링 데이터를 수집하십시오.

   "Data ONTAP 7, 8(7-Mode)" 실행 프로파일에서 '7-Mode 설치 점검' 옵션을 사용해야 합니다.

2. 다음 명령을 사용하여 각 7-Mode 컨트롤러에 대한 필수 정보를 수집합니다.

   ' * sysconfig_slot_number_ *'

   이 명령의 출력을 사용하여 디스크 쉘프 연결에 사용할 포트를 식별할 수 있습니다.

   ```
   host1> sysconfig 3
           slot 3: SAS Host Adapter 3a
                   24 Disks:            13440.0GB
                   1 shelf with IOM3
           slot 3: SAS Host Adapter 3b
                   24 Disks:            13440.0GB
                   1 shelf with IOM3
           slot 3: SAS Host Adapter 3c
                   24 Disks:            13440.0GB
                   1 shelf with IOM3
           slot 3: SAS Host Adapter 3d
                   24 Disks:            13440.0GB
                   1 shelf with IOM3
   ```

3. 클러스터에서 각 노드에 대해 다음 notes지옥을 실행하십시오.

   ' * system node run-node_node_name_-command sysconfig -a * '

   이 명령의 출력을 사용하여 사용 가능한 포트 및 확장 카드 슬롯에 대한 정보를 얻을 수 있습니다.

4. 타겟 클러스터 노드에서 7-Mode 디스크 쉘프 연결에 사용할 포트를 계획합니다.
   a. 사용 가능한(열린) 포트를 검토합니다.
   b. 확장 카드 슬롯을 검토합니다.
   c. 확장 카드 구성을 계획합니다.

타겟 플랫폼 및 ONTAP 버전에서도 확장 카드가 지원되는 경우 7-Mode 시스템에서 확장 카드를 이동할 수 있습니다. 필요한 경우 PAM 카드를 계획할 수도 있습니다.

"NetApp Hardware Universe를 참조하십시오"

d. 디스크 쉘프 케이블링에 사용할 대상 포트를 계획합니다.

대상 포트 선택은 다음 요소 중 일부에 따라 달라집니다.

- 별도의 디스크 쉘프 스택 또는 기존 디스크 쉘프 스택
- 포트 가용성
- SAS 또는 FC 연결
- 온보드 포트 또는 확장 카드의 가용성

5. 데이터 센터로 이동하여 케이블 연결 워크시트에 7-Mode 컨트롤러 및 타겟 클러스터 노드의 포트 연결을 물리적으로 기록합니다.

a. 케이블 연결 워크시트에 7-Mode 컨트롤러의 사용된 포트를 기록합니다.

b. 대상 클러스터 노드의 사용된 포트를 케이블링 워크시트에 기록합니다.

c. 단계에서 계획된 대로 7-Mode 디스크 쉘프 연결에 사용할 타겟 포트를 기록합니다 STEP_D0CFE719A0384F7FA5D9E73C8EA6C2E7.

d. 디스크 쉘프를 연결하는 데 적합한 케이블이 있는지 확인합니다.

새로운 디스크 쉘프 스택 위치를 기준으로 케이블 연결과 관련된 문제를 모두 식별해야 합니다.

e. 래더 랙 장착 또는 데이터 센터 요구 사항으로 인해 케이블 길이를 연장하는 계획을 수립합니다.

f. 각 디스크 쉘프 스택과 케이블에 7-Mode 컨트롤러에 레이블을 부착합니다.

모범 사례는 전환을 롤백하여 디스크 쉘프를 7-Mode 컨트롤러에 다시 연결해야 할 경우 7-Mode 디스크 쉘프 스택의 레이블을 지정하는 것입니다.

- 관련 정보 *

"DS4243, DS2246, DS4486 및 DS4246용 SAS 디스크 쉘프 설치 및 서비스 가이드"

"하드웨어 서비스 설명서의 Disk쉘프 14mk2"

"DS14mk2 FC 및 DS14mk4 FC 하드웨어 서비스 가이드"

# 복사 없는 전환 케이블링 워크시트

복사를 사용하지 않는 전환 케이블링 워크시트를 사용하여 케이블링 계획을 세울 수 있습니다. 7-Mode 컨트롤러 및 타겟 클러스터 노드에 연결된 포트 및 디스크 쉘프에 대한 정보를 기록해야 합니다. 또한 7-Mode 디스크 쉘프를 타겟 클러스터 노드에 연결하는 데 사용할 포트를 기록해 두어야 합니다.

| 7-Mode Cabling (source) | | | |
|---|---|---|---|
| Controller A (hostname): _____ | | | |
| Location: _____ Floor: _____ Rack: _____ | | | |
| Module A Ports | Module B Ports | Shelf Type / Asset Tag | Shelf IDs |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| Controller B (hostname): _____ | | | |
| Location: _____ Floor: _____ Rack: _____ | | | |
| Module A Ports | Module B Ports | Shelf Type / Asset Tag | Shelf IDs |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Clustered Data ONTAP Cabling (destination) | | | |
|---|---|---|---|
| Controller A (hostname): _____ | | | |
| Location: _____ Floor: _____ Rack: _____ | | | |
| Module A Ports | Module B Ports | Shelf Type / Asset Tag | Shelf IDs |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| Controller B (hostname): _____ | | | |
| Location: _____ Floor: _____ Rack: _____ | | | |
| Module A Ports | Module B Ports | Shelf Type / Asset Tag | Shelf IDs |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

- 모듈 A/B 포트: 모듈 A/B용 포트 연결
- 쉘프 유형/자산 태그: 디스크 쉘프 유형
- 쉘프 ID: 디스크 쉘프 ID

## 케이블 연결 워크시트 예

| **7-Mode** 케이블 연결 | | | | **Clustered Data ONTAP** 케이블 연결 | | | |
|---|---|---|---|---|---|---|---|
| 컨트롤러 A(호스트 이름): 7hostA | | | | 노드 A(호스트 이름): cluster1-01 | | | |
| 장소: 콜로라도 플로어: 세번째랙: 8 | | | | 장소: 콜로라도 플로어: 5번 랙: 3 | | | |
| 모듈 A 포트 | 모듈 B 포트 | 쉘프 유형 /자산 태그 | 쉘프 ID입니다 | 모듈 A 포트 | 모듈 B 포트 | 쉘프 유형 /자산 태그 | 쉘프 ID입니다 |
| 1a | 0A | DS4243/150 254-7 | 10-13 | 1a | 0A | DS4243/174 243-2 | 10-11 |
| 1b | 0b | DS4243/151 205-2 | 30-37로 이동합니다 | 1b | 0b | DS4243/150 254-7 | 20-23세 |
| 1C(오프라인) | 0C(오프라인) | 해당 없음 | 해당 없음 | 1C | 0C | DS4243/151 205-2 | 30-37로 이동합니다 |
| 1D | 0D | DS4243/143 921-4 | 14-15를 참조하십시오 | 1D | 0D | DS4243/143 921-4 | 14-15를 참조하십시오 |

| **7-Mode** 케이블 연결 | | | | **Clustered Data ONTAP** 케이블 연결 | | | |
|---|---|---|---|---|---|---|---|
| • 컨트롤러 B(호스트 이름): 7hostB * | • 노드 B(호스트 이름): cluster1-02 * | • 위치: 콜로라도 플로어: 3번째 랙: 8 * | • 위치: 콜로라도 플로어: 5번째 랙: 3 * | • 모듈 A 포트 * | • 모듈 B 포트 * | • 쉘프 유형/자산 태그 * | • 쉘프 ID * |
| • 모듈 A 포트 * | • 모듈 B 포트 * | • 쉘프 유형/자산 태그 * | • 쉘프 ID * | 1a | 0A | DS4243/174263-6 | 10-13 |
| 1a | 0A | DS4243/174233-2 | 10-11 | 1B(오프라인) | 0b(오프라인) | 해당 없음 | 해당 없음 |
| 1b | 0b | DS4243/174263-6 | 20-23세 | 1C | 0C | DS4243/174274-9 | 30-37로 이동합니다 |
| 1C | 0C | DS4243/174274-9 | 30-37로 이동합니다 | 1D | 0D | DS4243/174285-6 | 14-15를 참조하십시오 |

**Copyright Information**

Copyright © 2022 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

**Trademark Information**

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.