对使用 SnapMirror 时的过渡问题进行故障排除

ONTAP 7-Mode Transition

NetApp
June 07, 2022

This PDF was generated from https://docs.netapp.com/zh-cn/ontap-7mode-transition/snapmirror/task_resuming_a_failed_snapmirror_transfer_transition.html on June 07, 2022.
Always check docs.netapp.com for the latest.

目录

对使用 SnapMirror 时的过渡问题进行故障排除 1
恢复失败的 SnapMirror 基线传输 1
从失败的 LUN 过渡中恢复 1

对使用 SnapMirror 时的过渡问题进行故障排除

故障排除信息可帮助您确定并解决使用 SnapMirror 命令过渡 7- 模式数据时出现的问题。

恢复失败的 SnapMirror 基线传输

过渡期间， SnapMirror 基线传输可能会因多种原因而失败，例如网络连接断开，传输中止或控制器故障转移。更正发生原因故障后，如果重新启动检查点可用，您可以恢复 SnapMirror 传输。

如果基线传输的重新启动检查点不可用，则必须删除并重新创建卷，重新建立 SnapMirror 关系并重新启动过渡。

步骤

1. 在目标集群中，使用带有 ` -snapshot-checkpoint` 参数的 `snapmirror show` 命令查看基线传输和重新启动检查点的状态。

```
cluster2::> snapmirror show -destination-path dest_vserver:vol3 -fields
snapshot-checkpoint
source-path          destination-path snapshot-checkpoint
-------------------- ---------------- -------------------
src_system:vol3    dest_vserver:vol3 50MB
```

2. 如果存在 SnapMirror 检查点，请使用 `snapmirror initialize` 命令恢复基线传输。

```
cluster2::> snapmirror initialize -destination-path dest_vserver:vol3
```

从失败的 LUN 过渡中恢复

如果具有 LUN 的卷过渡失败，您可以使用 `lun transition 7-mode show` 命令检查哪些 LUN 未过渡到 ONTAP ，然后确定更正操作。

步骤

1. 更改为高级权限级别：

   ` * 设置 -privilege advanced*`

2. 检查哪些 LUN 出现故障：

   ` * LUN 过渡 7- 模式显示 *`

3. 查看 EMS 日志并确定必须采取的更正操作。
4. 执行 EMS 消息中所示的必要步骤以更正故障。

5. 如果任何受支持的 LUN 过渡失败，则要完成过渡：

   ` * LUN 过渡 start*`

6. 查看卷的过渡状态：

   ` * LUN 过渡显示 *`

   过渡状态可以是以下值之一：

   - `active` ： 卷处于活动 SnapMirror 过渡关系中，尚未过渡。
   - `Complete` ： 此卷的所有受支持 LUN 均已过渡。
   - `Failed` ： 卷的 LUN 过渡失败。
   - `none` ： 卷不包含要从 7- 模式系统过渡的 LUN 。

```
cluster1::*> lun transition show
Vserver                 Volume                Transition Status
------------------- ------------------- -----------------
vs1                     vol0                  none
                        vol1                  complete
                        vol2                  failed
                        vol3                  active
```

   - 相关信息 *

过渡 SAN 卷时的空间注意事项

版权信息

版权所有©2022 NetApp、Inc.。保留所有权利。Printed in the U.S.版权所涵盖的本文档的任何部分不得以任何形式或任何手段复制、包括影印、录制、 磁带或存储在电子检索系统中—未经版权所有者事先书面许可。

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

本软件由NetApp按"原样"提供、不含任何明示或默示担保、包括但不限于适销性和特定用途适用性的默示担保、特此声明不承担任何责任。IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice.NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp.The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S.patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

商标信息

NetApp、NetApp标识和中列出的标记 http://www.netapp.com/TM 是NetApp、Inc.的商标。其他公司和产品名称可能是其各自所有者的商标。