準備進行NFS轉換

ONTAP 7-Mode Transition

NetApp
May 03, 2022

This PDF was generated from https://docs.netapp.com/zh-tw/ontap-7mode-transition/copy-free/concept_prerequisites_to_transition_nfs_configurations.html on May 03, 2022. Always check docs.netapp.com for the latest.

目錄

準備進行NFS轉換 1
轉換NFS組態的先決條件 1
NFS移轉：支援和不支援的組態、以及必要的手動步驟 1
NFS匯出的轉換方式 3

準備進行NFS轉換

如果NFS已獲授權、且NFS服務正在以7-Mode運作的系統上執行、則您必須手動準備叢集和目標SVM、以便轉換NFS組態。您也必須瞭解哪些組態已轉換。

某些以7-Mode運作的NFS組態在ONTAP VMware不支援。部分組態並非由7-Mode Transition Tool轉換、必須手動套用至SVM。

轉換NFS組態的先決條件

只有在7-Mode系統和叢集上符合特定先決條件時、才會使用7-Mode Transition Tool來轉換NFS組態。如果不符合任何條件、則此工具不會轉換組態。

7-Mode必備條件

- NFS必須獲得授權。
- 如果已授權使用此功能、則必須在所有VFiler裝置上啟用NFS。MultiStore
- 在轉換期間、NFS服務必須在7-Mode系統上執行。

  即使在用戶端存取中斷連線並準備開始匯出階段之後、該服務仍必須在7-Mode系統上執行。

- 如果您想要轉換記憶體內的匯出規則、則必須先將其新增至「/etc/exports」檔案、才能進行轉換。

  7-Mode Transition Tool只會轉換在「/etc/exports」檔案中定義的持續匯出規則。

叢集先決條件

- NFS必須獲得授權。

相關資訊

"NetApp文件：ONTAP VMware 9"

NFS移轉：支援和不支援的組態、以及必要的手動步驟

有些NFS組態並未轉換ONTAP 為VMware、因為ONTAP 它們在VMware不受支援、7-Mode的功能有差異、或必須手動轉換。您應該驗證所有預先檢查錯誤和警告訊息、以評估此類組態對轉換的影響。

支援的轉換組態

在較高層級、7-Mode Transition Tool會轉換下列NFS組態：

- NFS選項：
  - 「nfs.udp.xfersize」

    - "NFs.v4.id.domain"
    - "NFs.v4.acl.max.aces.aces."
    - 「nfs.tcp.xfersize」
    - 「nfs、rpcsec、ctx.high」
    - 「nfs。rpcsec。ctx.idle」
    - "NFs.RESPON.觸發器"
    - wafl.default_nt_user`
    - nfs.mount_rootonly
    - 「nfs、tcp、enable」
    - 「nfs、udp、enable」
    - "NFs.RESPON.TRACE
    - nfs.v4.read_委派
    - nfs.v4.write委派
    - 「nfs、v4、acl、enable」
    - 「nfs、vStorage、enable」
    - 「nfs、v3、enable」
    - 「nfs、v4、enable」
- NFS匯出規則：

  如果匯出規則設定為-actual選項、則會忽略匯出路徑（別名路徑）、並使用實際路徑設定匯出規則。

- 使用Kerberos安全性krb5p匯出規則

如需這些NFS組態的詳細資訊、請參閱預先檢查結果。

不支援**ONTAP** 的組態

下列NFS組態ONTAP 不受支援：

- 非qtree層級NFS匯出的子Volume NFS匯出
- WebNFS
- PC-NFS
- NFSv2
- 從一或多個檔案系統路徑隔離NFS用戶端
- 部分NFS選項

  如需不受支援選項的完整清單、請參閱預先檢查警告訊息。

必須手動轉換的組態

有些NFS組態在ONTAP VMware支援中、但並非由7-Mode Transition Tool所轉換。

下列NFS組態會在預先檢查作業中產生警告訊息、您必須在SVM上手動套用組態：

- NFS稽核組態
- NFS選項：
  - "rpc. NSM.tcp.port"
  - "rpc. NSM.udp連接埠"
  - "rpc. mountd・tcp・port"
  - "rpc. mountd・udp・port"
  - "NFs.EXP.NEg.timeout"
  - "NFs.EXP.pos.timeout"
  - "NFS.EXP.Harvest .timeout"使用「vserver NFS modify」命令來修改NFS型儲存虛擬機器（SVM）的組態。
- Kerberos組態

功能不同**ONTAP** 的組態

下列NFS組態在ONTAP 功能上有所不同：

- NFS匯出規則
- NFS匯出存取快取
- NFS診斷命令
- 支援「show mount」命令
- NFS Kerberos加密
- NLM版本支援

相關資訊

自訂7-Mode組態的轉換

"NFS管理"

NFS匯出的轉換方式

您必須瞭解在轉換後如何在SVM上設定NFS匯出。如果VMware不支援7-Mode匯出組態、您可能需要執行一些手動步驟ONTAP 。

您必須瞭解NFS匯出轉換的下列考量事項：

- 如果SVM根磁碟區未匯出為允許所有NFS用戶端的唯讀存取、7-Mode Transition Tool會建立新的匯出原則、允許所有NFS用戶端的唯讀存取、並使用新的匯出原則匯出SVM的根磁碟區。

為了確保所有已轉換的磁碟區或qtree均可掛載、SVM的根磁碟區必須允許所有NFS用戶端的唯讀存取權。

- 當7-Mode磁碟區ONTAP 的匯出組態不受支援於VMware支援時、這些磁碟區會匯出以禁止存取所有NFS用戶端。

  這些磁碟區的匯出原則必須在轉換後手動設定、以提供所需的存取權限。

- 當7-Mode qtree的匯出組態不受ONTAP 支援於VMware移轉時、它們會繼承父Volume的匯出原則。

  這些qtree的匯出原則必須在轉換後手動設定、以提供必要的存取權限。

- 在本例ONTAP 中、NFS用戶端若要掛載qtree、則NFS用戶端必須在所有父連接路徑上、直到SVM根Volume連接路徑（即/）的唯讀權限。

  若要讓NFS用戶端掛載qtree、qtree必須屬於具有唯讀權限的磁碟區。如果沒有磁碟區層級的唯讀權限、NFS用戶端就無法掛載qtree。

- 如果在唯讀、讀寫及根存取權限清單的組合中指定相同的主機、則您必須在轉換後評估轉換的匯出規則、以決定主機的適當存取權限。

"NetApp技術報告4067：NFS最佳實務與實作指南"

範例：修改磁碟區的匯出原則、以允許存取qtree

請考量在7-Mode儲存系統（192：192：192：192）中設定的下列匯出規則、以允許NFS用戶端192：192：168：10的Volume volstd10和qtree qtre1的讀取/寫入存取權：

```
/vol/volstd10/qtree1 -sec=sys,rw=192.168.10.10,nosuid
/vol/volstd10 -sec=sys,rw=192.168.11.11,nosuid
```

轉換後ONTAP 、下列顯示的是位於畫面上的Volume volsdt10的匯出原則：

```
cluster-01::> export-policy rule show -vserver std_22 -policyname std_2226
-instance
 (vserver export-policy rule show)

                                                   Vserver: std_22
                                               Policy Name: std_2226
                                                Rule Index: 1
                                          Access Protocol: any
Client Match Hostname, IP Address, Netgroup, or Domain: 192.168.11.11
                                           RO Access Rule: sys
                                           RW Access Rule: sys
           User ID To Which Anonymous Users Are Mapped:65534
                                 Superuser Security Types: none
                             Honor SetUID Bits in SETATTR: false
                                Allow Creation of Devices: true
cluster-01::>
```

轉換後、ONTAP 下列為流程圖中qtree qtre1的匯出原則：

```
 cluster-01::> export-policy rule show -vserver std_22 -policyname
std_2225 -instance
  (vserver export-policy rule show)

                                       Vserver: std_22
                                   Policy Name: std_2225
                                    Rule Index: 1
                              Access Protocol: any
Client Match Hostname, IP Address, Netgroup, or Domain: 192.168.10.10
                               RO Access Rule: sys
                               RW Access Rule: sys
User ID To Which Anonymous Users Are Mapped: 65534
                     Superuser Security Types: none
                 Honor SetUID Bits in SETATTR: false
                    Allow Creation of Devices: true
cluster-01::>
```

NFS用戶端192.168.1.10若要存取qtree、NFS用戶端192.168.1.10必須擁有對qtree父Volume的唯讀存取權。

下列輸出顯示NFS用戶端在掛載qtree時遭到拒絕存取：

```
 [root@192.168.10.10 ]# mount 192.168.35.223:/vol/volstd10/qtree1
transition_volume_qtreemount:192.168.35.223:/vol/volstd10/qtree1 failed,
reason
given by server: Permission denied [root@192.168.10.10 ]#
```

您必須手動修改磁碟區的匯出原則、以提供NFS用戶端192.168.10.10的唯讀存取權。

```
cluster-01::> export-policy rule create -vserver std_22 -policyname
std_2226 -clientmatch
192.168.10.10 -rorule sys -rwrule never -allow-suid false -allow-dev true
-superuser none -protocol nfs
  (vserver export-policy rule create)

cluster-01::> export-policy rule show -vserver std_22 -policyname std_2226
-instance
  (vserver export-policy rule show)

                                   Vserver: std_22
                               Policy Name: std_2226
                                Rule Index: 1
                            Access Protocol: any
Client Match Hostname, IP Address, Netgroup, or Domain: 192.168.11.11
                             RO Access Rule: sys
                             RW Access Rule: sys
User ID To Which Anonymous Users Are Mapped: 65534
                   Superuser Security Types: none
               Honor SetUID Bits in SETATTR: false
                  Allow Creation of Devices: true

**                                   Vserver: std_22
                               Policy Name: std_2226
                                Rule Index: 2
                            Access Protocol: nfs
Client Match Hostname, IP Address, Netgroup, or Domain: 192.168.10.10
                             RO Access Rule: sys
                             RW Access Rule: never
User ID To Which Anonymous Users Are Mapped: 65534
                   Superuser Security Types: none
               Honor SetUID Bits in SETATTR: false
                  Allow Creation of Devices: true**

cluster-01::>
```

範例：qtree匯出規則在7-Mode和ONTAP VMware中有何不同

在7-Mode儲存系統中、當NFS用戶端透過其父Volume的掛載點存取qtree時、qtree匯出規則會被忽略、其父Volume的匯出規則也會生效。不過ONTAP 、在功能不全的情況下、無論NFS用戶端是直接掛載到qtree、還是透過其父Volume的掛載點存取qtree、都會強制執行qtree匯出規則。此範例特別適用於NFSv4。

以下是7-Mode儲存系統（192.168.1.18）上的匯出規則範例：

```
/vol/volstd10/qtree1 -sec=sys,ro=192.168.10.10,nosuid
/vol/volstd10   -sec=sys,rw=192.168.10.10,nosuid
```

在7-Mode儲存系統上、NFS用戶端192．168．10僅擁有對qtree的唯讀存取權。但是、當用戶端透過其父Volume的掛載點存取qtree時、用戶端可以寫入qtree、因為用戶端可以讀取/寫入該磁碟區。

```
[root@192.168.10.10]# mount 192.168.26.18:/vol/volstd10 transition_volume
[root@192.168.10.10]# cd transition_volume/qtree1
[root@192.168.10.10]# ls transition_volume/qtree1
[root@192.168.10.10]# mkdir new_folder
[root@192.168.10.10]# ls
new_folder
[root@192.168.10.10]#
```

在鏈接中、當用戶端直接存取qtree或透過qtree父Volume的掛載點存取qtree時、NFS用戶端192．168．10只能以唯讀方式存取qtree qtre1。ONTAP

轉換之後、您必須評估強制執行NFS匯出原則的影響、並視需要將程序修改為在ONTAP 更新中強制執行NFS匯出原則的新方法。

相關資訊

"NFS管理"

Copyright Information

Copyright © 2022 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.