修復MetroCluster 以不修復FC組態的組態

ONTAP MetroCluster

NetApp
May 05, 2022

This PDF was generated from https://docs.netapp.com/zh-tw/ontap-metrocluster/manage/task_heal_the_configuration_in_a_mcc_fc_configuration_supertask.html on May 05, 2022. Always check docs.netapp.com for the latest.

目錄

修復MetroCluster 以不修復FC組態的組態 1
修復MetroCluster 以不還原FC組態設定的組態 1
在協商切換後修復資料集合體 1
協調切換後修復根集合體 2

修復MetroCluster 以不修復FC組態的組態

修復MetroCluster 以不還原FC組態設定的組態

切換後、您必須執行特定的修復作業、才能還原MetroCluster 還原功能。

- 必須執行切換、且存續站台必須提供資料。
- 災難站台上的節點必須暫停或保持關機狀態。

  在修復過程中、不得完全開機。

- 災難站台的儲存設備必須可供存取（磁碟櫃已開機、功能正常且可存取）。
- 在網路附加MetroCluster 的不支援功能組態中、交換器間連結（ISL）必須啟動並運作。
- 在四節點MetroCluster 的不完整組態中、正常運作站台中的節點不得處於HA容錯移轉狀態（每個HA配對的所有節點都必須啟動並執行）。

修復作業必須先在資料集合體上執行、然後再在根集合體上執行。

在協商切換後修復資料集合體

您必須在完成任何維護或測試之後修復資料集合體。此程序可重新同步資料集合體、並準備災難站台以進行正常作業。在修復根集合體之前、您必須先修復資料集合體。

遠端叢集中的所有組態更新都會成功複寫到本機叢集。您可以在災難站台上開啟儲存設備的電源、但您並不需要、也不可以開啟災難站台上的控制器模組。

步驟

1. 執行MetroCluster flexoperationshow命令、確保已完成切換。

```
controller_A_1::> metrocluster operation show
  Operation: switchover
      State: successful
 Start Time: 7/25/2014 20:01:48
   End Time: 7/25/2014 20:02:14
     Errors: -
```

2. 從MetroCluster 存續的叢集執行flex修復 階段Aggregate命令、以重新同步資料集合體。

```
controller_A_1::> metrocluster heal -phase aggregates
[Job 130] Job succeeded: Heal Aggregates is successful.
```

   如果修復被否決、您可以選擇MetroCluster 使用—overrover-etoes參數重新發出還原指令。如果您使用此選用參數、系統將會置換任何軟質否決、以防止修復作業。

3. 執行MetroCluster flexoperationshow命令、確認作業已完成。

```
controller_A_1::> metrocluster operation show
    Operation: heal-aggregates
      State: successful
Start Time: 7/25/2014 18:45:55
   End Time: 7/25/2014 18:45:56
     Errors: -
```

4. 執行儲存Aggregate show命令來檢查集合體的狀態。

```
controller_A_1::> storage aggregate show
Aggregate     Size Available Used% State   #Vols  Nodes            RAID
Status
--------- -------- --------- ----- ------- ------ ----------------
------------
...
aggr_b2    227.1GB   227.1GB    0% online       0 mcc1-a2
raid_dp, mirrored, normal...
```

5. 如果已在災難站台更換儲存設備、您可能需要重新鏡射集合體。

協調切換後修復根集合體

在資料集合體修復之後、您必須修復根集合體、以準備進行切換作業。

必須成功完成資料集合體階段MetroCluster 的還原程序。

步驟

1. 執行MetroCluster f還原 階段根Aggregate命令、切換回鏡射Aggregate。

```
cluster_A::> metrocluster heal -phase root-aggregates
[Job 137] Job succeeded: Heal Root Aggregates is successful
```

如果修復被否決、您可以選擇MetroCluster 使用—overrover-etoes參數重新發出還原指令。如果您使用此選用參數、系統將會置換任何軟質否決、以防止修復作業。

2. 在MetroCluster 健全的叢集上執行flexoperationshow命令、確認修復作業已完成：

```
cluster_A::> metrocluster operation show
  Operation: heal-root-aggregates
      State: successful
 Start Time: 7/29/2014 20:54:41
   End Time: 7/29/2014 20:54:42
     Errors: -
```

3. 請在正常站台上發出下列命令、檢查並移除屬於災難站台的任何故障磁碟：「磁碟show -disks（磁碟顯示-中斷）」
4. 開啟或開機災難站台上的每個控制器模組。

   如果系統顯示載入器提示、請執行「boot_ontap」命令。

5. 引導節點後、請確認根集合體已鏡射。

   如果兩個plexes都存在、則當plexes未同步時、會自動進行重新同步。如果某個叢發生故障、則必須銷毀該叢、並使用儲存Aggregate mirror -Aggregate gregate名稱命令重新建立鏡射關係。

Copyright Information

Copyright © 2022 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.