安裝並連接新的控制器模組

ONTAP MetroCluster

NetApp
May 03, 2022

This PDF was generated from https://docs.netapp.com/zh-tw/ontap-metrocluster/upgrade/task_install_and_cable_the_new_controller.html on May 03, 2022. Always check docs.netapp.com for the latest.

目錄

安裝並連接新的控制器模組 1
安裝新的控制器模組並進行纜線連接 1
將新控制器模組的FC-VI和HBA連接埠連接至FC交換器 2
新控制器模組的叢集對等連線纜線 2

安裝並連接新的控制器模組

安裝新的控制器模組並進行纜線連接

您必須在機箱中實際安裝新的控制器模組、然後將其纜線。

步驟

1. 如果您的系統中有I/O擴充模組（IOXM）、且正在建立單一機箱HA配對、則必須拔下IOXM纜線並將其移除。

   然後、您可以將閒置的支架用於新的控制器模組。不過、新組態不會有IOXM提供的額外I/O。

2. 實際安裝新的控制器模組、必要時安裝額外的風扇：

如果您要新增控制器模組…	然後執行下列步驟…
在空的機槽中建立單一機箱HA配對、而系統屬於下列其中一個平台：	a. 卸下機箱背面的空白板、此擋板會覆蓋將包含新控制器模組的空插槽。 b. 將控制器模組輕推至機箱的一半。 為了防止控制器模組自動開機、請勿在本程序稍後的步驟中、將其完全放入機箱。
當現有組態位於控制器IOX模組組組態中時、請在獨立於HA合作夥伴的機箱中建立雙機箱HA配對。 • FAS8200 • 80xx	在機架或系統機櫃中安裝新系統。

3. 視需要連接叢集網路連線：

   a. 識別控制器模組上用於叢集連線的連接埠。

      "作業系統：安裝與設定AFF"

      "解答A220/FAS2700系統安裝與設定說明AFF"

      "《系統安裝與設定說明》（英文）AFF"

      "《系統安裝與設定說明》（英文）AFF"

      "FAS8200系統安裝與設定說明"

   b. 如果您要設定交換式叢集、請識別要在叢集網路交換器上使用的連接埠。

      請參閱Data ONTAP 《叢集式的*Cisco*交換器設定指南》、《_ NetApp 10G叢集模式交換器安裝指南_》或《_ NetApp 1G叢集模式交換器安裝指南_》、視您使用的交換器而定。

c. 將纜線連接至叢集連接埠：

如果叢集是…	然後…
雙節點無交換器叢集	將現有控制器模組上的叢集連接埠直接連接至新控制器模組上的對應叢集連接埠。
交換式叢集	將每個控制器上的叢集連接埠連接至子步驟b中所識別的叢集網路交換器上的連接埠

將新控制器模組的FC-VI和HBA連接埠連接至FC交換器

新控制器模組的FC-VI連接埠和HBA（主機匯流排介面卡）必須以纜線連接至站台FC交換器。

步驟

1. 使用您的組態和交換器機型表、連接FC-VI連接埠和HBA連接埠。
   - "FC交換器的連接埠指派（使用ONTAP 版本不含更新版本）"
   - "FC交換器的連接埠指派（使用ONTAP 功能）9.0"
   - "使用兩個啟動器連接埠的系統連接埠指派"

新控制器模組的叢集對等連線纜線

您必須將新的控制器模組纜線連接至叢集對等網路、以便與合作夥伴站台上的叢集建立連線。

每個控制器模組上至少應使用兩個連接埠進行叢集對等處理。

建議的連接埠和網路連線最低頻寬為1 GbE。

步驟

1. 識別並連接至少兩個連接埠以供叢集對等、並驗證它們是否與合作夥伴叢集具有網路連線能力。

Copyright Information

Copyright © 2022 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.