# Retrieve cluster chassis

ONTAP 9.13.1 REST API reference

NetApp
February 13, 2024

This PDF was generated from https://docs.netapp.com/us-en/ontap-restapi-9131/ontap/cluster_chassis_endpoint_overview.html on February 13, 2024. Always check docs.netapp.com for the latest.

# Table of Contents

Retrieve cluster chassis . . . 1
Cluster chassis endpoint overview . . . 1
Retrieve a collection of chassis . . . 3
Retrieve a chassis . . . 11

# Retrieve cluster chassis

## Cluster chassis endpoint overview

### Overview

You can use the chassis GET API to retrieve all of the chassis information in the cluster.

### Examples

#### Retrieving a list of chassis from the cluster

The following example shows the response with a list of chassis in the cluster:

```
# The API:
/api/cluster/chassis

# The call:
curl -X GET "https://<mgmt-ip>/api/cluster/chassis" -H "accept:
application/hal+json"

# The response:
{
"records": [
  {
    "id": "021352005981",
    "_links": {
      "self": {
        "href": "/api/cluster/chassis/021352005981"
      }
    }
  },
],
"num_records": 1,
"_links": {
  "self": {
    "href": "/api/cluster/chassis"
  }
}
}
```

---

#### Retrieving a specific chassis from the cluster

The following example shows the response of the requested chassis. If there is no chassis with the requested

ID, an error is returned.

```
# The API:
/api/cluster/chassis/{id}

# The call:
curl -X GET "https://<mgmt-ip>/api/cluster/chassis/021352005981" -H
"accept: application/hal+json"

# The response:
{
"id": "021352005981",
"state": "ok",
"nodes": [
  {
    "name": "node-1",
    "uuid": "6ede364b-c3d0-11e8-a86a-00a098567f31",
    "position": "top",
    "usbs": {
      "supported": true,
      "enabled": true,
      "ports": [
        {
          "connected": false
        }
      ]
    },
    "pcis": {
      "cards": [
        {
          "slot": "0",
          "device": "Gigabit Ethernet I210",
          "info": "\t  e0M MAC Address:    d0:39:ea:3f:06:2b (auto-1000t-
fd-up) \n\t  e0S MAC Address:    d0:39:ea:3f:06:2c (auto-1000t-fd-up) \n\t
Device Type:        1533\n\t  Firmware Version:   3.25-0.0 0x800005D1\n"
        },
        {
          "slot": "0",
          "device": "Intel Lewisburg series chipset SATA Controller",
          "info": "\t  Additional Info: 0 (0xaaf00000)   \n\t
SHM2S86Q120GLM22NP FW1146 114473MB 512B/sect (SPG190108HJ)  \n"
        }
      ]
    },
    "_links": {
      "self": {
```

```
          "href": "/api/cluster/nodes/6ede364b-c3d0-11e8-a86a-00a098567f31"
        }
      }
    }
  ],
  "frus": [
    {
      "id": "PSU2",
      "type": "psu",
      "state": "ok"
    },
    {
      "id": "PSU1",
      "type": "psu",
      "state": "ok"
    },
    {
      "id": "Fan2",
      "type": "fan",
      "state": "ok"
    },
    {
      "id": "Fan3",
      "type": "fan",
      "state": "ok"
    },
    {
      "id": "Fan1",
      "type": "fan",
      "state": "ok"
    }
  ],
  "_links": {
    "self": {
      "href": "/api/cluster/chassis/021352005981"
    }
  }
  }
```


# Retrieve a collection of chassis

GET `/cluster/chassis`

**Introduced In:** 9.6

Retrieves a collection of chassis.

## Related ONTAP commands

- `system chassis show`
- `system chassis fru show`

## Learn more

- DOC /cluster/chassis

## Parameters

| Name | Type | In | Required | Description |
|---|---|---|---|---|
| shelves.uid | string | query | False | Filter by shelves.uid |
| frus.state | string | query | False | Filter by frus.state |
| frus.type | string | query | False | Filter by frus.type |
| frus.id | string | query | False | Filter by frus.id |
| id | string | query | False | Filter by id |
| nodes.usbs.supported | boolean | query | False | Filter by nodes.usbs.supported<br>• Introduced in: 9.9 |
| nodes.usbs.enabled | boolean | query | False | Filter by nodes.usbs.enabled<br>• Introduced in: 9.9 |
| nodes.usbs.ports.connected | boolean | query | False | Filter by nodes.usbs.ports.connected<br>• Introduced in: 9.9 |
| nodes.uuid | string | query | False | Filter by nodes.uuid |

| Name | Type | In | Required | Description |
|---|---|---|---|---|
| nodes.pcis.cards.slot | string | query | False | Filter by nodes.pcis.cards.slot<br>• Introduced in: 9.9 |
| nodes.pcis.cards.device | string | query | False | Filter by nodes.pcis.cards.device<br>• Introduced in: 9.9 |
| nodes.pcis.cards.info | string | query | False | Filter by nodes.pcis.cards.info<br>• Introduced in: 9.9 |
| nodes.position | string | query | False | Filter by nodes.position<br>• Introduced in: 9.8 |
| nodes.name | string | query | False | Filter by nodes.name |
| state | string | query | False | Filter by state |
| fields | array[string] | query | False | Specify the fields to return. |
| max_records | integer | query | False | Limit the number of records returned. |
| return_records | boolean | query | False | The default is true for GET calls. When set to false, only the number of records is returned.<br>• Default value: 1 |

| Name | Type | In | Required | Description |
|---|---|---|---|---|
| return_timeout | integer | query | False | The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.<br>• Default value: 1<br>• Max value: 120<br>• Min value: 0 |
| order_by | array[string] | query | False | Order results by specified fields and optional [asc |

## Response

```
Status: 200, Ok
```

| Name | Type | Description |
|---|---|---|
| _links | _links | |
| num_records | integer | Number of records. |
| records | array[chassis] | |

**Example response**


```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "num_records": 1,
  "records": {
    "frus": {
      "state": "ok",
      "type": "fan"
    },
    "id": "021352005981",
    "nodes": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "node1",
      "pcis": {
        "cards": {
          "device": "Intel Lewisburg series chipset SATA Controller",
          "info": "Additional Info: 0 (0xaaf00000)   SHM2S86Q120GLM22NP
FW1146 114473MB 512B/sect (SPG190108GW)",
          "slot": "0"
        }
      },
      "position": "top",
      "usbs": {
        "ports": {
        }
      },
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "shelves": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
```

```
        "uid": "7777841915827391056"
      },
      "state": "ok"
    }
  }
```


## Error

```
Status: Default, Error
```

| Name | Type | Description |
|---|---|---|
| error | error | |

### Example error


```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


## Definitions

**See Definitions**

href

| Name | Type | Description |
|---|---|---|
| href | string | |

_links

| Name | Type | Description |
|---|---|---|
| next | href | |
| self | href | |

frus

| Name | Type | Description |
|---|---|---|
| id | string | |
| state | string | |
| type | string | |

_links

| Name | Type | Description |
|---|---|---|
| self | href | |

cards

| Name | Type | Description |
|---|---|---|
| device | string | The description of the PCI card. |
| info | string | The info string from the device driver of the PCI card. |
| slot | string | The slot where the PCI card is placed. This can sometimes take the form of "6-1" to indicate slot and subslot. |

pcis

| Name | Type | Description |
|---|---|---|
| cards | array[cards] | |

ports

| Name | Type | Description |
| --- | --- | --- |
| connected | boolean | Indicates whether or not the USB port has a device connected to it. |

usbs

The status of the USB ports on the controller.

| Name | Type | Description |
| --- | --- | --- |
| enabled | boolean | Indicates whether or not the USB ports are enabled. |
| ports | array[ports] | |
| supported | boolean | Indicates whether or not USB ports are supported on the current platform. |

nodes

List of nodes in chassis.

| Name | Type | Description |
| --- | --- | --- |
| _links | _links | |
| name | string | |
| pcis | pcis | |
| position | string | The position of the node in the chassis, when viewed from the rear of the system. |
| usbs | usbs | The status of the USB ports on the controller. |
| uuid | string | |

shelf_reference

Shelf

| Name | Type | Description |
| --- | --- | --- |
| _links | _links | |
| uid | string | |

chassis

| Name | Type | Description |
|---|---|---|
| frus | array[frus] | List of FRUs in the chassis. |
| id | string | |
| nodes | array[nodes] | List of nodes in the chassis. |
| shelves | array[shelf_reference] | List of shelves in chassis. |
| state | string | |

error_arguments

| Name | Type | Description |
|---|---|---|
| code | string | Argument code |
| message | string | Message argument |

error

| Name | Type | Description |
|---|---|---|
| arguments | array[error_arguments] | Message arguments |
| code | string | Error code |
| message | string | Error message |
| target | string | The target parameter that caused the error. |

# Retrieve a chassis

GET `/cluster/chassis/{id}`

**Introduced In:** 9.6

Retrieves a specific chassis.

## Related ONTAP commands

- `system chassis show`
- `system chassis fru show`

## Learn more

- DOC /cluster/chassis

## Parameters

| Name | Type | In | Required | Description |
|---|---|---|---|---|
| id | string | path | True | Chassis ID |
| fields | array[string] | query | False | Specify the fields to return. |

## Response

```
Status: 200, Ok
```

| Name | Type | Description |
|---|---|---|
| frus | array[frus] | List of FRUs in the chassis. |
| id | string | |
| nodes | array[nodes] | List of nodes in the chassis. |
| shelves | array[shelf_reference] | List of shelves in chassis. |
| state | string | |

**Example response**


```
{
  "frus": {
    "state": "ok",
    "type": "fan"
  },
  "id": "021352005981",
  "nodes": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "pcis": {
      "cards": {
        "device": "Intel Lewisburg series chipset SATA Controller",
        "info": "Additional Info: 0 (0xaaf00000)   SHM2S86Q120GLM22NP
FW1146 114473MB 512B/sect (SPG190108GW)",
        "slot": "0"
      }
    },
    "position": "top",
    "usbs": {
      "ports": {
      }
    },
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "shelves": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uid": "7777841915827391056"
  },
  "state": "ok"
}
```


## Error

```
Status: Default, Error
```

| Name | Type | Description |
| --- | --- | --- |
| error | error | |

**Example error**

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

**See Definitions**

frus

| Name | Type | Description |
|---|---|---|
| id | string | |
| state | string | |
| type | string | |

href

| Name | Type | Description |
|---|---|---|
| href | string | |

_links

| Name | Type | Description |
|---|---|---|
| self | href | |

cards

| Name | Type | Description |
|---|---|---|
| device | string | The description of the PCI card. |
| info | string | The info string from the device driver of the PCI card. |
| slot | string | The slot where the PCI card is placed. This can sometimes take the form of "6-1" to indicate slot and subslot. |

pcis

| Name | Type | Description |
|---|---|---|
| cards | array[cards] | |

ports

| Name | Type | Description |
|---|---|---|
| connected | boolean | Indicates whether or not the USB port has a device connected to it. |

usbs

The status of the USB ports on the controller.

| Name | Type | Description |
|---|---|---|
| enabled | boolean | Indicates whether or not the USB ports are enabled. |
| ports | array[ports] | |
| supported | boolean | Indicates whether or not USB ports are supported on the current platform. |

nodes

List of nodes in chassis.

| Name | Type | Description |
|---|---|---|
| _links | _links | |
| name | string | |
| pcis | pcis | |
| position | string | The position of the node in the chassis, when viewed from the rear of the system. |
| usbs | usbs | The status of the USB ports on the controller. |
| uuid | string | |

shelf_reference

Shelf

| Name | Type | Description |
|---|---|---|
| _links | _links | |
| uid | string | |

error_arguments

| Name | Type | Description |
|---|---|---|
| code | string | Argument code |
| message | string | Message argument |

error

| Name | Type | Description |
| --- | --- | --- |
| arguments | array[error_arguments] | Message arguments |
| code | string | Error code |
| message | string | Error message |
| target | string | The target parameter that caused the error. |

**Copyright information**

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

**Trademark information**

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.