NVMe/FC Host Configuration for Oracle Linux 8.2 with ONTAP

ONTAP SAN Host

Ciaran McNamara
October 16, 2020

This PDF was generated from https://docs.netapp.com/us-en/ontap-sanhost/nvme_ol_82.html on March 06, 2021. Always check docs.netapp.com for the latest.

Table of Contents

NVMe/FC Host Configuration for Oracle Linux 8.2 with ONTAP . . . 1
- Supportability . . . 1
- Known limitations . . . 1
- Enabling NVMe/FC . . . 1
- Configuring the Broadcom FC Adapter for NVMe/FC . . . 2
- Validating NVMe/FC . . . 3
- Enabling 1MB I/O Size for Broadcom NVMe/FC . . . 6

NVMe/FC Host Configuration for Oracle Linux 8.2 with ONTAP

Supportability

NVMe/FC is supported on ONTAP 9.6 or later for Oracle Linux 8.2. Oracle Linux 8.2 host can run both NVMe/FC and FCP traffic through the same fibre channel (FC) initiator adapter ports. See the Hardware Universe for a list of supported FC adapters and controllers. For the most current list of supported configurations see the NetApp Interoperability Matrix.

Known limitations

None.

Enabling NVMe/FC

1. Install Oracle Linux 8.2 on the server.
2. After the installation is complete, verify that you are running the supported Unbreakable Enterprise kernel. See the NetApp Interoperability Matrix.

   ```
   # uname -r
   5.4.17-2011.1.2.el8uek.x86_64
   ```

3. Upgrade the nvme-cli package. The native nvme-cli package contains the NVMe/FC auto-connect scripts, ONTAP udev rule which enables round-robin load balancing for NVMe Multipath as well as the NetApp plug-in for ONTAP namespaces.

   ```
   # rpm -qa|grep nvme-cli
   nvme-cli-1.9-5.el8.x86_64
   ```

4. On the Oracle Linux 8.2 host, check the host NQN string at /etc/nvme/hostnqn and verify that it matches the host NQN string for the corresponding subsystem on the ONTAP array.

   ```
   # cat /etc/nvme/hostnqn
   nqn.2014-08.org.nvmexpress:uuid:9ed5b327-b9fc-4cf5-97b3-1b5d986345d1
   ```

```
::> vserver nvme subsystem host show -vserver vs_ol_nvme
Vserver  Subsystem Host NQN
----------- ---------------
------------------------------------------------------------
vs_ol_nvme
              nvme_ss_ol_1
                                  nqn.2014-
08.org.nvmexpress:uuid:9ed5b327-b9fc-4cf5-97b3-1b5d986345d1
```

If the hostnqn strings do not match, you should use the vserver modify command to update the host NQN string on your corresponding ONTAP array subsystem to match to host NQN string from etc/nvme/hostnqn on the host.

Configuring the Broadcom FC Adapter for NVMe/FC

1. Verify that you are using the supported adapter. For the most current list of supported adapters, see the NetApp Interoperability Matrix.

   ```
   # cat /sys/class/scsi_host/host*/modelname
   LPe32002-M2
   LPe32002-M2
   ```

   ```
   # cat /sys/class/scsi_host/host*/modeldesc
   Emulex LightPulse LPe32002-M2 2-Port 32Gb Fibre Channel Adapter
   Emulex LightPulse LPe32002-M2 2-Port 32Gb Fibre Channel Adapter
   ```

2. NVMe support in lpfc is already enabled by default:

   ```
   # cat /sys/module/lpfc/parameters/lpfc_enable_fc4_type
   3
   ```

   Newer lpfc drivers (both inbox and outbox) have lpfc_enable_fc4_type default set to 3. Therefore, you do not need to set this explicitly in the /etc/modprobe.d/lpfc.conf.

3. Verify that the NVMe/FC initiator ports are enabled and able to see the target ports, and all are up and running.

   In the example below, only a single initiator port has been enabled and connected with two target LIFs as seen in the below output:

```
# cat /sys/class/scsi_host/host*/nvme_info
NVME Initiator Enabled
XRI Dist lpfc0 Total 6144 IO 5894 ELS 250
NVME LPORT lpfc0 WWPN x100000109b1c1204 WWNN x200000109b1c1204 DID
x011d00 ONLINE
NVME RPORT WWPN x203800a098dfdd91 WWNN x203700a098dfdd91 DID x010c07
TARGET DISCSRVC ONLINE
NVME RPORT WWPN x203900a098dfdd91 WWNN x203700a098dfdd91 DID x011507
TARGET DISCSRVC ONLINE

NVME Statistics
LS: Xmt 0000000f78 Cmpl 0000000f78 Abort 00000000
LS XMIT: Err 00000000 CMPL: xb 00000000 Err 00000000
Total FCP Cmpl 000000002fe29bba Issue 000000002fe29bc4 OutIO
000000000000000a
abort 00001bc7 noxri 00000000 nondlp 00000000 qdepth 00000000 wqerr
00000000 err 00000000
FCP CMPL: xb 00001e15 Err 0000d906

NVME Initiator Enabled
XRI Dist lpfc1 Total 6144 IO 5894 ELS 250
NVME LPORT lpfc1 WWPN x100000109b1c1205 WWNN x200000109b1c1205 DID
x011900 ONLINE
NVME RPORT WWPN x203d00a098dfdd91 WWNN x203700a098dfdd91 DID x010007
TARGET DISCSRVC ONLINE
NVME RPORT WWPN x203a00a098dfdd91 WWNN x203700a098dfdd91 DID x012a07
TARGET DISCSRVC ONLINE

NVME Statistics
LS: Xmt 0000000fa8 Cmpl 0000000fa8 Abort 00000000
LS XMIT: Err 00000000 CMPL: xb 00000000 Err 00000000
Total FCP Cmpl 000000002e14f170 Issue 000000002e14f17a OutIO
000000000000000a
abort 000016bb noxri 00000000 nondlp 00000000 qdepth 00000000 wqerr
00000000 err 00000000
FCP CMPL: xb 00001f50 Err 0000d9f8
```

Validating NVMe/FC

1. Verify the following NVMe/FC settings.

```
# cat /sys/module/nvme_core/parameters/multipath
Y
```

```
# cat /sys/class/nvme-subsystem/nvme-subsys*/model
NetApp ONTAP Controller
NetApp ONTAP Controller
```

```
# cat /sys/class/nvme-subsystem/nvme-subsys*/iopolicy
round-robin
round-robin
```

In the above example, two namespaces are mapped to the Oracle Linux 8.2 ANA host. These are visible through four target LIFs: two local node LIFs and two other partner/remote node LIFs. This setup shows as two ANA Optimized and two ANA Inaccessible paths for each namespace on the host.

2. Verify that the namespaces are created.

```
# nvme list
Node                  SN
Model                                                    Namespace Usage
Format         FW Rev
--------------------   ---------------------------------------
---------------------------------------------- -----------------
------------------------------- ---------------- ---------------
/dev/nvme0n1     814vWBNRwf9HAAAAAAAB  NetApp ONTAP Controller
1                  85.90 GB / 85.90 GB     4 KiB + 0 B   FFFFFFFF
/dev/nvme0n2     814vWBNRwf9HAAAAAAAB  NetApp ONTAP Controller
2                  85.90 GB / 85.90 GB     4 KiB + 0 B   FFFFFFFF
/dev/nvme0n3     814vWBNRwf9HAAAAAAAB  NetApp ONTAP Controller
3                  85.90 GB / 85.90 GB     4 KiB + 0 B   FFFFFFFF
```

3. Verify the status of the ANA paths.

```
# nvme list-subsys /dev/nvme0n1
nvme-subsys0 - NQN=nqn.1992-
08.com.netapp:sn.5f5f2c4aa73b11e9967e00a098df41bd:subsystem.nvme_ss_ol_1
\
+- nvme0 fc traddr=nn-0x203700a098dfdd91:pn-0x203800a098dfdd91
host_traddr=nn-0x200000109b1c1204:pn-0x100000109b1c1204 live
inaccessible
+- nvme1 fc traddr=nn-0x203700a098dfdd91:pn-0x203900a098dfdd91
host_traddr=nn-0x200000109b1c1204:pn-0x100000109b1c1204 live
inaccessible
+- nvme2 fc traddr=nn-0x203700a098dfdd91:pn-0x203a00a098dfdd91
host_traddr=nn-0x200000109b1c1205:pn-0x100000109b1c1205 live optimized
+- nvme3 fc traddr=nn-0x203700a098dfdd91:pn-0x203d00a098dfdd91
host_traddr=nn-0x200000109b1c1205:pn-0x100000109b1c1205 live optimized
```

4. Verify the NetApp plug-in for ONTAP devices.

```
# nvme netapp ontapdevices -o column
Device                 Vserver                         Namespace Path
NSID    UUID
Size
----------------------- ------------------------------
------------------------------------------------------------------------
--------- ------------------------------------------------------------
---------
/dev/nvme0n1      vs_ol_nvme
/vol/ol_nvme_vol_1_1_0/ol_nvme_ns              1          72b887b1-5fb6-
47b8-be0b-33326e2542e2   85.90GB
/dev/nvme0n2      vs_ol_nvme
/vol/ol_nvme_vol_1_0_0/ol_nvme_ns              2          04bf9f6e-9031-
40ea-99c7-a1a61b2d7d08    85.90GB
/dev/nvme0n3      vs_ol_nvme
/vol/ol_nvme_vol_1_1_1/ol_nvme_ns              3          264823b1-8e03-
4155-80dd-e904237014a4  85.90GB

# nvme netapp ontapdevices -o json
{
"ONTAPdevices" : [
    {
        "Device" : "/dev/nvme0n1",
        "Vserver" : "vs_ol_nvme",
        "Namespace_Path" : "/vol/ol_nvme_vol_1_1_0/ol_nvme_ns",
        "NSID" : 1,
        "UUID" : "72b887b1-5fb6-47b8-be0b-33326e2542e2",
        "Size" : "85.90GB",
```

```
        "LBA_Data_Size" : 4096,
        "Namespace_Size" : 20971520
    },
    {
        "Device" : "/dev/nvme0n2",
        "Vserver" : "vs_ol_nvme",
        "Namespace_Path" : "/vol/ol_nvme_vol_1_0_0/ol_nvme_ns",
        "NSID" : 2,
        "UUID" : "04bf9f6e-9031-40ea-99c7-a1a61b2d7d08",
        "Size" : "85.90GB",
        "LBA_Data_Size" : 4096,
        "Namespace_Size" : 20971520
      },
      {
         "Device" : "/dev/nvme0n3",
         "Vserver" : "vs_ol_nvme",
         "Namespace_Path" : "/vol/ol_nvme_vol_1_1_1/ol_nvme_ns",
         "NSID" : 3,
         "UUID" : "264823b1-8e03-4155-80dd-e904237014a4",
         "Size" : "85.90GB",
         "LBA_Data_Size" : 4096,
         "Namespace_Size" : 20971520
       },
  ]
}
```

Enabling 1MB I/O Size for Broadcom NVMe/FC

The lpfc_sg_seg_cnt parameter must be set to 256 in order for the host to issue 1MB size I/O.

1. Set the `lpfc_sg_seg_cnt` parameter to 256.

```
# cat /etc/modprobe.d/lpfc.conf
options lpfc lpfc_sg_seg_cnt=256
```

2. Run a `dracut -f` command, and reboot the host.
3. Verify that `lpfc_sg_seg_cnt` is 256.

```
# cat /sys/module/lpfc/parameters/lpfc_sg_seg_cnt
256
```

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.