Citrix

ONTAP SAN Host

NetApp
March 06, 2021

This PDF was generated from https://docs.netapp.com/us-en/ontap-sanhost/hu_citrix_8x.html on March 06, 2021. Always check docs.netapp.com for the latest.

Table of Contents

Citrix 1
Using Citrix Hypervisor with NetApp ONTAP 1

Citrix

Using Citrix Hypervisor with NetApp ONTAP

Introduction

This document provides guidance on ONTAP SAN host configuration settings for Citrix Hypervisor 8.0, 8.1, 8.2 OS releases with FC, FCoE and iSCSi protocols.

SAN Booting

Before you begin

If you decide to use SAN booting, it must be supported by your configuration. You can use the NetApp Interoperability Matrix Tool to verify that your OS, HBA, HBA firmware and the HBA boot BIOS, and ONTAP version are supported.

1. Map the SAN boot LUN to the host.
2. Verify multiple paths are available.

   Remember, multiple paths will only be available after the host OS is up and running on the paths.

3. Enable SAN booting in the server BIOS for the ports to which the SAN boot LUN is mapped.

   For information on how to enable the HBA BIOS, see your vendor-specific documentation.

4. Reboot the host to verify the boot is successful.

Multipathing

Multipath support in Citrix Hypervisor is based on the Device Mapper Multipathd components. Device mapper nodes are not automatically created for all LUNs presented to the hypervisor and are only provisioned when LUNs are actively used by the Storage Management Layer (API). Citrix Hypervisor Storage Manager API plugin handles activating and deactivating multipath nodes automatically.

Due to incompatibilities with the Integrated Multipath Management architecture, Citrix recommends that you use the Citrix XenCenter application for managing the storage configuration. If it is necessary to query the status of Device Mapper tables manually, or list active device mapper multipath nodes on the system, you can use the `/sbin/mpathutil status` command to verify the settings for your ONTAP LUNs. For more information refer to the standard vendor documentation for Citrix Hypervisor.

Non-ASA Configuration

For non-ASA configuration there should be two groups of paths with different priorities. The paths with the higher priorities are Active/Optimized, meaning they are serviced by the controller where the aggregate is located. The paths with the lower priorities are active but are non-optimized because they are served from a different controller. The non-optimized paths are only used when no optimized paths are available.

Example

The following example displays the correct output for an ONTAP LUN with two Active/Optimized paths and two Active/Non-Optimized paths:

```
# mpathutil status
show topology
3600a0980383034587724507145353 17a dm-0 NETAPP  , LUN C-Mode
size=80G features='4 queue_if_no_path pg_init_retries 50
retain_attached_hw_handle' hwhandler='1 alua' wp=rw
|-+- policy='service-time 0' prio=50 status=active
| |- 2:0:2:0   sdc   8:32    active ready running
| |- 12:0:5:0  sdn   8:208   active ready running
| |- 2:0:6:0   sdg   8:96    active ready running
| `- 12:0:0:0  sdi   8:128   active ready running
`-+-`policy='service-time 0' prio=10 status=enabled
  |- 2:0:0:0   sda   8:0     active ready running
  |- 2:0:1:0   sdb   8:16    active ready running
  |- 12:0:3:0  sd1   8:176   active ready running
  `-12:0:6:0   sdo   8:224   active ready running
[root@sanhost ~]#
```

Do not use an excessive number of paths to a single LUN. No more than 4 paths should be required. More than 8 paths might cause path issues during storage failures.

Recommended Settings

The Citrix Hypervisor 8.x OS is compiled with all settings required to recognize and correctly manage ONTAP LUNs. For Citrix Hypervisor 8.x, an empty zerobyte `/etc/multipath.conf` file must exist, but you do not need to make specific changes to the file.

Enable the host multipath service from the **Xencenter Management Portal** and verify that the multipath service is enabled and running.

```
# systemct1 status multipathd
multipathd.service - Device-Mapper Multipath Device Controller
  Loaded:  load (/usr/lib/systemd/system/multipathd.service; enabled;
vendor preset: enabled)
 Drop-In:  /etc/systemd/system/multipathd.service.d
             slice.config
  Active:  active (running) since Fri YYYY-MM-DD 00:00:26 IST; 1 month 9
days ago
Main PID:  3789 (multipathd)
  CGroup:  /control.slice/multipathd.service
            3789  /sbin/multipathd
```

There is no requirement to append content to the `/etc/multipath.conf` file, unless you have devices that you do not want to be managed by multipath or you have existing settings that override defaults. You can add the following syntax to the multipath.conf file to exclude the unwanted devices.

Replace the **<DevID>** with the WWID string of the device you want to exclude. Use the following command to determine the WWID:

```
# cat /etc/multipath.conf
blacklist {
     wwid    <DevId>
     devnode "^(ram|raw|loop|fd|md|dm-|sr|scd|st)[0-9]*"
     devnode "^hd[a-z]"
     devnode "^cciss.*"
}
```

Example

In this example for Citrix Hypervisor 8.x, sda is the local SCSI disk that we need to the blacklist.

1. Run the following command to determine the WWID:

```
# lib/udev/scsi_id -gud /dev/sda
3600a0980383034587724507145353 17a
```

2. Add this WWID to the blacklist stanza in the `/etc/multipath.conf`:

```
#cat /etc/multipath.conf
blacklist {
  wwid    3600a0980383034587724507145353 17a
  devnode "^(ram|raw|loop|fd|md|dm-|sr|scd|st)[0-9*]"
  devnode "^hd[a-z]"
  devnode "^cciss.*"
}
```

Refer to the multipath parameter run time configuration by using the `$multipathd show config` command. You should always check your running configuration for legacy settings that might be overriding default settings, especially in the defaults section.

The following table shows the critical **multipathd** parameters for ONTAP LUNs and the required values. If a host is connected to LUNs from other vendors and any of these parameters are overridden, they need to be corrected by later stanzas in **multipath.conf** that apply specifically to ONTAP LUNs. If this is not done, the ONTAP LUNs might not work as expected. The following defaults should only be overridden in consultation with NetApp and/or the OS vendor and only when the impact is fully understood.

Parameter	Setting
detect_prio	yes
dev_loss_tmo	"infinity"
failback	immediate

Parameter	Setting
fast_io_fail_tmo	5
features	"3 queue_if_no_path pg_init_retries 50"
flush_on_last_del	"yes"
hardware_handler	"0"
path_checker	"tur"
path_grouping_policy	"group_by_prio"
path_selector	"service-time 0"
polling_interval	5
prio	"ontap"
product	LUN.*
retain_attached_hw_handler	yes
rr_weight	"uniform"
user_friendly_names	no
vendor	NETAPP

Example

The following example illustrates how to correct an overridden default. In this case, the **multipath.conf** file defines values for **path_checker** and **detect_prio** that are not compatible with ONTAP LUNs. If they cannot be removed because of other SAN arrays attached to the host, these parameters can be corrected specifically for ONTAP LUNs with a device stanza.

```
# cat /etc/multipath.conf
defaults {
  path_checker readsector0
  detect_prio no
}
devices{
        device{
                vendor "NETAPP "
                product "LUN.*"
                path_checker tur
                detect_prio yes
        }
}
```

Citrix Hypervisor recommends use of Citrix VM tools for all Linux and Windows based guest VMs for a supported configuration.

Known Problems and Limitations

NetApp Bug ID	Title	Description	Citrix Tracker ID
1242343	Kernel disruption on Citrix Hypervisor 8.0 with QLogic QLE2742 32GB FC during storage failover operations	Kernel disruption might occur during storage failover operations on Citrix Hypervisor 8.0 kernel (4.19.0+1) with QLogic QLE2742 32GB HBA. This issue prompts a reboot of the operating system and causes application disruption. If kdump is configured, the kernel disruption generates a vmcore file under the /var/crash/ directory. You can use the vmcore file to understand the cause of the failure. After the kernel disruption, you can recover the operating system by rebooting the host operating system and restarting the application.	NETAPP-98

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.