Cisco 스위치에서 Cisco Nexus 9336C-FX2 클러스터 스위치로 마이그레이션합니다

ONTAP Systems Switches

NetApp
February 04, 2022

This PDF was generated from https://docs.netapp.com/ko-kr/ontap-systems-switches/switch-cisco-9336/migrate-to-9336-overview.html on February 04, 2022. Always check docs.netapp.com for the latest.

목차

Cisco 스위치에서 Cisco Nexus 9336C-FX2 클러스터 스위치로 마이그레이션합니다 1
Cisco 스위치에서 Cisco Nexus 9336C-FX2 클러스터 스위치로 마이그레이션합니다 1
Cisco 스위치에서 Cisco Nexus 9336C-FX2 클러스터 스위치로 마이그레이션하는 방법 2

Cisco 스위치에서 Cisco Nexus 9336C-FX2 클러스터 스위치로 마이그레이션합니다

Cisco 스위치에서 Cisco Nexus 9336C-FX2 클러스터 스위치로 마이그레이션합니다

일부 구형 Cisco Nexus 클러스터 스위치를 Cisco Nexus 9336C-FX2 클러스터 스위치로 교체할 경우 특정 구성 정보, 포트 연결 및 케이블 연결 요구 사항을 알고 있어야 합니다.

- 지원되는 클러스터 스위치는 다음과 같습니다.
  - Nexus 9336C-FX2
  - Nexus 92300YC
  - Nexus 5596UP
  - Nexus 5020
  - Nexus 5010
- 클러스터 스위치는 노드 연결에 다음 포트를 사용합니다.
  - Nexus 9336C-FX2:
    - 포트 1-3: 중단모드(4x10G) 클러스터 내 포트, int e1/1/1-4, e1/2/1-4, e1/3/1-4
    - 포트 4-6: 클러스터 내부/HA 포트(4x25G), 내부 e1/4/1-4, e1/5/1-4, e1/6/1-4
    - 포트 7-34:40/100GbE 내부 클러스터/HA 포트, int e1/7-34
  - Nexus 92300YC:
    - 포트 e1/1-48(10/25 GbE) e1/49-64(40/100 GbE)
  - Nexus 5596UP:
    - 포트 1/1-40(10GbE)
  - Nexus 5020:
    - 포트 1/1-32(10GbE)
  - Nexus 5010(확장 포함):
    - 포트 e1/1-12, e2/1-6(10GbE)
- 클러스터 스위치는 다음과 같은 ISL(Inter-Switch Link) 포트를 사용합니다.
  - 포트 int e1/35-36: Nexus 9336C-FX2
  - 포트 e1/65-66 (100GbE): Nexus 92300YC
  - 포트 e1/41-48(10GbE): Nexus 5596UP
  - 포트 e1/33-40 (10GbE): Nexus 5020
  - 포트 e1/13-20 (10GbE): Nexus 5010
- Hardware Universe_에는 모든 클러스터 스위치에 대해 지원되는 케이블 연결에 대한 정보가 포함되어 있습니다.
- Nexus 9336C-FX2 스위치의 일부 포트가 10GbE 또는 40GbE에서 실행되도록 구성했습니다.

- 노드에서 Nexus 9336C-FX2 클러스터 스위치로 10GbE 및 40GbE 연결을 계획, 마이그레이션 및 문서화했습니다.
- 이 절차에서 지원되는 ONTAP 및 NX-OS 버전은 *Cisco* 이더넷 스위치 페이지에 있습니다.

  "Cisco 이더넷 스위치"

Cisco 스위치에서 Cisco Nexus 9336C-FX2 클러스터 스위치로 마이그레이션하는 방법

ONTAP 클러스터에 대한 운영 중단 없이 이전 Cisco 클러스터 스위치를 Cisco Nexus 9336C-FX2 클러스터 네트워크 스위치로 마이그레이션할 수 있습니다.

- 기존 클러스터가 올바르게 설정되고 작동해야 합니다.
- 무중단 운영을 보장하기 위해 모든 클러스터 포트가 가동 상태여야 합니다.
- Nexus 9336C-FX2 클러스터 스위치는 적절한 버전의 NX-OS 설치 및 RCF(Reference Configuration File)를 적용하여 구성 및 작동해야 합니다.
- 기존 클러스터 네트워크 구성에는 다음이 있어야 합니다.
  - 구형 Cisco 스위치를 사용하는 완전히 기능이 정상 작동하는 중복 NetApp 클러스터입니다.
  - 이전 Cisco 스위치와 새 스위치 모두에 대한 관리 연결 및 콘솔 액세스
  - 클러스터 LIF를 사용하는 UP 상태의 모든 클러스터 LIF는 홈 포트에 있습니다.
  - 이전 Cisco 스위치 간에 또는 새 스위치 간에 연결되고 연결된 ISL 포트

이 절차의 예에서는 다음 스위치 및 노드 명명법을 사용합니다.

- 기존 Cisco Nexus 5596UP 클러스터 스위치는 C1 및 C2입니다.
- 새로운 Nexus 9336C-FX2 클러스터 스위치는 CS1과 CS2입니다.
- 노드는 노드 1과 노드 2입니다.
- 클러스터 LIF는 노드 1의 node1_clus1 및 node1_clus2이고, 노드 2의 node2_clus1 및 node2_clus2입니다.
- 스위치 C2가 먼저 스위치 CS2로 대체된 다음 스위치 C1이 스위치 CS1로 대체됩니다.
  - 임시 ISL은 C1을 CS1에 연결하는 CS1에 구축됩니다.
  - 그런 다음 노드와 C2 사이의 케이블 연결을 C2에서 분리하고 CS2에 다시 연결합니다.
  - 그런 다음, 노드와 C1 사이의 케이블 연결을 C1에서 분리하고 CS1에 다시 연결합니다.
  - 그런 다음 C1과 CS1 사이의 임시 ISL이 제거됩니다.

    i. 이 클러스터에서 AutoSupport가 활성화되어 있으면 'system node AutoSupport invoke -node * -type all-message maINT=xh' AutoSupport 메시지를 호출하여 자동 케이스 생성을 억제합니다

    여기서 x는 유지 보수 기간(시간)입니다.

    > AutoSupport 메시지는 유지보수 기간 동안 자동 케이스 생성이 억제되도록 이 유지보수 작업의 기술 지원에 알립니다.

ii. 권한 수준을 고급으로 변경하고 'Set-Privilege advanced'라는 메시지가 나타나면 * y * 를 입력합니다

고급 프롬프트(*>)가 나타납니다.

iii. 모든 클러스터 LIF에서 'network interface show-vserver Cluster-fields auto-revert'라는 자동 되돌리기 기능이 설정되어 있는지 확인합니다

```
cluster1::*> network interface show -vserver Cluster -fields auto-
revert

          Logical
Vserver   Interface     Auto-revert
--------- ------------- ------------
Cluster
          node1_clus1   true
          node1_clus2   true
          node2_clus1   true
          node2_clus2   true

4 entries were displayed.
```

iv. 각 클러스터 인터페이스의 관리 또는 운영 상태 확인:

각 포트는 Link에, Health Status에 대해서는 Healthy로 표시되어야 합니다.

A. 네트워크 포트 속성 'network port show-ipSpace Cluster'를 표시합니다

```
cluster1::*> network port show -ipspace Cluster

Node: node1

Ignore
                                                        Speed(Mbps)
Health   Health
Port      IPspace      Broadcast Domain Link MTU  Admin/Oper
Status   Status
--------- ------------ ---------------- ---- ---- -----------
-------- ------
e0a       Cluster      Cluster          up   9000  auto/10000
healthy  false
e0b       Cluster      Cluster          up   9000  auto/10000
healthy  false

Node: node2

Ignore
                                                        Speed(Mbps)
Health   Health
Port      IPspace      Broadcast Domain Link MTU  Admin/Oper
Status   Status
--------- ------------ ---------------- ---- ---- -----------
-------- ------
e0a       Cluster      Cluster          up   9000  auto/10000
healthy  false
e0b       Cluster      Cluster          up   9000  auto/10000
healthy  false

4 entries were displayed.
```

B. 논리 인터페이스 및 지정된 홈 노드에 대한 정보를 표시합니다. 네트워크 인터페이스 show-vserver 클러스터

   각 LIF는 '상태 관리/작업'에 대해 위/위로 표시되고 '홈'에 대해서는 true로 표시되어야 합니다.

```
cluster1::*> network interface show -vserver Cluster

            Logical      Status     Network            Current
Current Is
Vserver     Interface    Admin/Oper Address/Mask       Node
Port    Home
----------- -----------  ---------- ------------------
------------- ------- ----
Cluster
            node1_clus1  up/up      169.254.209.69/16  node1
e0a     true
            node1_clus2  up/up      169.254.49.125/16  node1
e0b     true
            node2_clus1  up/up      169.254.47.194/16  node2
e0a     true
            node2_clus2  up/up      169.254.19.183/16  node2
e0b     true

4 entries were displayed.
```

v. 각 노드의 클러스터 포트는 'network device-discovery show-protocol CDP' 명령을 사용하여 노드 관점에서 기존 클러스터 스위치에 연결됩니다

```
cluster1::*> network device-discovery show -protocol cdp
Node/       Local  Discovered
Protocol    Port   Device (LLDP: ChassisID)  Interface
Platform
----------- ------ ------------------------- ----------------
----------------
node2      /cdp
            e0a    c1                        0/2
N5K-C5596UP
            e0b    c2                        0/2
N5K-C5596UP
node1      /cdp
            e0a    c1                        0/1
N5K-C5596UP
            e0b    c2                        0/1
N5K-C5596UP

4 entries were displayed.
```

vi. 클러스터 포트와 스위치는 'show CDP neighbors' 명령을 사용하여 스위치의 관점에서 다음과 같이 연결됩니다

```
c1# show cdp neighbors

Capability Codes: R - Router, T - Trans-Bridge, B - Source-Route-
Bridge
                  S - Switch, H - Host, I - IGMP, r - Repeater,
                  V - VoIP-Phone, D - Remotely-Managed-Device,
                  s - Supports-STP-Dispute


Device-ID             Local Intrfce Hldtme Capability  Platform
Port ID
node1                 Eth1/1         124   H           FAS2750
e0a
node2                 Eth1/2         124   H           FAS2750
e0a
c2                    Eth1/41        179   S I s       N5K-C5596UP
Eth1/41
c2                    Eth1/42        175   S I s       N5K-C5596UP
Eth1/42
c2                    Eth1/43        179   S I s       N5K-C5596UP
Eth1/43
c2                    Eth1/44        175   S I s       N5K-C5596UP
Eth1/44
c2                    Eth1/45        179   S I s       N5K-C5596UP
Eth1/45
c2                    Eth1/46        179   S I s       N5K-C5596UP
Eth1/46
c2                    Eth1/47        175   S I s       N5K-C5596UP
Eth1/47
c2                    Eth1/48        179   S I s       N5K-C5596UP
Eth1/48
Total entries displayed: 10

c2# show cdp neighbors

Capability Codes: R - Router, T - Trans-Bridge, B - Source-Route-
Bridge
                  S - Switch, H - Host, I - IGMP, r - Repeater,
                  V - VoIP-Phone, D - Remotely-Managed-Device,
                  s - Supports-STP-Dispute


Device-ID             Local Intrfce Hldtme Capability  Platform
Port ID
node1                 Eth1/1        124    H           FAS2750
e0b
```

```
node2                    Eth1/2        124    H           FAS2750
e0b
c1                       Eth1/41       175    S I s       N5K-C5596UP
Eth1/41
c1                       Eth1/42       175    S I s       N5K-C5596UP
Eth1/42
c1                       Eth1/43       175    S I s       N5K-C5596UP
Eth1/43
c1                       Eth1/44       175    S I s       N5K-C5596UP
Eth1/44
c1                       Eth1/45       175    S I s       N5K-C5596UP
Eth1/45
c1                       Eth1/46       175    S I s       N5K-C5596UP
Eth1/46
c1                       Eth1/47       176    S I s       N5K-C5596UP
Eth1/47
c1                       Eth1/48       176    S I s       N5K-C5596UP
Eth1/48
```

vii. 'cluster ping -cluster -node -name' 명령을 사용하여 클러스터 네트워크가 완전히 연결되어 있는지 확인합니다

```
cluster1::*> cluster ping-cluster -node node2
Host is node2
Getting addresses from network interface table...
Cluster node1_clus1 169.254.209.69 node1     e0a
Cluster node1_clus2 169.254.49.125 node1     e0b
Cluster node2_clus1 169.254.47.194 node2     e0a
Cluster node2_clus2 169.254.19.183 node2     e0b
Local = 169.254.47.194 169.254.19.183
Remote = 169.254.209.69 169.254.49.125
Cluster Vserver Id = 4294967293
Ping status:
....
Basic connectivity succeeds on 4 path(s)
Basic connectivity fails on 0 path(s)
................
Detected 9000 byte MTU on 4 path(s):
    Local 169.254.19.183 to Remote 169.254.209.69
    Local 169.254.19.183 to Remote 169.254.49.125
    Local 169.254.47.194 to Remote 169.254.209.69
    Local 169.254.47.194 to Remote 169.254.49.125
Larger than PMTU communication succeeds on 4 path(s)
RPC status:
2 paths up, 0 paths down (tcp check)
2 paths up, 0 paths down (udp check)
```

viii. C1 및 CS1 사이에 있는 포트 e1/41-48의 cs1에 임시 ISL을 구성합니다.

다음 예에서는 새 ISL이 C1 및 CS1에 어떻게 구성되어 있는지 보여 줍니다.

```
cs1# configure
Enter configuration commands, one per line. End with CNTL/Z.
cs1(config)# interface e1/41-48
cs1(config-if-range)# description temporary ISL between Nexus
5596UP and Nexus 9336C
cs1(config-if-range)# no lldp transmit
cs1(config-if-range)# no lldp receive
cs1(config-if-range)# switchport mode trunk
cs1(config-if-range)# no spanning-tree bpduguard enable
cs1(config-if-range)# channel-group 101 mode active
cs1(config-if-range)# exit
cs1(config)# interface port-channel 101
cs1(config-if)# switchport mode trunk
cs1(config-if)# spanning-tree port type network
cs1(config-if)# exi
cs1(config)# exit
```

ix. 포트 1/41-48에서 ISL 케이블을 C2에서 분리하고 케이블을 CS1의 포트 1/41-48에 연결합니다.

x. ISL 포트 및 포트 채널이 C1 및 CS1을 연결하는 작동 중인지 확인합니다. '포트 채널 요약 정보'

   다음 예에서는 ISL 포트가 C1 및 CS1에서 작동하는지 확인하는 데 사용되는 Cisco show port-channel summary 명령을 보여 줍니다.

```
c1# show port-channel summary
Flags:  D - Down        P - Up in port-channel (members)
        I - Individual  H - Hot-standby (LACP only)
        s - Suspended   r - Module-removed
        b - BFD Session Wait
        S - Switched    R - Routed
        U - Up (port-channel)
        p - Up in delay-lacp mode (member)
        M - Not in use. Min-links not met
----------------------------------------------------------------------
-----------
Group Port-       Type     Protocol  Member Ports
      Channel
----------------------------------------------------------------------
-----------
1     Po1(SU)     Eth      LACP      Eth1/41(P)   Eth1/42(P)
Eth1/43(P)
                                     Eth1/44(P)   Eth1/45(P)
Eth1/46(P)
                                     Eth1/47(P)   Eth1/48(P)


cs1# show port-channel summary
Flags:  D - Down        P - Up in port-channel (members)
        I - Individual  H - Hot-standby (LACP only)
        s - Suspended   r - Module-removed
        b - BFD Session Wait
        S - Switched    R - Routed
        U - Up (port-channel)
        p - Up in delay-lacp mode (member)
        M - Not in use. Min-links not met
----------------------------------------------------------------------
-----------
Group Port-       Type     Protocol  Member Ports
      Channel
----------------------------------------------------------------------
-----------
1     Po1(SU)     Eth      LACP      Eth1/35(P)   Eth1/36(P)
101   Po101(SU)   Eth      LACP      Eth1/41(P)   Eth1/42(P)
Eth1/43(P)
                                     Eth1/44(P)   Eth1/45(P)
Eth1/46(P)
                                     Eth1/47(P)   Eth1/48(P)
```

i. 노드 1의 경우 C2의 e1/1에서 케이블을 분리한 다음 Nexus 9336C-FX2에서 지원하는 적절한 케이블을

사용하여 CS2의 e1/1에 케이블을 연결합니다.

ii. 노드 2의 경우 C2의 e1/2에서 케이블을 분리한 다음 Nexus 9336C-FX2에서 지원하는 적절한 케이블을 사용하여 CS2의 e1/2에 케이블을 연결합니다.

iii. 각 노드의 클러스터 포트는 이제 노드의 관점에서 클러스터 스위치에 다음과 같이 연결됩니다. 'network device-discovery show-protocol CDP'

```
cluster1::*> network device-discovery show -protocol cdp

Node/       Local  Discovered
Protocol    Port   Device (LLDP: ChassisID)  Interface
Platform
----------- ------ ------------------------- ----------------
----------------
node2      /cdp
            e0a    c1                        0/2
N5K-C5596UP
            e0b    cs2                       0/2
N9K-C9336C
node1      /cdp
            e0a    c1                        0/1
N5K-C5596UP
            e0b    cs2                       0/1
N9K-C9336C

4 entries were displayed.
```

iv. 노드 1의 경우, 1C1의 e1/1에서 케이블을 분리한 다음 Nexus 9336C-FX2에서 지원하는 적절한 케이블을 사용하여 CS1의 e1/1에 케이블을 연결합니다.

v. 노드 2의 경우, C1의 e1/2에서 케이블을 분리한 다음 Nexus 9336C-FX2에서 지원하는 적절한 케이블을 사용하여 CS1의 e1/2에 케이블을 연결합니다.

vi. 각 노드의 클러스터 포트는 이제 노드의 관점에서 클러스터 스위치에 다음과 같이 연결됩니다. 'network device-discovery show-protocol CDP'

```
cluster1::*> network device-discovery show -protocol cdp
Node/       Local  Discovered
Protocol    Port   Device (LLDP: ChassisID)  Interface
Platform
----------- ------ ------------------------- ----------------
----------------
node2      /cdp
            e0a    cs1                       0/2
N9K-C9336C
            e0b    cs2                       0/2
N9K-C9336C
node1      /cdp
            e0a    cs1                       0/1
N9K-C9336C
            e0b    cs2                       0/1
N9K-C9336C
4 entries were displayed.
```

vii. CS1과 C1 사이의 임시 ISL을 삭제합니다.

```
cs1(config)# no interface port-channel 10
cs1(config)# interface e1/41-48
cs1(config-if-range)# lldp transmit
cs1(config-if-range)# lldp receive
cs1(config-if-range)# no switchport mode trunk
cs1(config-if-range)# no channel-group
cs1(config-if-range)# description 10GbE Node Port
cs1(config-if-range)# spanning-tree bpduguard enable
cs1(config-if-range)# exit
cs1(config)# exit
```

viii. 클러스터의 최종 구성 'network port show-ipSpace Cluster'를 확인합니다

각 포트는 Link에, Health Status에 대해서는 Healthy로 표시되어야 합니다.

```
cluster1::*> network port show -ipspace Cluster

Node: node1

Ignore
                                                  Speed(Mbps) Health
Health
Port      IPspace      Broadcast Domain Link MTU  Admin/Oper  Status
Status
```

```
--------- ------------ ---------------- ---- ---- ----------- --------
------
e0a       Cluster      Cluster          up   9000  auto/10000 healthy
false
e0b       Cluster      Cluster          up   9000  auto/10000 healthy
false

Node: node2

Ignore
                                                   Speed(Mbps) Health
Health
Port      IPspace      Broadcast Domain Link MTU  Admin/Oper  Status
Status
--------- ------------ ---------------- ---- ---- ----------- --------
------
e0a       Cluster      Cluster          up   9000  auto/10000 healthy
false
e0b       Cluster      Cluster          up   9000  auto/10000 healthy
false

4 entries were displayed.


cluster1::*> network interface show -vserver Cluster

            Logical    Status     Network            Current
Current Is
Vserver     Interface  Admin/Oper Address/Mask       Node          Port
Home
----------- ---------- ---------- ------------------ -------------
------- ----
Cluster
            node1_clus1  up/up    169.254.209.69/16  node1         e0a
true
            node1_clus2  up/up    169.254.49.125/16  node1         e0b
true
            node2_clus1  up/up    169.254.47.194/16  node2         e0a
true
            node2_clus2  up/up    169.254.19.183/16  node2         e0b
true

4 entries were displayed.


cluster1::*> network device-discovery show -protocol cdp
```

```
Node/       Local  Discovered
Protocol    Port   Device (LLDP: ChassisID)  Interface         Platform
----------- ------ ------------------------- ----------------
----------------
node2      /cdp
            e0a    cs1                       0/2               N9K-
C9336C
            e0b    cs2                       0/2               N9K-
C9336C
node1      /cdp
            e0a    cs1                       0/1               N9K-
C9336C
            e0b    cs2                       0/1               N9K-
C9336C

4 entries were displayed.


cs1# show cdp neighbors

Capability Codes: R - Router, T - Trans-Bridge, B - Source-Route-Bridge
                  S - Switch, H - Host, I - IGMP, r - Repeater,
                  V - VoIP-Phone, D - Remotely-Managed-Device,
                  s - Supports-STP-Dispute

Device-ID          Local Intrfce  Hldtme Capability  Platform      Port
ID
node1              Eth1/1         124    H           FAS2750       e0a
node2              Eth1/2         124    H           FAS2750       e0a
cs2                Eth1/35        179    R S I s     N9K-C9336C
Eth1/35
cs2                Eth1/36        179    R S I s     N9K-C9336C
Eth1/36


cs2# show cdp neighbors

Capability Codes: R - Router, T - Trans-Bridge, B - Source-Route-Bridge
                  S - Switch, H - Host, I - IGMP, r - Repeater,
                  V - VoIP-Phone, D - Remotely-Managed-Device,
                  s - Supports-STP-Dispute

Device-ID          Local Intrfce  Hldtme Capability  Platform      Port
ID
node1              Eth1/1         124    H           FAS2750       e0b
node2              Eth1/2         124    H           FAS2750       e0b
```

```
cs1                 Eth1/35        179    R S I s     N9K-C9336C
Eth1/35
cs1                 Eth1/36        179    R S I s     N9K-C9336C
Eth1/36

Total entries displayed: 4
```

i. 클러스터 네트워크에 'cluster ping-cluster-node-name'(클러스터 ping-cluster-node-name)이 완전히 연결되어 있는지 확인합니다

```
cluster1::*> set -priv advanced

Warning: These advanced commands are potentially dangerous; use them
only when
         directed to do so by NetApp personnel.
Do you want to continue? {y|n}: y

cluster1::*> **cluster ping-cluster -node node2**
Host is node2
Getting addresses from network interface table...
Cluster node1_clus1 169.254.209.69 node1     e0a
Cluster node1_clus2 169.254.49.125 node1     e0b
Cluster node2_clus1 169.254.47.194 node2     e0a
Cluster node2_clus2 169.254.19.183 node2     e0b
Local = 169.254.47.194 169.254.19.183
Remote = 169.254.209.69 169.254.49.125
Cluster Vserver Id = 4294967293
Ping status:
....
Basic connectivity succeeds on 4 path(s)
Basic connectivity fails on 0 path(s)
................
Detected 9000 byte MTU on 4 path(s):
    Local 169.254.19.183 to Remote 169.254.209.69
    Local 169.254.19.183 to Remote 169.254.49.125
    Local 169.254.47.194 to Remote 169.254.209.69
    Local 169.254.47.194 to Remote 169.254.49.125
Larger than PMTU communication succeeds on 4 path(s)
RPC status:
2 paths up, 0 paths down (tcp check)
2 paths up, 0 paths down (udp check)


cluster1::*> set -privilege admin
cluster1::*>
```

ii. ONTAP 9.8 이상에서는 시스템 스위치 이더넷 로그 설정 암호 시스템 스위치 이더넷 로그 활성화 수집 명령을 사용하여 스위치 관련 로그 파일을 수집하는 이더넷 스위치 상태 모니터 로그 수집 기능을 활성화합니다

```
cluster1::*> system switch ethernet log setup-password
Enter the switch name: <return>
The switch name entered is not recognized.
Choose from the following list:
cs1
cs2

cluster1::*> system switch ethernet log setup-password

Enter the switch name: cs1
RSA key fingerprint is
e5:8b:c6:dc:e2:18:18:09:36:63:d9:63:dd:03:d9:cc
Do you want to continue? {y|n}::[n] y

Enter the password: <enter switch password>
Enter the password again: <enter switch password>

cluster1::*> system switch ethernet log setup-password

Enter the switch name: cs2
RSA key fingerprint is
57:49:86:a1:b9:80:6a:61:9a:86:8e:3c:e3:b7:1f:b1
Do you want to continue? {y|n}:: [n] y

Enter the password: <enter switch password>
Enter the password again: <enter switch password>

cluster1::*> system  switch ethernet log enable-collection

Do you want to enable cluster log collection for all nodes in the
cluster?
{y|n}: [n] y

Enabling cluster switch log collection.

cluster1::*>
```

이러한 명령에서 오류가 반환되면 NetApp 지원에 문의하십시오.

iii. ONTAP 릴리스 9.5P16, 9.6P12 및 9.7P10 이상의 패치 릴리스의 경우, 'system cluster cluster-switch log setup-password system cluster-switch log enable-collection' 명령을 사용하여 스위치 관련 로그 파일을 수집하기 위한 이더넷 스위치 상태 모니터 로그 수집 기능을 활성화합니다

```
cluster1::*> system cluster-switch log setup-password
Enter the switch name: <return>
The switch name entered is not recognized.
Choose from the following list:
cs1
cs2

cluster1::*> system cluster-switch log setup-password

Enter the switch name: cs1
RSA key fingerprint is
e5:8b:c6:dc:e2:18:18:09:36:63:d9:63:dd:03:d9:cc
Do you want to continue? {y|n}::[n] y

Enter the password: <enter switch password>
Enter the password again: <enter switch password>

cluster1::*> system cluster-switch log setup-password

Enter the switch name: cs2
RSA key fingerprint is
57:49:86:a1:b9:80:6a:61:9a:86:8e:3c:e3:b7:1f:b1
Do you want to continue? {y|n}:: [n] y

Enter the password: <enter switch password>
Enter the password again: <enter switch password>

cluster1::*> system cluster-switch log enable-collection

Do you want to enable cluster log collection for all nodes in the
cluster?
{y|n}: [n] y

Enabling cluster switch log collection.

cluster1::*>
```

이러한 명령에서 오류가 반환되면 NetApp 지원에 문의하십시오.

iv. 자동 케이스 생성을 억제한 경우 AutoSupport 메시지 '시스템 노드 AutoSupport invoke -node * -type all-message MAINT=end'를 호출하여 다시 활성화합니다

Copyright Information

Copyright © 2022 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.