安裝硬體
Cluster and storage switches

NetApp
March 22, 2024

This PDF was generated from https://docs.netapp.com/zh-tw/ontap-systems-switches/switch-cisco-92300/setup-worksheet-92300yc.html on March 22, 2024. Always check docs.netapp.com for the latest.

目錄

安裝硬體 1
完成Cisco Nexus 2300YC佈線工作表 1
設定Cisco Nexus 2300YC交換器 7

安裝硬體

完成Cisco Nexus 2300YC佈線工作表

如果您想要記錄支援的平台、請下載本頁的PDF檔案、並填寫佈線工作表。

佈線工作表範例提供從交換器到控制器的建議連接埠指派範例。空白工作表提供範本、可用於設定叢集。

佈線工作表範例

每對交換器的連接埠定義範例如下：

叢集交換器**A**		叢集交換器**B**	
交換器連接埠	節點與連接埠使用量	交換器連接埠	節點與連接埠使用量
1.	10/25 GbE節點	1.	10/25 GbE節點
2.	10/25 GbE節點	2.	10/25 GbE節點
3.	10/25 GbE節點	3.	10/25 GbE節點
4.	10/25 GbE節點	4.	10/25 GbE節點
5.	10/25 GbE節點	5.	10/25 GbE節點
6.	10/25 GbE節點	6.	10/25 GbE節點
7.	10/25 GbE節點	7.	10/25 GbE節點
8.	10/25 GbE節點	8.	10/25 GbE節點
9.	10/25 GbE節點	9.	10/25 GbE節點
10.	10/25 GbE節點	10.	10/25 GbE節點
11.	10/25 GbE節點	11.	10/25 GbE節點
12.	10/25 GbE節點	12.	10/25 GbE節點
13.	10/25 GbE節點	13.	10/25 GbE節點
14	10/25 GbE節點	14	10/25 GbE節點

叢集交換器**A**		叢集交換器**B**	
15	10/25 GbE節點	15	10/25 GbE節點
16	10/25 GbE節點	16	10/25 GbE節點
17	10/25 GbE節點	17	10/25 GbE節點
18	10/25 GbE節點	18	10/25 GbE節點
19	10/25 GbE節點	19	10/25 GbE節點
20	10/25 GbE節點	20	10/25 GbE節點
21	10/25 GbE節點	21	10/25 GbE節點
22	10/25 GbE節點	22	10/25 GbE節點
23	10/25 GbE節點	23	10/25 GbE節點
24	10/25 GbE節點	24	10/25 GbE節點
25	10/25 GbE節點	25	10/25 GbE節點
26	10/25 GbE節點	26	10/25 GbE節點
27	10/25 GbE節點	27	10/25 GbE節點
28.28	10/25 GbE節點	28.28	10/25 GbE節點
29	10/25 GbE節點	29	10/25 GbE節點
30	10/25 GbE節點	30	10/25 GbE節點
31	10/25 GbE節點	31	10/25 GbE節點
32	10/25 GbE節點	32	10/25 GbE節點
33	10/25 GbE節點	33	10/25 GbE節點
34	10/25 GbE節點	34	10/25 GbE節點
35	10/25 GbE節點	35	10/25 GbE節點

叢集交換器**A**		叢集交換器**B**	
36	10/25 GbE節點	36	10/25 GbE節點
37	10/25 GbE節點	37	10/25 GbE節點
38	10/25 GbE節點	38	10/25 GbE節點
39	10/25 GbE節點	39	10/25 GbE節點
40	10/25 GbE節點	40	10/25 GbE節點
41.	10/25 GbE節點	41.	10/25 GbE節點
42.	10/25 GbE節點	42.	10/25 GbE節點
43.	10/25 GbE節點	43.	10/25 GbE節點
44	10/25 GbE節點	44	10/25 GbE節點
45	10/25 GbE節點	45	10/25 GbE節點
46	10/25 GbE節點	46	10/25 GbE節點
47	10/25 GbE節點	47	10/25 GbE節點
48	10/25 GbE節點	48	10/25 GbE節點
49	40/100 GbE節點	49	40/100 GbE節點
50	40/100 GbE節點	50	40/100 GbE節點
51.	40/100 GbE節點	51.	40/100 GbE節點
52.	40/100 GbE節點	52.	40/100 GbE節點
53.	40/100 GbE節點	53.	40/100 GbE節點
54	40/100 GbE節點	54	40/100 GbE節點
55	40/100 GbE節點	55	40/100 GbE節點
56	40/100 GbE節點	56	40/100 GbE節點

叢集交換器**A**		叢集交換器**B**	
57	40/100 GbE節點	57	40/100 GbE節點
58	40/100 GbE節點	58	40/100 GbE節點
59	40/100 GbE節點	59	40/100 GbE節點
60	40/100 GbE節點	60	40/100 GbE節點
61.	40/100 GbE節點	61.	40/100 GbE節點
62.	40/100 GbE節點	62.	40/100 GbE節點
63.	40/100 GbE節點	63.	40/100 GbE節點
64	40/100 GbE節點	64	40/100 GbE節點
65	100 GbE ISL至交換器B連接埠65	65	100 GbE ISL以交換器A連接埠65
66	100 GbE ISL至交換器B連接埠66	66	100 GbE ISL以交換器A連接埠65

空白的佈線工作表

您可以使用空白的佈線工作表來記錄叢集中支援作為節點的平台。的_支援叢集連線_區段 "Hardware Universe" 定義平台所使用的叢集連接埠。

叢集交換器**A**		叢集交換器**B**	
交換器連接埠	節點/連接埠使用量	交換器連接埠	節點/連接埠使用量
1.		1.	
2.		2.	
3.		3.	
4.		4.	
5.		5.	
6.		6.	

叢集交换器**A**		叢集交换器**B**	
7.		7.	
8.		8.	
9.		9.	
10.		10.	
11.		11.	
12.		12.	
13.		13.	
14		14	
15		15	
16		16	
17		17	
18		18	
19		19	
20		20	
21		21	
22		22	
23		23	
24		24	
25		25	
26		26	
27		27	
28.28		28.28	

叢集交换器**A**		叢集交换器**B**	
29		29	
30		30	
31		31	
32		32	
33		33	
34		34	
35		35	
36		36	
37		37	
38		38	
39		39	
40		40	
41.		41.	
42.		42.	
43.		43.	
44		44	
45		45	
46		46	
47		47	
48		48	
49		49	
50		50	

叢集交換器**A**		叢集交換器**B**	
51.		51.	
52.		52.	
53.		53.	
54		54	
55		55	
56		56	
57		57	
58		58	
59		59	
60		60	
61.		61.	
62.		62.	
63.		63.	
64		64	
65	ISL至交換器B連接埠65	65	ISL至交換器A連接埠65
66	ISL至交換器B連接埠66	66	ISL至交換器A連接埠66

設定Cisco Nexus 2300YC交換器

請遵循此程序來設定及設定Cisco Nexus 2300YC交換器。

步驟

1. 將序列連接埠連接至主機或序列連接埠。
2. 將管理連接埠（位於交換器的非連接埠端）連接至SFTP伺服器所在的相同網路。
3. 在主控台設定主機端序列設定：
    - 9600傳輸速率

- 8個資料位元
- 1停止位元
- 同位元檢查：無
- 流程控制：無

4. 首次開機或清除執行組態後重新開機時、Nexus 92300YC交換器會在開機週期中循環運作。輸入* yes *中止開機自動資源配置、以中斷此週期。

   隨即顯示系統管理員帳戶設定。

   顯示範例

```
$ VDC-1 %$ %POAP-2-POAP_INFO:   - Abort Power On Auto Provisioning
[yes - continue with normal setup, skip - bypass password and basic
configuration, no - continue with Power On Auto Provisioning]
(yes/skip/no)[no]: y
Disabling POAP.......Disabling POAP
2019 Apr 10 00:36:17 switch %$ VDC-1 %$ poap: Rolling back, please
wait... (This may take 5-15 minutes)

          ---- System Admin Account Setup ----

Do you want to enforce secure password standard (yes/no) [y]:
```

5. 輸入* y*以強制執行安全密碼標準：

```
Do you want to enforce secure password standard (yes/no) [y]: y
```

6. 輸入並確認使用者管理的密碼：

```
Enter the password for "admin":
Confirm the password for "admin":
```

7. 鍵入* yes*以進入「基本系統組態」對話方塊。

顯示範例

```
This setup utility will guide you through the basic configuration of
the system. Setup configures only enough connectivity for management
of the system.

Please register Cisco Nexus9000 Family devices promptly with your
supplier. Failure to register may affect response times for initial
service calls. Nexus9000 devices must be registered to receive
entitled support services.

Press Enter at anytime to skip a dialog. Use ctrl-c at anytime
to skip the remaining dialogs.

Would you like to enter the basic configuration dialog (yes/no):
```

8. 建立另一個登入帳戶：

```
Create another login account (yes/no) [n]:
```

9. 設定唯讀和讀寫SNMP社群字串：

```
Configure read-only SNMP community string (yes/no) [n]:

Configure read-write SNMP community string (yes/no) [n]:
```

10. 設定叢集交換器名稱：

```
Enter the switch name : cs2
```

11. 設定頻外管理介面：

```
Continue with Out-of-band (mgmt0) management configuration? (yes/no)
[y]: y

Mgmt0 IPv4 address : 172.22.133.216

Mgmt0 IPv4 netmask : 255.255.224.0

Configure the default gateway? (yes/no) [y]: y

IPv4 address of the default gateway : 172.22.128.1
```

12. 設定進階IP選項：

```
Configure advanced IP options? (yes/no) [n]: n
```

13. 設定遠端登入服務：

```
Enable the telnet service? (yes/no) [n]: n
```

14. 設定SSH服務和SSH金鑰：

```
Enable the ssh service? (yes/no) [y]: y

       Type of ssh key you would like to generate (dsa/rsa) [rsa]: rsa

       Number of rsa key bits <1024-2048> [1024]: 2048
```

15. 設定其他設定：

```
Configure the ntp server? (yes/no) [n]: n

  Configure default interface layer (L3/L2) [L2]: L2

  Configure default switchport interface state (shut/noshut) [noshut]:
noshut

  Configure CoPP system profile (strict/moderate/lenient/dense)
[strict]: strict
```

16. 確認交換器資訊並儲存組態：

```
Would you like to edit the configuration? (yes/no) [n]: n

Use this configuration and save it? (yes/no) [y]: y

[] 100%
Copy complete, now saving to disk (please wait)...
Copy complete.
```

接下來呢？

"準備安裝NX-OS軟體和RCF"。

版權資訊

Copyright © 2024 NetApp, Inc. 版權所有。台灣印製。非經版權所有人事先書面同意，不得將本受版權保護文件的任何部分以任何形式或任何方法（圖形、電子或機械）重製，包括影印、錄影、錄音或儲存至電子檢索系統中。

由 NetApp 版權資料衍伸之軟體必須遵守下列授權和免責聲明：

此軟體以 NETAPP「原樣」提供，不含任何明示或暗示的擔保，包括但不限於有關適售性或特定目的適用性之擔保，特此聲明。於任何情況下，就任何已造成或基於任何理論上責任之直接性、間接性、附隨性、特殊性、懲罰性或衍生性損害（包括但不限於替代商品或服務之採購；使用、資料或利潤上的損失；或企業營運中斷），無論是在使用此軟體時以任何方式所產生的契約、嚴格責任或侵權行為（包括疏忽或其他）等方面，NetApp 概不負責，即使已被告知有前述損害存在之可能性亦然。

NetApp 保留隨時變更本文所述之任何產品的權利，恕不另行通知。NetApp 不承擔因使用本文所述之產品而產生的責任或義務，除非明確經過 NetApp 書面同意。使用或購買此產品並不會在依據任何專利權、商標權或任何其他 NetApp 智慧財產權的情況下轉讓授權。

本手冊所述之產品受到一項（含）以上的美國專利、國外專利或申請中專利所保障。

有限權利說明：政府機關的使用、複製或公開揭露須受 DFARS 252.227-7013（2014 年 2 月）和 FAR 52.227-19（2007 年 12 月）中的「技術資料權利 - 非商業項目」條款 (b)(3) 小段所述之限制。

此處所含屬於商業產品和 / 或商業服務（如 FAR 2.101 所定義）的資料均為 NetApp, Inc. 所有。根據本協議提供的所有 NetApp 技術資料和電腦軟體皆屬於商業性質，並且完全由私人出資開發。 美國政府對於該資料具有非專屬、非轉讓、非轉授權、全球性、有限且不可撤銷的使用權限，僅限於美國政府為傳輸此資料所訂合約所允許之範圍，並基於履行該合約之目的方可使用。除非本文另有規定，否則未經 NetApp Inc. 事前書面許可，不得逕行使用、揭露、重製、修改、履行或展示該資料。美國政府授予國防部之許可權利，僅適用於 DFARS 條款 252.227-7015(b)（2014 年 2 月）所述權利。

商標資訊

NETAPP、NETAPP 標誌及 http://www.netapp.com/TM 所列之標章均為 NetApp, Inc. 的商標。文中所涉及的所有其他公司或產品名稱，均為其各自所有者的商標，不得侵犯。