更換Cisco Nexus 3232C儲存交換器

ONTAP Systems Switches

NetApp
May 03, 2022

This PDF was generated from https://docs.netapp.com/zh-tw/ontap-systems-switches/switch-cisco-3232c/task-steps-to-replace-a-cisco-nexus-3232c-storage-switch.html on May 03, 2022. Always check docs.netapp.com for the latest.

目錄

更換Cisco Nexus 3232C儲存交換器 1
更換Cisco Nexus 3232C儲存交換器的步驟 1

更換Cisco Nexus 3232C儲存交換器

更換Cisco Nexus 3232C儲存交換器時、您必須注意特定的組態資訊、連接埠連線和纜線需求。

在Cisco Nexus儲存交換器上安裝NX-OS軟體和RCFs之前、您必須先確認下列情況：

- 您的系統可支援Cisco Nexus 3232C儲存交換器。
- 您必須查閱Cisco乙太網路交換器頁面上的交換器相容性表、以取得支援ONTAP 的版本、包括支援的功能、NX-OS和RCF。

> 您應該知道RCF和NX-OS版本中的命令語法可能會有相依性。

- 您必須參閱Cisco網站上提供的適當軟體與升級指南、以取得Cisco交換器升級與降級程序的完整文件、網址為 "Cisco Nexus 3000系列交換器"。
- 您必須下載適用的RCT。

更換Cisco Nexus 3232C儲存交換器的步驟

您可以執行特定的工作順序、不中斷地更換故障的Cisco Nexus 3232C儲存交換器。

現有的網路組態必須具有下列特性：

- 「Cisco乙太網路交換器」頁面提供您交換器上最新的RCF和NX-OS版本。
- 兩台交換器都必須具備管理連線能力。

> 請確定已完成所有疑難排解步驟、以確認您的交換器需要更換。

更換的Cisco Nexus 3232C交換器必須具備下列特性：

- 管理網路連線功能必須正常。
- 更換交換器的主控台存取必須已就緒。
- 必須將適當的RCF和NX-OS作業系統映像載入交換器。
- 交換器的初始自訂必須完成。

程序摘要：

- 確認要更換的交換器為**S2**（步驟 **1.-5.**）
- 拔下交換器**S2**的纜線 （步驟**6**）
- 將纜線重新連接至交換器**NS2**（步驟 **7.**）
- 驗證交換器**NS2**上的所有裝置組態（步驟 **8.-10.**）
- 此程序會以新的3232C交換器NS2取代第二個Nexus 3232C儲存交換器S2。
- 這兩個節點分別是node1和node2。

步驟

1. 如果AutoSupport 此叢集啟用了Section,則會叫用AutoSupport 下列訊息來抑制自動建立案例：「System nodeeseInvoke AutoSupport -Node *-type all - Message MAn=xh」

   _x_是維護時段的持續時間（以小時為單位）。

   > 此資訊可通知技術支援人員執行此維護工作、以便在維護期間抑制自動建立案例。AutoSupport

2. 檢查儲存節點連接埠的健全狀況、確定已連線至儲存交換器S1：「torage port show -port-type ENET」

```
storage::*> storage port show -port-type ENET
                                        Speed                      VLAN
Node                Port Type  Mode    (Gb/s) State    Status      ID
------------------ ---- ----- ------- ------ -------- --------- ----
node1
                    e3a  ENET  storage    100 enabled  online      30
                    e3b  ENET  storage      0 enabled  offline     30
                    e7a  ENET  storage      0 enabled  offline     30
                    e7b  ENET  storage      0 enabled  offline     30
node2
                    e3a  ENET  storage    100 enabled  online      30
                    e3b  ENET  storage      0 enabled  offline     30
                    e7a  ENET  storage      0 enabled  offline     30
                    e7b  ENET  storage      0 enabled  offline     30
```

3. 驗證儲存交換器S1是否可用：「network device-dDiscovery show」

```
storage::*> network device-discovery show
Node/       Local  Discovered
Protocol    Port   Device (LLDP: ChassisID)  Interface         Platform
----------- ------ ------------------------- -----------------
----------------
node1/cdp
            e3a    S1                        Ethernet1/1       NX3232C
            e4a    node2                     e4a               AFF-A700
            e4e    node2                     e4e               AFF-A700
node1/lldp
            e3a    S1                        Ethernet1/1       -
            e4a    node2                     e4a               -
            e4e    node2                     e4e               -
node2/cdp
            e3a    S1                        Ethernet1/2       NX3232C
            e4a    node1                     e4a               AFF-A700
            e4e    node1                     e4e               AFF-A700
node2/lldp
            e3a    S1                        Ethernet1/2       -
            e4a    node1                     e4a               -
            e4e    node1                     e4e               -
```

4. 在工作交換器上執行「show LLDP鄰近裝置」命令、確認您可以同時看到節點和所有磁碟櫃：「How LLDP鄰近裝置」

```
S1# show lldp neighbors
Capability codes:
  (R) Router, (B) Bridge, (T) Telephone, (C) DOCSIS Cable Device
  (W) WLAN Access Point, (P) Repeater, (S) Station, (O) Other
Device ID               Local Intf      Hold-time  Capability  Port ID
node1                   Eth1/1          121        S           e3a
node2                   Eth1/2          121        S           e3a
SHFGD2008000011         Eth1/5          121        S           e0a
SHFGD2008000011         Eth1/6          120        S           e0a
SHFGD2008000022         Eth1/7          120        S           e0a
SHFGD2008000022         Eth1/8          120        S           e0a
```

5. [[五]驗證儲存系統中的機櫃連接埠：「torage shelage port show -Fields remie-device, remie-port]（磁碟櫃連接埠顯示-欄位遠端裝置、遠端連接埠）」

```
storage::*> storage shelf port show -fields remote-device,remote-port

shelf  id  remote-port  remote-device
-----  --  -----------  -------------
3.20   0   Ethernet1/5  S1
3.20   1   -            -
3.20   2   Ethernet1/6  S1
3.20   3   -            -
3.30   0   Ethernet1/7  S1
3.20   1   -            -
3.30   2   Ethernet1/8  S1
3.20   3   -            -
```

6. [[六]移除連接至儲存交換器S2的所有纜線。
7. [[shara]將所有纜線重新連接至更換的交換器NS2。
8. [[8]]重新檢查儲存節點連接埠的健全狀況狀態：「torage port show -port-type ENET」

```
storage::*> storage port show -port-type ENET
                                        Speed                        VLAN
Node                Port Type  Mode    (Gb/s) State    Status        ID
------------------ ---- ----- ------- ------ -------- ------------ ---
node1
                    e3a  ENET  storage    100 enabled  online        30
                    e3b  ENET  storage      0 enabled  offline       30
                    e7a  ENET  storage      0 enabled  offline       30
                    e7b  ENET  storage    100 enabled  online        30
node2
                    e3a  ENET  storage    100 enabled  online        30
                    e3b  ENET  storage      0 enabled  offline       30
                    e7a  ENET  storage      0 enabled  offline       30
                    e7b  ENET  storage    100 enabled  online        30
```

9. 確認兩台交換器都可用：「網路裝置探索秀」

```
storage::*> network device-discovery show
Node/       Local  Discovered
Protocol    Port   Device (LLDP: ChassisID)  Interface         Platform
----------- ------ ------------------------- ----------------  --------
node1/cdp
            e3a    S1                        Ethernet1/1       NX3232C
            e4a    node2                     e4a               AFF-A700
            e4e    node2                     e4e               AFF-A700
            e7b    NS2                       Ethernet1/1       NX3232C
node1/lldp
            e3a    S1                        Ethernet1/1       -
            e4a    node2                     e4a               -
            e4e    node2                     e4e               -
            e7b    NS2                       Ethernet1/1       -
node2/cdp
            e3a    S1                        Ethernet1/2       NX3232C
            e4a    node1                     e4a               AFF-A700
            e4e    node1                     e4e               AFF-A700
            e7b    NS2                       Ethernet1/2       NX3232C
node2/lldp
            e3a    S1                        Ethernet1/2       -
            e4a    node1                     e4a               -
            e4e    node1                     e4e               -
            e7b    NS2                       Ethernet1/2       -
```

10. [[TEON]驗證儲存系統中的機櫃連接埠：「torage shelage port show -Fields remie-device, remie-port]（儲存櫃連接埠顯示欄位遠端裝置、遠端連接埠）」

```
storage::*> storage shelf port show -fields remote-device,remote-port
shelf id remote-port remote-device
----- -- ----------- -------------
3.20  0  Ethernet1/5 S1
3.20  1  Ethernet1/5 NS2
3.20  2  Ethernet1/6 S1
3.20  3  Ethernet1/6 NS2
3.30  0  Ethernet1/7 S1
3.20  1  Ethernet1/7 NS2
3.30  2  Ethernet1/8 S1
3.20  3  Ethernet1/8 NS2
```

11. 如果您禁止自動建立個案、請叫用AutoSupport 下列訊息重新啟用此功能：「System Node AutoSupport 現象叫用節點*-type all -most MAn=end」

Copyright Information

Copyright © 2022 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.