# Install hardware

## Cluster and storage switches

NetApp
March 22, 2024

This PDF was generated from https://docs.netapp.com/us-en/ontap-systems-switches/switch-cisco-92300/setup-worksheet-92300yc.html on March 22, 2024. Always check docs.netapp.com for the latest.

# Table of Contents

Install hardware . . . . . 1
Complete Cisco Nexus 92300YC cabling worksheet . . . . . 1
Configure the Cisco Nexus 92300YC switch . . . . . 7

# Install hardware

## Complete Cisco Nexus 92300YC cabling worksheet

If you want to document the supported platforms, download a PDF of this page and complete the cabling worksheet.

The sample cabling worksheet provides examples of recommended port assignments from the switches to the controllers. The blank worksheet provides a template that you can use in setting up your cluster.

### Sample cabling worksheet

The sample port definition on each pair of switches is as follows:

| **Cluster switch A** | | **Cluster switch B** | |
|---|---|---|---|
| Switch port | Node and port usage | Switch port | Node and port usage |
| 1 | 10/25 GbE node | 1 | 10/25 GbE node |
| 2 | 10/25 GbE node | 2 | 10/25 GbE node |
| 3 | 10/25 GbE node | 3 | 10/25 GbE node |
| 4 | 10/25 GbE node | 4 | 10/25 GbE node |
| 5 | 10/25 GbE node | 5 | 10/25 GbE node |
| 6 | 10/25 GbE node | 6 | 10/25 GbE node |
| 7 | 10/25 GbE node | 7 | 10/25 GbE node |
| 8 | 10/25 GbE node | 8 | 10/25 GbE node |
| 9 | 10/25 GbE node | 9 | 10/25 GbE node |
| 10 | 10/25 GbE node | 10 | 10/25 GbE node |
| 11 | 10/25 GbE node | 11 | 10/25 GbE node |
| 12 | 10/25 GbE node | 12 | 10/25 GbE node |
| 13 | 10/25 GbE node | 13 | 10/25 GbE node |
| 14 | 10/25 GbE node | 14 | 10/25 GbE node |

| Cluster switch A | | Cluster switch B | |
|---|---|---|---|
| 15 | 10/25 GbE node | 15 | 10/25 GbE node |
| 16 | 10/25 GbE node | 16 | 10/25 GbE node |
| 17 | 10/25 GbE node | 17 | 10/25 GbE node |
| 18 | 10/25 GbE node | 18 | 10/25 GbE node |
| 19 | 10/25 GbE node | 19 | 10/25 GbE node |
| 20 | 10/25 GbE node | 20 | 10/25 GbE node |
| 21 | 10/25 GbE node | 21 | 10/25 GbE node |
| 22 | 10/25 GbE node | 22 | 10/25 GbE node |
| 23 | 10/25 GbE node | 23 | 10/25 GbE node |
| 24 | 10/25 GbE node | 24 | 10/25 GbE node |
| 25 | 10/25 GbE node | 25 | 10/25 GbE node |
| 26 | 10/25 GbE node | 26 | 10/25 GbE node |
| 27 | 10/25 GbE node | 27 | 10/25 GbE node |
| 28 | 10/25 GbE node | 28 | 10/25 GbE node |
| 29 | 10/25 GbE node | 29 | 10/25 GbE node |
| 30 | 10/25 GbE node | 30 | 10/25 GbE node |
| 31 | 10/25 GbE node | 31 | 10/25 GbE node |
| 32 | 10/25 GbE node | 32 | 10/25 GbE node |
| 33 | 10/25 GbE node | 33 | 10/25 GbE node |
| 34 | 10/25 GbE node | 34 | 10/25 GbE node |
| 35 | 10/25 GbE node | 35 | 10/25 GbE node |
| 36 | 10/25 GbE node | 36 | 10/25 GbE node |

| Cluster switch A | | Cluster switch B | |
|---|---|---|---|
| 37 | 10/25 GbE node | 37 | 10/25 GbE node |
| 38 | 10/25 GbE node | 38 | 10/25 GbE node |
| 39 | 10/25 GbE node | 39 | 10/25 GbE node |
| 40 | 10/25 GbE node | 40 | 10/25 GbE node |
| 41 | 10/25 GbE node | 41 | 10/25 GbE node |
| 42 | 10/25 GbE node | 42 | 10/25 GbE node |
| 43 | 10/25 GbE node | 43 | 10/25 GbE node |
| 44 | 10/25 GbE node | 44 | 10/25 GbE node |
| 45 | 10/25 GbE node | 45 | 10/25 GbE node |
| 46 | 10/25 GbE node | 46 | 10/25 GbE node |
| 47 | 10/25 GbE node | 47 | 10/25 GbE node |
| 48 | 10/25 GbE node | 48 | 10/25 GbE node |
| 49 | 40/100 GbE node | 49 | 40/100 GbE node |
| 50 | 40/100 GbE node | 50 | 40/100 GbE node |
| 51 | 40/100 GbE node | 51 | 40/100 GbE node |
| 52 | 40/100 GbE node | 52 | 40/100 GbE node |
| 53 | 40/100 GbE node | 53 | 40/100 GbE node |
| 54 | 40/100 GbE node | 54 | 40/100 GbE node |
| 55 | 40/100 GbE node | 55 | 40/100 GbE node |
| 56 | 40/100 GbE node | 56 | 40/100 GbE node |
| 57 | 40/100 GbE node | 57 | 40/100 GbE node |
| 58 | 40/100 GbE node | 58 | 40/100 GbE node |

| Cluster switch A | | Cluster switch B | |
|---|---|---|---|
| 59 | 40/100 GbE node | 59 | 40/100 GbE node |
| 60 | 40/100 GbE node | 60 | 40/100 GbE node |
| 61 | 40/100 GbE node | 61 | 40/100 GbE node |
| 62 | 40/100 GbE node | 62 | 40/100 GbE node |
| 63 | 40/100 GbE node | 63 | 40/100 GbE node |
| 64 | 40/100 GbE node | 64 | 40/100 GbE node |
| 65 | 100 GbE ISL to switch B port 65 | 65 | 100 GbE ISL to switch A port 65 |
| 66 | 100 GbE ISL to switch B port 66 | 66 | 100 GbE ISL to switch A port 65 |

## Blank cabling worksheet

You can use the blank cabling worksheet to document the platforms that are supported as nodes in a cluster. The *Supported Cluster Connections* section of the Hardware Universe defines the cluster ports used by the platform.

| Cluster switch A | | Cluster switch B | |
|---|---|---|---|
| Switch port | Node/port usage | Switch port | Node/port usage |
| 1 | | 1 | |
| 2 | | 2 | |
| 3 | | 3 | |
| 4 | | 4 | |
| 5 | | 5 | |
| 6 | | 6 | |
| 7 | | 7 | |
| 8 | | 8 | |
| 9 | | 9 | |

| Cluster switch A | | Cluster switch B | |
|---|---|---|---|
| 10 | | 10 | |
| 11 | | 11 | |
| 12 | | 12 | |
| 13 | | 13 | |
| 14 | | 14 | |
| 15 | | 15 | |
| 16 | | 16 | |
| 17 | | 17 | |
| 18 | | 18 | |
| 19 | | 19 | |
| 20 | | 20 | |
| 21 | | 21 | |
| 22 | | 22 | |
| 23 | | 23 | |
| 24 | | 24 | |
| 25 | | 25 | |
| 26 | | 26 | |
| 27 | | 27 | |
| 28 | | 28 | |
| 29 | | 29 | |
| 30 | | 30 | |
| 31 | | 31 | |

| Cluster switch A | | Cluster switch B | |
|---|---|---|---|
| 32 | | 32 | |
| 33 | | 33 | |
| 34 | | 34 | |
| 35 | | 35 | |
| 36 | | 36 | |
| 37 | | 37 | |
| 38 | | 38 | |
| 39 | | 39 | |
| 40 | | 40 | |
| 41 | | 41 | |
| 42 | | 42 | |
| 43 | | 43 | |
| 44 | | 44 | |
| 45 | | 45 | |
| 46 | | 46 | |
| 47 | | 47 | |
| 48 | | 48 | |
| 49 | | 49 | |
| 50 | | 50 | |
| 51 | | 51 | |
| 52 | | 52 | |
| 53 | | 53 | |

| Cluster switch A | | Cluster switch B | |
|---|---|---|---|
| 54 | | 54 | |
| 55 | | 55 | |
| 56 | | 56 | |
| 57 | | 57 | |
| 58 | | 58 | |
| 59 | | 59 | |
| 60 | | 60 | |
| 61 | | 61 | |
| 62 | | 62 | |
| 63 | | 63 | |
| 64 | | 64 | |
| 65 | ISL to switch B port 65 | 65 | ISL to switch A port 65 |
| 66 | ISL to switch B port 66 | 66 | ISL to switch A port 66 |

# Configure the Cisco Nexus 92300YC switch

Follow this procedure to set up and configure the Cisco Nexus 92300YC switch.

**Steps**

1. Connect the serial port to a host or serial port.
2. Connect the management port (on the non-port side of the switch) to the same network where your SFTP server is located.
3. At the console, set the host side serial settings:
    - 9600 baud
    - 8 data bits
    - 1 stop bit
    - parity: none
    - flow control: none
4. When booting for the first time or rebooting after erasing the running configuration, the Nexus 92300YC switch loops in a boot cycle. Interrupt this cycle by typing **yes** to abort Power on Auto Provisioning.

The System Admin Account setup is displayed.

**Show example**

```
$ VDC-1 %$ %POAP-2-POAP_INFO:   - Abort Power On Auto Provisioning
[yes - continue with normal setup, skip - bypass password and basic
configuration, no - continue with Power On Auto Provisioning]
(yes/skip/no)[no]: y
Disabling POAP.......Disabling POAP
2019 Apr 10 00:36:17 switch %$ VDC-1 %$ poap: Rolling back, please
wait... (This may take 5-15 minutes)

          ---- System Admin Account Setup ----

Do you want to enforce secure password standard (yes/no) [y]:
```

5. Type **y** to enforce secure password standard:

```
Do you want to enforce secure password standard (yes/no) [y]: y
```

6. Enter and confirm the password for user admin:

```
Enter the password for "admin":
Confirm the password for "admin":
```

7. Type **yes** to enter the Basic System Configuration dialog.

**Show example**

```
This setup utility will guide you through the basic configuration of
the system. Setup configures only enough connectivity for management
of the system.

Please register Cisco Nexus9000 Family devices promptly with your
supplier. Failure to register may affect response times for initial
service calls. Nexus9000 devices must be registered to receive
entitled support services.

Press Enter at anytime to skip a dialog. Use ctrl-c at anytime
to skip the remaining dialogs.

Would you like to enter the basic configuration dialog (yes/no):
```

8. Create another login account:

```
Create another login account (yes/no) [n]:
```

9. Configure read-only and read-write SNMP community strings:

```
Configure read-only SNMP community string (yes/no) [n]:

Configure read-write SNMP community string (yes/no) [n]:
```

10. Configure the cluster switch name:

```
Enter the switch name : cs2
```

11. Configure the out-of-band management interface:

```
Continue with Out-of-band (mgmt0) management configuration? (yes/no)
[y]: y

Mgmt0 IPv4 address : 172.22.133.216

Mgmt0 IPv4 netmask : 255.255.224.0

Configure the default gateway? (yes/no) [y]: y

IPv4 address of the default gateway : 172.22.128.1
```

12. Configure advanced IP options:

```
Configure advanced IP options? (yes/no) [n]: n
```

13. Configure Telnet services:

```
Enable the telnet service? (yes/no) [n]: n
```

14. Configure SSH services and SSH keys:

```
Enable the ssh service? (yes/no) [y]: y

       Type of ssh key you would like to generate (dsa/rsa) [rsa]: rsa

       Number of rsa key bits <1024-2048> [1024]: 2048
```

15. Configure other settings:

```
Configure the ntp server? (yes/no) [n]: n

  Configure default interface layer (L3/L2) [L2]: L2

  Configure default switchport interface state (shut/noshut) [noshut]:
noshut

  Configure CoPP system profile (strict/moderate/lenient/dense)
[strict]: strict
```

16. Confirm switch information and save the configuration:

```
Would you like to edit the configuration? (yes/no) [n]: n

Use this configuration and save it? (yes/no) [y]: y

[] 100%
Copy complete, now saving to disk (please wait)...
Copy complete.
```

**What's next?**

Prepare to install NX-OS software and RCF.

**Copyright information**

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

**Trademark information**

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.