可选—移动内部存储或转换为驱动器架

AFF and FAS Controller Upgrade

NetApp
June 07, 2022

This PDF was generated from https://docs.netapp.com/zh-cn/ontap-systems-upgrade/upgrade/upgrade-optional-move-internal-storage.html on June 07, 2022. Always check docs.netapp.com for the latest.

目录

可选—移动内部存储或转换为驱动器架 1
可选：移动内部存储或将系统转换为驱动器架 1
从原始节点移动内部驱动器 1
将原始节点转换为驱动器架 2

可选—移动内部存储或转换为驱动器架

可选：移动内部存储或将系统转换为驱动器架

如果原始节点是支持的型号之一，则可以在通过移动存储进行升级期间将其内部 SATA 驱动器或 SSD 移动到连接到新节点的驱动器架。您还可以将系统转换为驱动器架并将其连接到新节点。

您只能在同一集群中移动驱动器或驱动器架。

选项

- "从原始节点移动内部驱动器"

  如果原始节点是支持的型号之一，则在通过移动存储进行升级的过程中，您可以将节点的内部 SATA 驱动器或 SSD 移动到连接到同一集群中新节点的驱动器架。您不能将 SAS 驱动器传输到连接到新节点的驱动器架。

- "将原始节点转换为驱动器架"

  如果原始节点是支持的型号之一，则在通过移动存储进行升级的过程中，您可以将节点转换为驱动器架，然后将其连接到同一集群中的新节点。

从原始节点移动内部驱动器

如果原始节点是支持的型号之一，则在通过移动存储进行升级的过程中，您可以将节点的内部 SATA 驱动器或 SSD 移动到连接到同一集群中新节点的驱动器架。您不能将 SAS 驱动器传输到连接到新节点的驱动器架。

开始之前

- 您必须已查看 "升级控制器硬件的注意事项" 关于移动内部驱动器。

  如果您需要特定于您的配置的指导，请联系技术支持。

- 原始节点中的 SATA 或 SSD 驱动器托架必须与新驱动器架兼容。
- 新节点必须已连接兼容的驱动器架。
- 驱动器架必须具有足够的可用托架，以容纳原始节点上的 SATA 或 SSD 驱动器托架。

步骤

1. 从系统正面轻轻卸下挡板。
2. 按驱动器托架左侧的释放按钮。

   托架上的凸轮把手部分弹开，托架从中板上松开。

3. 将凸轮把手拉至完全打开位置，以使托架从中板中取出，然后将托架轻轻滑出驱动器架。

> 在拆卸，安装或搬运驱动器时，请始终用双手。但是，请勿将手放在托架下侧暴露的驱动器板上。

4. 在凸轮把手处于打开位置的情况下，将托架插入新驱动器架的插槽中，用力推动，直到托架停止。

   > 插入托架时，请用双手。

5. 关闭凸轮把手，使托架完全固定在中板中，并且把手卡入到位。

   您必须缓慢关闭手柄，使其与托架的正面正确对齐。

6. 重复 第 2 步 到 第 5 步 要移至新系统的所有驱动器。

将原始节点转换为驱动器架

如果原始节点是支持的型号之一，则在通过移动存储进行升级的过程中，您可以将节点转换为驱动器架，然后将其连接到同一集群中的新节点。

您必须已查看 "升级控制器硬件的注意事项" 关于将节点转换为驱动器架。如果您需要特定于您的配置的指导，请联系技术支持。

步骤

1. 将要转换的节点中的控制器模块更换为相应的 IOM 模块。

   "NetApp Hardware Universe"

2. 设置驱动器架 ID 。

   每个驱动器架（包括机箱）都需要一个唯一 ID 。

3. 根据需要重置其他驱动器架 ID 。
4. 关闭连接到新节点的所有驱动器架的电源，然后关闭新节点的电源。
5. 将转换后的驱动器架连接到新系统上的 SAS 端口，如果使用带外 ACP 布线，则连接到新节点上的 ACP 端口。
6. 打开转换后的驱动器架以及连接到新节点的任何其他驱动器架的电源。
7. 打开新节点的电源，然后按 Ctrl-C 访问启动环境提示符，以中断每个节点上的启动过程。

版权信息

版权所有©2022 NetApp、Inc.。保留所有权利。Printed in the U.S.版权所涵盖的本文档的任何部分不得以任何形式或任何手段复制、包括影印、录制、 磁带或存储在电子检索系统中—未经版权所有者事先书面许可。

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

本软件由NetApp按"原样"提供、不含任何明示或默示担保、包括但不限于适销性和特定用途适用性的默示担保、特此声明不承担任何责任。IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice.NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp.The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S.patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

商标信息

NetApp、NetApp标识和中列出的标记 http://www.netapp.com/TM 是NetApp、Inc.的商标。其他公司和产品名称可能是其各自所有者的商标。