階段6.使用AFF EsceeA900 控制器模組和NVRAM模組來開機節點2

AFF and FAS Controller Upgrade

NetApp
May 03, 2022

This PDF was generated from https://docs.netapp.com/zh-tw/ontap-systems-upgrade/upgrade-arl-auto-affa900/boot_node2_with_a900_controller_and_nvs.html on May 03, 2022. Always check docs.netapp.com for the latest.

目錄

階段6.使用AFF EsceeA900控制器模組和NVRAM模組來開機節點2 1
使用AFF EsceeA900控制器模組和NVRAM模組來開機節點2 1
驗證node2安裝 4
還原節點2上的金鑰管理程式組態 9
將非根Aggregate和NAS資料lifs移回節點2 9

階段6.使用AFF EsceeA900控制器模組和NVRAM模組來開機節點2

使用AFF EsceeA900控制器模組和NVRAM模組來開機節點2

節點2搭配AFF EsceA900控制器模組和NVRAM模組、現在已準備好升級。透過交換控制器模組和NVRAM模組、將AFF 某個處理器從某個部分升級至AFF 某個部分、只需移動主控台和管理連線即可。本節提供使用AFF E4A900控制器模組和NVRAM模組來開機節點2所需的步驟。

步驟

1. 如果此組態正在使用NetApp儲存加密（NSE）、則必須將「setenv bootarg.storageEncryption.support'命令設定為「true」、並將「kmip.init.maxwait`變數」設定為「Off」、以避免在節點2組態載入後發生開機迴圈：

   「etenv bootarg.storageencryption。支援true」

   「kmip.init.maxwait關」

2. 將節點開機至「boot_menu」：

   Boot_ONTAP功能表

3. 節點會在開機功能表停止。輸入「22/7」、然後選取隱藏選項「boot_after控制器置換」。若要將AFF EsceA700 node1磁碟重新指派至AFF EsceA900 node1、請在提示字元下輸入節點2的實際節點名稱。請參考下列範例：

```
LOADER-A> boot_ontap menu
.
.
<output truncated>
.
All rights reserved.
******************************
*                            *
* Press Ctrl-C for Boot Menu. *
*                            *
******************************
.
<output truncated>
.
Please choose one of the following:

(1)  Normal Boot.
(2)  Boot without /etc/rc.
(3)  Change password.
```

```
(4)  Clean configuration and initialize all disks.
(5)  Maintenance mode boot.
(6)  Update flash from backup config.
(7)  Install new software first.
(8)  Reboot node.
(9)  Configure Advanced Drive Partitioning.
(10) Set Onboard Key Manager recovery secrets.
(11) Configure node for external key management.
Selection (1-11)? 22/7

(22/7)                          Print this secret List
(25/6)                          Force boot with multiple filesystem
disks missing.
(25/7)                          Boot w/ disk labels forced to clean.
(29/7)                          Bypass media errors.
(44/4a)                         Zero disks if needed and create new
flexible root volume.
(44/7)                          Assign all disks, Initialize all disks
as SPARE, write DDR labels
.
.
<output truncated>
.
.
(wipeconfig)                        Clean all configuration on boot
device
(boot_after_controller_replacement) Boot after controller upgrade
(boot_after_mcc_transition)         Boot after MCC transition
(9a)                                Unpartition all disks and remove
their ownership information.
(9b)                                Clean configuration and initialize
node with partitioned disks.
(9c)                                Clean configuration and initialize
node with whole disks.
(9d)                                Reboot the node.
(9e)                                Return to main boot menu.



The boot device has changed. System configuration information could be
lost. Use option (6) to restore the system configuration, or option (4)
to initialize all disks and setup a new system.
Normal Boot is prohibited.

Please choose one of the following:
```

```
(1)  Normal Boot.
(2)  Boot without /etc/rc.
(3)  Change password.
(4)  Clean configuration and initialize all disks.
(5)  Maintenance mode boot.
(6)  Update flash from backup config.
(7)  Install new software first.
(8)  Reboot node.
(9)  Configure Advanced Drive Partitioning.
(10) Set Onboard Key Manager recovery secrets.
(11) Configure node for external key management.
Selection (1-11)? boot_after_controller_replacement

This will replace all flash-based configuration with the last backup to
disks. Are you sure you want to continue?: yes

.
.
<output truncated>
.
.
Controller Replacement: Provide name of the node you would like to
replace:<nodename of the node being replaced>
Changing sysid of node node1 disks.
Fetched sanown old_owner_sysid = 536940063 and calculated old sys id =
536940063
Partner sysid = 4294967295, owner sysid = 536940063
.
.
<output truncated>
.
.
varfs_backup_restore: restore using /mroot/etc/varfs.tgz
varfs_backup_restore: attempting to restore /var/kmip to the boot device
varfs_backup_restore: failed to restore /var/kmip to the boot device
varfs_backup_restore: attempting to restore env file to the boot device
varfs_backup_restore: successfully restored env file to the boot device
wrote key file "/tmp/rndc.key"
varfs_backup_restore: timeout waiting for login
varfs_backup_restore: Rebooting to load the new varfs
Terminated
<node reboots>

System rebooting...

.
```

```
.
Restoring env file from boot media...
copy_env_file:scenario = head upgrade
Successfully restored env file from boot media...
Rebooting to load the restored env file...
.
System rebooting...
.
.
.
<output truncated>
.
.
.
.
WARNING: System ID mismatch. This usually occurs when replacing a boot
device or NVRAM cards!
Override system ID? {y|n} y
.
.
.
.
Login:
```

> 在前述主控台輸出範例中、ONTAP 如果系統使用進階磁碟分割（ADP）磁碟、則會提示您輸入合作夥伴節點名稱。
>
> 上例所示的系統ID為範例ID。您要升級之節點的實際系統ID會有所不同。
>
> 在提示輸入節點名稱與登入提示之間、節點會重新開機數次、以還原環境變數、更新系統卡上的韌體、以及進行其他ONTAP 的更新。

驗證node2安裝

您必須使用AFF EsceA900控制器模組和NVRAM模組來驗證node2安裝。由於實體連接埠沒有變更、因此您不需要將實體連接埠從AFF EsceA700 node2對應到AFF EsceA900 node2。

使用AFF E4A900控制器模組開機節點1之後、您必須確認其安裝正確。您必須等待節點2加入仲裁、然後繼續執行控制器更換作業。

在此過程中、節點2加入仲裁時、操作會暫停。

步驟

1. 驗證node2是否已加入仲裁：

「cluster show -node2 -Fields health」

保健領域的產出應該是真的。

2. 驗證node2是否與node1屬於同一個叢集、而且它是否正常：

   「叢集展示」

3. 切換至進階權限模式：

   《進階設定》

4. 檢查控制器更換作業的狀態、並確認它處於暫停狀態、且狀態與節點2停止之前的狀態相同、以執行安裝新控制器和移動纜線的實體工作：

   「System Controller replace show」（系統控制器更換顯示）

   「System Controller replace show-details」（系統控制器取代顯示詳細資料

5. 恢復控制器更換作業：

   「系統控制器更換恢復」

6. 控制器更換作業會暫停以進行介入、並顯示下列訊息：

```
Cluster::*> system controller replace show
Node          Status                      Error-Action
------------  ------------------------
-----------------------------------
Node2         Paused-for-intervention     Follow the instructions given
in
                                          Step Details
Node1         None

Step Details:
---------------------------------------------
To complete the Network Reachability task, the ONTAP network
configuration must be manually adjusted to match the new physical
network configuration of the hardware. This includes:


1. Re-create the interface group, if needed, before restoring VLANs. For
detailed commands and instructions, refer to the "Re-creating VLANs,
ifgrps, and broadcast domains" section of the upgrade controller
hardware guide for the ONTAP version running on the new controllers.
2. Run the command "cluster controller-replacement network displaced-
vlans show" to check if any VLAN is displaced.
3. If any VLAN is displaced, run the command "cluster controller-
replacement network displaced-vlans restore" to restore the VLAN on the
desired port.
2 entries were displayed.
```

在此程序中、_重新建立VLAN、ifgrps和廣播網域_一節已重新命名為_在節點2上還原網路組態。

7. 在控制器更換處於暫停狀態時、繼續執行 [Restore network configuration on node2]。

還原節點2上的網路組態

確認節點2處於仲裁狀態並可與節點1通訊之後、請確認節點1的VLAN、介面群組和廣播網域是否顯示在節點2上。此外、請確認所有節點2網路連接埠都已設定在正確的廣播網域中。

如需建立及重新建立VLAN、介面群組及廣播網域的詳細資訊、請參閱 "參考資料" 連結至_Network Management內容。

步驟

1. 列出已升級節點2上的所有實體連接埠：

   「網路連接埠show -node2」

   此時會顯示節點上的所有實體網路連接埠、VLAN連接埠和介面群組連接埠。從這個輸出中、您可以看

到ONTAP 任何實體連接埠、這些連接埠已被動作區移至「叢集」廣播網域。您可以使用此輸出來協助決定哪些連接埠應做為介面群組成員連接埠、VLAN基礎連接埠或獨立實體連接埠來裝載lifs。

2. 列出叢集上的廣播網域：

   《廣播網域節目》

3. 列出節點2上所有連接埠的網路連接埠可連線性：

   「網路連接埠可連線性show -node2」

   您應該會看到類似下列範例的輸出。連接埠和廣播名稱各不相同。

```
Cluster::*> network port reachability show -node local
Node      Port     Expected Reachability                Reachability
Status
--------- -------- -----------------------------------
---------------------
Node2
          e0M      Default:Mgmt                         no-reachability
          e10a     Default:Default-3                    ok
          e10b     Default:Default-4                    ok
          e11a     Cluster:Cluster                      no-reachability
          e11b     Cluster:Cluster                      no-reachability
          e11c     -                                    no-reachability
          e11d     -                                    no-reachability
          e2a      Default:Default-1                    ok
          e2b      Default:Default-2                    ok
          e9a      Default:Default                      no-reachability
          e9b      Default:Default                      no-reachability
          e9c      Default:Default                      no-reachability
          e9d      Default:Default                      no-reachability
13 entries were displayed.
```

   在前面的範例中、節點2已在更換控制器之後開機並加入仲裁。它有數個連接埠無法連線、且正在等待連線能力掃描。

4. 使用下列命令、以「ok」以外的連線狀態、修復節點2上每個連接埠的連線能力、順序如下：

   「網路連接埠可連線性修復-節點<node_name>-port <port_name>」

   a. 實體連接埠
   b. VLAN連接埠

   您應該會看到如下範例所示的輸出：

```
Cluster ::> reachability repair -node node2 -port e9d
```

```
Warning: Repairing port "node2:e9d" may cause it to move into a
different broadcast domain, which can cause LIFs to be re-homed away
from the port. Are you sure you want to continue? {y|n}:
```

如前述範例所示、若連接埠的連線狀態可能與目前所在廣播網域的連線狀態不同、則會出現警告訊息。檢視連接埠的連線能力、並視需要回答「y」或「n」。

驗證所有實體連接埠的可連線性是否符合預期：

「網路連接埠連線能力顯示」

執行可連線性修復時ONTAP 、嘗試將連接埠放在正確的廣播網域中。但是、如果無法判斷連接埠的連線能力、而且不屬於任何現有的廣播網域、ONTAP 則無法使用這些連接埠來建立新的廣播網域。

5. 驗證連接埠可連線性：

   「網路連接埠連線能力顯示」

   當所有連接埠均已正確設定並新增至正確的廣播網域時、「network port re連通 性show」命令會針對所有連接的連接埠、將連線狀態報告為「ok」、對於沒有實體連線的連接埠、狀態應顯示為「不可到達性」。如果有任何連接埠報告這兩個以外的狀態、請執行連線能力修復、並依照中的指示、從廣播網域新增或移除連接埠 步驟4.。

6. 確認所有連接埠均已置入廣播網域：

   「網路連接埠展示」

7. 確認廣播網域中的所有連接埠均已設定正確的最大傳輸單元（MTU）：

   「網路連接埠廣播網域節目」

8. 還原LIF主連接埠、指定需要還原的Vserver和LIF主連接埠（如果有）、請使用下列步驟：

   a. 列出任何已移出的生命：

      「顯示介面」

   b. 還原LIF主節點和主連接埠：

      「顯示介面還原主節點節點節點節點節點<node_name>-vserver <vserver_name>-lif-name <LIF_name>」

9. 驗證所有生命段是否都有主連接埠、且是否以管理方式啟動：

   「網路介面顯示欄位主連接埠、狀態管理」

還原節點2上的金鑰管理程式組態

如果您使用NetApp Volume Encryption（NVE）來加密要升級的系統上的磁碟區、加密組態必須同步至新節點。當節點1集合體從節點2到節點1完成ARL時、加密的磁碟區會離線。

執行下列步驟、將加密組態同步至新節點：

步驟

1. 在叢集提示字元中使用下列命令、同步化Onboard Key Manager（OKM）的加密組態：

   「安全金鑰管理程式內建同步」

2. 為OKM輸入整個叢集的通關密碼。

將非根Aggregate和NAS資料lifs移回節點2

在驗證節點2上的網路組態之後、在將Aggregate從節點1重新定位至節點2之前、您必須驗證屬於節點2的NAS資料lifs目前位於節點1上、是否已從節點1重新定位至節點2。您還必須驗證節點2上是否存在SAN lifs。

在升級過程中、遠端LIF會處理SAN LUN的流量。在升級期間、移轉SAN LIF對於叢集或服務健全狀況並不必要。除非需要將SAN LIF對應至新連接埠、否則不會移動SAN LIF。將node2聯機後，必須驗證該生命段是否正常且位於適當的端口上。

步驟

1. 恢復重新定位作業：

   「系統控制器更換恢復」

   系統會執行下列工作：

   - 叢集仲裁檢查
   - 系統ID檢查
   - 映像版本檢查
   - 目標平台檢查
   - 網路連線能力檢查

   此作業會在網路連線能力檢查的這個階段暫停。

2. 恢復重新定位作業：

   「系統控制器更換恢復」

   系統會執行下列檢查：

   - 叢集健全狀況檢查
   - 叢集LIF狀態檢查

執行這些檢查之後、系統會將非根Aggregate和NAS資料lifs重新定位回節點2、節點2現在正在AFF 運行於E4A900控制器上。

資源重新配置完成後、控制器更換作業會暫停。

3. 檢查集合體重新配置和NAS資料LIF移動作業的狀態：

   「System Controller replace show-details」（系統控制器取代顯示詳細資料

   如果控制器更換程序暫停、請檢查並修正錯誤（如果有）、然後發出「推入」以繼續操作。

4. 如有必要、請還原並還原任何已移轉的生命。列出任何已移出的生命生命：

   「叢集控制器更換網路置換介面show」

   如果有任何生命段被移除、請將主節點還原回節點2：

   「叢集控制器更換網路置換介面還原主節點」

5. 繼續作業、以提示系統執行必要的POST檢查：

   「系統控制器更換恢復」

   系統會執行下列POST檢查：

   - 叢集仲裁檢查
   - 叢集健全狀況檢查
   - 集合體重建檢查
   - Aggregate狀態檢查
   - 磁碟狀態檢查
   - 叢集LIF狀態檢查
   - Volume檢查

Copyright Information

Copyright © 2022 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.