Stage 7. Complete the upgrade

AFF and FAS Controller Upgrade

NetApp
July 19, 2022

This PDF was generated from https://docs.netapp.com/us-en/ontap-systems-upgrade/upgrade-arl-auto-affa900/ensure_new_controllers_are_set_up_correctly.html on July 19, 2022. Always check docs.netapp.com for the latest.

Table of Contents

Stage 7. Complete the upgrade . . . 1
Confirm that the new controllers are set up correctly . . . 1
Set up Storage Encryption on the new controller module . . . 4
Set up NetApp Volume Encryption on the new controller module . . . 4
Decommission the old system . . . 6
Resume SnapMirror operations . . . 6

Stage 7. Complete the upgrade

Confirm that the new controllers are set up correctly

To confirm the correct setup, you must verify that the HA pair is enabled. You must also verify that node1 and node2 can access each other's storage and that neither owns data LIFs belonging to other nodes on the cluster. In addition, you must verify that all data aggregates are on their correct home nodes, and that the volumes for both nodes are online. If one of the new nodes has a unified target adapter, you must restore any port configurations and you might need to change the use of the adapter.

Steps

1. After the post-checks of node2, the storage failover and cluster HA pair for the node2 cluster are enabled. When the operation is done, both nodes show as completed and the system performs some cleanup operations.
2. Verify that storage failover is enabled:

   ```
   storage failover show
   ```

   The following example shows the output of the command when storage failover is enabled:

   ```
   cluster::> storage failover show
                                   Takeover
   Node             Partner            Possible          State Description
   -------------  --------------   --------------  ------------------
   node1            node2            true             Connected to node2
   node2            node1            true             Connected to node1
   ```

3. Verify that node1 and node2 belong to the same cluster by using the following command and examining the output:

   ```
   cluster show
   ```

4. Verify that node1 and node2 can access each other's storage by using the following command and examining the output:

   ```
   storage failover show -fields local-missing-disks,partner-missing-disks
   ```

5. Verify that neither node1 nor node2 owns data LIFs home-owned by other nodes in the cluster by using the following command and examining the output:

   ```
   network interface show
   ```

   If neither node1 or node2 owns data LIFs home-owned by other nodes in the cluster, revert the data LIFs to their home owner:

   ```
   network interface revert
   ```

6. Verify that the aggregates are owned by their respective home nodes.

   `storage aggregate show -owner-name node1`

   `storage aggregate show -owner-name node2`

7. Determine whether any volumes are offline:

   `volume show -node node1 -state offline`

   `volume show -node node2 -state offline`

8. If any volumes are offline, compare them with the list of offline volumes that you captured in the section Prepare the nodes for upgrade, and bring online any of the offline volumes, as required, by using the following command, once for each volume:

   `volume online -vserver vserver_name -volume volume_name`

9. Install new licenses for the new nodes by using the following command for each node:

   `system license add -license-code license_code,license_code,license_code…`

   The license-code parameter accepts a list of 28 upper-case alphabetic character keys. You can add one license at a time, or you can add multiple licenses at once, separating each license key by a comma.

10. Remove all of the old licenses from the original nodes by using one of the following commands:

    `system license clean-up -unused -expired`

    `system license delete -serial-number node_serial_number -package licensable_package`

    - Delete all expired licenses:

      `system license clean-up -expired`

    - Delete all unused licenses:

      `system license clean-up -unused`

    - Delete a specific license from a cluster by using the following commands on the nodes:

      ```
      system license delete -serial-number node1_serial_number -package *
      system license delete -serial-number node2_serial_number -package *
      ```

    The following output is displayed:

    ```
    Warning: The following licenses will be removed:
    <list of each installed package>
    Do you want to continue? {y|n}: y
    ```

Enter `y` to remove all of the packages.

11. Verify that the licenses are correctly installed by using the following command and examining its output:

    ```
    system license show
    ```

    You can compare the output with the output that you captured in the Prepare the nodes for upgrade section.

12. If NetApp Storage Encryption (NSE) was in use on the configuration and you set the `setenv bootarg.storageencryption.support` command to `true` with the `<kmip.init.maxwait>` variable `off` (in *Boot node2 with the AFF A900 or the FAS9500 controller and NVRAM modules*, Step 1), you must reset the variable:

    ```
    set diag; systemshell -node node_name -command sudo kenv -u -p
    kmip.init.maxwait
    ```

13. Configure the SPs by using the following command on both nodes:

    ```
    system service-processor network modify -node node_name
    ```

    Refer to References to link to the *System Administration Reference* for information about the SPs and the *ONTAP 9 Commands: Manual Page Reference* for detailed information about the system `service-processor network modify` command.

14. Take the following actions on one of the new nodes:
    a. Enter advanced privilege level:

       ```
       set -privilege advanced
       ```

    b. Enter the following command:

       ```
       storage failover modify -node node_name -cifs- ndo-duration
       default|medium|low
       ```

       - Enter `medium` if the system will have workloads in which 50% to 75% of the operations will be 4 KB or smaller.
       - Enter `low` if the system will have workloads in which 75% to 100% of the operations will be 4 KB or smaller.

    c. Return to the admin level:

       ```
       set -privilege admin
       ```

    d. Reboot the system to ensure that the changes take effect.

15. If you want to set up a switchless cluster on the new nodes, refer to References to link to the *NetApp Support Site* and follow the instructions in *Transitioning to a two-node switchless cluster*.

After you finish

If Storage Encryption is enabled on node1 and node2, complete the section Set up Storage Encryption on the new controller module. Otherwise, complete the section Decommission the old system.

Set up Storage Encryption on the new controller module

If the replaced controller or the HA partner of the new controller uses Storage Encryption, you must configure the new controller module for Storage Encryption, including installing SSL certificates and setting up key management servers.

About this task

This procedure includes steps that are performed on the new controller module. You must enter the command on the correct node.

Steps

1. Verify that the key management servers are still available, their status, and their authentication key information:

   ```
   security key-manager external show-status

   security key-manager onboard show-backup
   ```

2. Add the key management servers listed in the previous step to the key management server list in the new controller.

   a. Add the key management server:

      ```
      security key-manager external add-servers -key-servers
      key_management_server_ip_address
      ```

   b. Repeat the previous step for each listed key management server. You can link up to four key management servers.

   c. Verify the that the key management servers were added successfully:

      ```
      security key-manager external show
      ```

3. On the new controller module, run the key management setup wizard to set up and install the key management servers.

   You must install the same key management servers that are installed on the existing controller module.

   a. Launch the key management server setup wizard on the new node:

      ```
      security key-manager external enable
      ```

   b. Complete the steps in the wizard to configure key management servers.

4. Restore authentication keys from all linked key management servers to the new node:

   ```
   security key-manager external restore -node new_controller_name
   ```

Set up NetApp Volume Encryption on the new controller module

If the replaced controller or high availability (HA) partner of the new controller uses

NetApp Volume Encryption (NVE), you must configure the new controller module for NVE.

About this task

This procedure includes steps that are performed on the new controller module. You must enter the command on the correct node.

Steps

1. Verify that the key management servers are still available, their status, and their authentication key information:

   ```
   security key-manager key query -node node
   ```

2. Add the key management servers listed in the previous step to the key management server list in the new controller:

   a. Add the key management server:

      ```
      security key-manager external add-servers -key-servers
      key_management_server_ip_address
      ```

   b. Repeat the previous step for each listed key management server. You can link up to four key management servers.

   c. Verify the that the key management servers were added successfully:

      ```
      security key-manager external show
      ```

3. On the new controller module, run the key management setup wizard to set up and install the key management servers.

   You must install the same key management servers that are installed on the existing controller module.

   a. Launch the key management server setup wizard on the new node:

      ```
      security key-manager external enable
      ```

   b. Complete the steps in the wizard to configure key management servers.

4. Restore authentication keys from all linked key management servers to the new node:

For…	Use this command…
External key management (EKM)	`security key-manager external restore` This command needs the OKM passphrase
Onboard Key Manager	`security key-manager onboard sync`

After you finish

Check if any volumes were taken offline because authentication keys were not available or EKM servers could not be reached. Bring those volumes back online by using the `volume online` command.

After you finish

Check if any volumes were taken offline because authentication keys were not available or External Key

Management servers could not be reached. Bring those volumes back online using the `volume online` command.

Decommission the old system

After upgrading, you can decommission the old system through the NetApp Support Site. Decommissioning the system tells NetApp that the system is no longer in operation and removes it from support databases.

Steps

1. Refer to References to link to the *NetApp Support Site* and log in.
2. Select **Products > My Products** from the menu.
3. On the **View Installed Systems** page, choose which **Selection Criteria** you want to use to display information about your system.

   You can choose one of the following to locate your system:

   - Serial Number (located on the back of the unit)
   - Serial Numbers for My Location
4. Select **Go!**

   A table displays cluster information, including the serial numbers.

5. Locate the cluster in the table and select **Decommission this system** from the Product Tool Set drop-down menu.

Resume SnapMirror operations

You can resume SnapMirror transfers that were quiesced before upgrade and resume the SnapMirror relationships. The updates are on schedule after the upgrade is completed.

Steps

1. Verify the SnapMirror status on the destination:

   ```
   snapmirror show
   ```

2. Resume the SnapMirror relationship:

   ```
   snapmirror resume -destination-vserver vserver_name
   ```

Copyright Information

Copyright © 2022 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.