管理X1143A-R6介面卡

ONTAP 9

NetApp
May 14, 2022

This PDF was generated from https://docs.netapp.com/zh-tw/ontap/san-config/supported-port-config-x1143a-r6-adapter-concept.html on May 14, 2022. Always check docs.netapp.com for the latest.

目錄

管理X1143A-R6介面卡 1
X1143A-R6介面卡支援的連接埠組態總覽 1
設定連接埠 1
將UTA2連接埠從CNA模式變更為FC模式 1
變更CNA/UTA2目標介面卡光纖模組 3
檢視介面卡設定 4

管理X1143A-R6介面卡

X1143A-R6介面卡支援的連接埠組態總覽

根據預設、X1143A-R6介面卡是以FC目標模式設定、但您可以將其連接埠設定為10 Gb乙太網路和FCoE（CNA）連接埠、或設定為16 Gb FC啟動器或目標連接埠。這需要不同的SFP+介面卡。

當X1143A-R6介面卡設定為乙太網路和FCoE時、可在相同的10-GbE連接埠上支援並行NIC和FCoE目標流量。如果設定為FC、則可針對FC目標或FC啟動器模式個別設定每個共用相同ASIC的雙埠配對。這表示單一X1143A-R6介面卡可在一個雙埠配對上支援FC目標模式、在另一個雙埠配對上支援FC啟動器模式。連接至相同ASIC的連接埠配對必須設定為相同模式。

在FC模式中、X1143A-R6介面卡的運作速度就像任何現有的FC裝置一樣、最高可達16 Gbps。在CNA模式中、您可以使用X1143A-R6介面卡來同時處理NIC和FCoE流量、並共用相同的10 GbE連接埠。CNA模式僅支援FC目標模式的FCoE功能。

設定連接埠

若要設定統一化目標介面卡（X1143A-R6）、您必須在相同的特性設定模式下、在同一個晶片上設定兩個鄰近的連接埠。

步驟

1. 使用「系統節點硬體統一連線修改」命令、視光纖通道（FC）或整合式網路卡（CNA）的需求設定連接埠。
2. 連接FC或10 Gb乙太網路適用的纜線。
3. 確認您已安裝正確的SFP+：

   「網路FCP介面卡顯示-instance -Node介面卡」

   對於CNA、您應該使用10Gb乙太網路SFP。對於FC、您應該使用8 GB SFP或16 GB SFP、視所連接的FC架構而定。

將UTA2連接埠從CNA模式變更為FC模式

您應該將UTA2連接埠從「融合式網路介面卡」（CNA）模式變更為「光纖通道」（FC）模式、以支援FC啟動器和FC目標模式。當您需要變更連接埠與網路的實體媒體時、應該將特性設定從CNA模式變更為FC模式。

步驟

1. 使介面卡離線：

   「網路FCP介面卡修改節點node_name介面卡介面卡名稱-STATUS-admin DOWN」

2. 變更連接埠模式：

「ucadmin modify -node_name -Adapter adapter_name -mode FCP」

3. 重新啟動節點、然後將介面卡上線：

   「網路FCP介面卡修改節點node_name介面卡介面卡名稱-STATUS-admin up」

4. 請通知您的管理員或VIF管理程式、視情況刪除或移除連接埠：

   - 如果連接埠作為LIF的主連接埠、介面群組（ifgrp）或主機VLAN的成員、則管理員應執行下列動作：
     i. 移動LIF、從ifgrp移除連接埠、或分別刪除VLAN。
     ii. 執行「network port delete」命令、手動刪除連接埠。

     如果「網路連接埠刪除」命令失敗、系統管理員應該解決錯誤、然後再次執行命令。

   - 如果連接埠不是LIF的主連接埠、不是ifgrp的成員、也不是主控VLAN、則VIF管理程式應在重新開機時從記錄中移除連接埠。

     如果VIF管理程式未移除連接埠、則管理員必須在重新開機後使用「network port DELETE」命令手動移除連接埠。

```
net-f8040-34::> network port show

    Node: net-f8040-34-01
                                                          Speed(Mbps) Health
    Port      IPspace      Broadcast Domain Link MTU  Admin/Oper  Status
    --------- ------------ ---------------- ---- ---- -----------
--------
    ...
    e0i       Default      Default          down 1500  auto/10    -
    e0f       Default      Default          down 1500  auto/10    -
    ...

    net-f8040-34::> ucadmin show
                           Current  Current    Pending  Pending    Admin
    Node          Adapter  Mode     Type       Mode     Type
Status
    ------------  -------  -------  ---------  -------  ---------
-----------
    net-f8040-34-01
                  0e       cna      target     -        -
offline
    net-f8040-34-01
                  0f       cna      target     -        -
offline
    ...

    net-f8040-34::> network interface create -vs net-f8040-34 -lif m
```

```
-role
node-mgmt-home-node net-f8040-34-01 -home-port e0e -address 10.1.1.1
-netmask 255.255.255.0


    net-f8040-34::> network interface show -fields home-port, curr-port

    vserver lif                   home-port curr-port
    ------- --------------------- --------- ---------
    Cluster net-f8040-34-01_clus1 e0a       e0a
    Cluster net-f8040-34-01_clus2 e0b       e0b
    Cluster net-f8040-34-01_clus3 e0c       e0c
    Cluster net-f8040-34-01_clus4 e0d       e0d
    net-f8040-34
            cluster_mgmt          e0M       e0M
    net-f8040-34
            m                     e0e       e0i
    net-f8040-34
            net-f8040-34-01_mgmt1 e0M       e0M
    7 entries were displayed.

    net-f8040-34::> ucadmin modify local 0e fc

    Warning: Mode on adapter 0e and also adapter 0f will be changed to
fc.
    Do you want to continue? {y|n}: y
    Any changes will take effect after rebooting the system. Use the
"system node reboot" command to reboot.

    net-f8040-34::> reboot local
      (system node reboot)

    Warning: Are you sure you want to reboot node "net-f8040-34-01"?
    {y|n}: y
```

5. 確認您已安裝正確的SFP+：

   「網路FCP介面卡顯示-instance -Node介面卡」

   對於CNA、您應該使用10Gb乙太網路SFP。對於FC、您應該先使用8 GB SFP或16 GB SFP、再變更節點上的組態。

變更CNA/UTA2目標介面卡光纖模組

您應該變更統一化目標介面卡（CNA/UTA2）上的光學模組、以支援您為介面卡選取的特性設定模式。

步驟

1. 驗證卡中使用的目前SFP+。接著、將目前的SFP+替換為適當的SFP+、以符合偏好的特性設定（FC或CNA）。
2. 從X1143A-R6介面卡移除目前的光纖模組。
3. 針對您偏好的個人化模式（FC或CNA）光纖插入正確的模組。
4. 確認您已安裝正確的SFP+：

   「網路FCP介面卡顯示-instance -Node介面卡」

   支援的SFP+模組和Cisco品牌銅線（雙軸纜線）纜線列於中 "NetApp Hardware Universe"。

檢視介面卡設定

若要檢視統一化目標介面卡（X1143A-R6）的設定、您必須執行「系統硬體統一連線show」命令、以顯示控制器上的所有模組。

步驟

1. 在不連接纜線的情況下啟動控制器。
2. 執行「系統硬體統一連線show」命令、查看連接埠組態和模組。
3. 在設定CNA和連接埠之前、請先檢視連接埠資訊。

Copyright Information

Copyright © 2022 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.