NVMe儲存設備

ONTAP 9

NetApp
May 05, 2022

This PDF was generated from https://docs.netapp.com/zh-tw/ontap/concept_nvme_provision_overview.html on May 05, 2022. Always check docs.netapp.com for the latest.

目錄

NVMe儲存設備 1
配置NVMe儲存設備 1
為SUSE Linux配置NVMe儲存設備 1
調整命名空間大小 2

NVMe儲存設備

配置NVMe儲存設備

您可以使用非揮發性記憶體Express（NVMe）傳輸協定、在SAN環境中提供儲存設備。NVMe傳輸協定已針對固態儲存設備的效能最佳化。

對於NVMe、儲存目標稱為命名空間。NVMe命名空間是一組非揮發性儲存設備、可格式化為邏輯區塊、並以標準區塊裝置呈現給主機。您可以建立命名空間和子系統、然後將命名空間對應至子系統、就像是將LUN配置及對應至FC和iSCSI的igroup一樣。

NVMe目標是透過使用FC交換器的標準FC基礎架構、或使用乙太網路交換器和主機端介面卡的標準TCP基礎架構、連線至網路。

支援下列NVMe傳輸協定：

傳輸協定	開始於…	允許者…
TCP	零點9.10.1 ONTAP	預設
FCP	部分9.4 ONTAP	預設

相關資訊

- "使用System Manager為SUSE Linux配置NVMe儲存設備"
- "使用CLI設定NVMe的SVM"

為SUSE Linux配置NVMe儲存設備

建立命名空間、以使用NVMe傳輸協定為SUSE Linux伺服器提供儲存設備。Linux的命名空間似乎是SCSI磁碟裝置。

此程序會在現有的儲存VM上建立新的命名空間。您的儲存VM必須設定為NVMe、而且您的FC或TCP傳輸應該已經設定完成。

> 從ONTAP 供應儲存設備開始、預設會啟用QoS。您可以在資源配置程序期間或稍後停用QoS或選擇自訂QoS原則。

步驟

1. 在系統管理員中、按一下*儲存設備> NVMe命名空間*、然後按一下*新增*。

   如果您需要建立新的子系統、請按一下*「更多選項」*。

   a. 如果您執行ONTAP 的是支援功能的9.8或更新版本、而您想要停用QoS或選擇自訂QoS原則、請按一下*

更多選項*、然後在*儲存與最佳化*下選取*效能服務層級*。

2. 將FC交換器分區至WWPN。每個啟動器使用一個區域、並在每個區域中包含所有目標連接埠。
3. 在您的Linux伺服器上、探索新的命名空間。
4. 初始化命名空間並使用檔案系統進行格式化。
5. 確認Linux伺服器可以在命名空間上寫入和讀取資料。

調整命名空間大小

從ONTAP 版本號《支援》（2019）9.10.1開始、您可以使用ONTAP 支援的CLI來增加或減少NVMe命名空間的大小。您可以使用System Manager來增加NVMe命名空間的大小。

增加命名空間的大小

使用System Manager	使用CLI
1. 按一下「儲存設備**> NVMe**命名空間」。 2. 在您要增加的命名空間上執行Hoover、按一下 ⋮，然後按一下*編輯*。 3. 在* capaciam*下、變更命名空間的大小。	1. 輸入下列命令：「vserver NVMe命名空間modify -vserver *Svm_name*-path *path*–size *new_size__of_namespace*」

減少命名空間的大小

您必須使用ONTAP NVMe-CLI來減少NVMe命名空間的大小。

1. 將權限設定變更為進階：

   "進階權限"

2. 減少命名空間的大小：

   「Vserver NVMe命名空間修改-vserver *svm_name*-path *namespace_path*-size *new_size__of_namespace*」

Copyright Information

Copyright © 2022 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.