ハードウェアのセットアップがハングした場合（SG5600）

StorageGRID

NetApp
May 03, 2022

This PDF was generated from https://docs.netapp.com/ja-jp/storagegrid-116/sg5600/he-error-error-synchronizing-with-santricity-os-software.html on May 03, 2022. Always check docs.netapp.com for the latest.

目次

ハードウェアのセットアップがハングした場合（ SG5600 ） 1
HE エラー： SANtricity OS ソフトウェアとの同期エラー 2

ハードウェアのセットアップがハングした場合（SG5600）

ハードウェア障害やケーブル接続エラーによって E5600SG コントローラのブート処理が完了しなかった場合は、 StorageGRID アプライアンスインストーラを使用できないことがあります。

手順

1. いずれかのコントローラの警告 LED を確認し、点滅しているエラーコードを探します。

   電源投入時は、ハードウェアの初期化が完了するまで、保守操作可能を示す LED と保守操作要を示す LED が点灯した状態になります。また、 *diagnostic LED* という名前の下の桁の上の小数点も点灯します。デジタル表示ディスプレイには、両方のコントローラに共通のコードが順番に表示されます。これは正常な状態であり、エラーを示すものではありません。ハードウェアのブートが完了すると、保守操作の LED は消灯し、ディスプレイの制御がファームウェアに切り替わります。

2. E5600SG コントローラのデジタル表示ディスプレイのコードを確認します。

   > インストールとプロビジョニングには時間がかかります。フェーズによっては、StorageGRID アプライアンスインストーラの更新が数分間報告されないこともあります。

   エラーが発生すると、デジタル表示ディスプレイに HE などの一連のコードが点滅します。

3. これらのコードの意味については、次のリソースを参照してください。

コントローラ	参照
E5600SG コントローラ	• “he error:Error synchronizing with SANtricity OS Software” （エラー： OS ソフトウェアとの同期エラー） • "E5600SG コントローラのデジタル表示ディスプレイ・コード "
E2700 コントローラ	E シリーズのドキュメント • 注： * E シリーズ E5600 コントローラに関するコードは、アプライアンスの E5600SG コントローラには適用されません。

4. この方法で問題 が解決しない場合は、テクニカルサポートにお問い合わせください。

E5600SG コントローラのデジタル表示ディスプレイのコード

HE エラー： SANtricity OS ソフトウェアとの同期エラー

"E2700 コントローラドライブトレイおよび関連ドライブトレイ設置ガイド"

"ネットアップのマニュアル： E2700 シリーズ"

HE エラー： SANtricity OS ソフトウェアとの同期エラー

StorageGRID アプライアンスインストーラが SANtricity OS ソフトウェアと同期できない場合は、コンピューティングコントローラのデジタル表示ディスプレイに HE エラーコードが表示されます。

HE エラーコードが表示された場合は、次の対処策を実施します。

手順

1. 2 本の SAS インターコネクトケーブルの整合性をチェックし、しっかりと接続されていることを確認します。
2. 必要に応じて、一方または両方のケーブルを交換し、再試行します。
3. この方法で問題 が解決しない場合は、テクニカルサポートにお問い合わせください。

Copyright Information

Copyright © 2022 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.