MATLAB INTERFACE FOR RPL DODAG VISUALIZATION

Software Recommended: NetSim Standard v12.1 (32bit/ 64bit), Visual Studio 2015/2017/2019, MATLAB (32bit/ 64bit)

Note: This project works only with MATLAB v2015b or higher versions.

RPL (Routing Protocol for Low-Power and Lossy Networks) is a routing protocol for wireless networks with low power consumption and generally susceptible to packet loss. It is a proactive protocol based on distance vectors and operates on IEEE 802.15.4, optimized for multi-hop and many-to-one communication, but also supports one-to-one messages.


This protocol is specified in RFC 6550 with special applications in RFCs 5867, 5826, 5673 and 5548. RPL can support a wide variety of link layers, including those with limitations, with potential losses or that are used in devices with limited resources. This protocol can quickly create network routes, share routing knowledge and adapt the topology in an efficient way.

RPL creates a topology similar to a tree (DAG or directed acyclic graph). Each node within the network has an assigned rank (Rank), which increases as the teams move away from the root node (DODAG). The nodes resend packets using the lowest range as the route selection criteria.


The DODAG formed as part of RPL protocol in NetSim can be visualized by interfacing NetSim with MATLAB.

Steps to run MATLAB interface


1. After you unzip the downloaded project folder, Open NetSim Home Page click on **Open Simulation** option,




2. Click on Workspace options




3. Click on More Options,




4. Click on **Import**, browse the extracted folder path and go into the Workspace_DODAG_Visualization directory. Click on the Select folder button and then on **OK**.



5. Go to home page, Click on Open Simulation Workspace options Open code



- 6. Place PlotDAG.m file inside the MATLAB root directory. For Eg: "<MATLAB installed path>\MATLAB\R2015b", (Note: PlotDAG.m is provided inside the MATLAB_Code directory)
- **7.** Following modifications were done to the RPL project for this implementation:
 - a. Open RPL.c file and add fn_netsim_matlab_init(), fn_netsim_matlab_DODDAG_run() and fn_netsim_matlab_DODDAG_Init() inside fn_NetSim_RPL_Init() and fn_netsim_matlab_finish() inside fn_NetSim_RPL_Finish ().



- b. Add definitions of the following functions inside RPL.h file
 - a. double fn_netsim_matlab_init();
 - b. double fn_netsim_matlab_DODDAG_Init();
 - c. double fn_netsim_matlab_DODDAG_run();
- c. double fn_netsim_matlab_finish();

```
₹ RPL

        $\omega$ fn_netsim_matlab_finish()


    → (Global Scope)

                            __cplusplus
_cplusplus
                   #define _NETSIM_RPL_H_
       22
                 =#ifdef
                  #endif
                         //Log settings
                #define DEBUG_RPL
                  //#define DEBUG_RPL_PRINT_IP_TABLE
#define DEBUG_RPL_PRINT_DAO_ROUTE_INFOMATION
                  //#define DEBUG_RPL_TRICKLE
                   #endif
       33
       35
36
                  #include "RPL Message.h"
       37
38
39
                  //Include necessary lib's
#pragma comment(lib, "NetworkStack.lib")
#pragma comment(lib, "RPLlib,lib")
                         double fn_netsim_matlab_init();
                        double fn_netsim_matlab_DODDAG_Init();
double fn_netsim_matlab_DODDAG_run();
double fn_netsim_matlab_finish();
       41
       42
       44
       46
                          * Maximum amount of timer doubling.
```


d. Go to the Neighbor.c file. Inside Function void choose_parents_and_siblings(NETSIM_ID d) add fn_netsim_matlab_DODDAG_run() below rpl_add_route_to_parent()

```
Neighbor.c → X RPL_Message.h =
                           TA RPL
                                                                                                                          choose_parents_and_siblings(NETSIM_ID
                                NetSim_EVENTDETAILS pevent;
memset(&pevent, 0, sizeof pevent);
pevent.dEventTime = pstruEventDetails->dEventTime;
pevent.nDeviceId = d;
pevent.nDeviceType = DEVICE_TYPE(d);
pevent.nEventType = TIMER_EVENT;
pevent.nProtocolId = MM_PROTOCOL_RPL;
pevent.nSubEventType = RPL_NEM_PREF_PARENT;
fonAddFixer(&pevent);
      310
311
      312
      313
314
315
316
      317
318
319
320
321
                                  fnpAddEvent(&pevent);
                                netsim matlab DODDAG run();
       322
      323
324
                            for (i = 0; i < rpl->neighbor_count; i++)
      325
326
327
328
                                    RPL_NEIGHBOR neighbor = rpl->neighbor_list[i];
                                  if (matching_ranks[i] >= INFINITE_RANK)
                                         if (neighbor->lastDIOMSG != NULL)
      329
                                               */
**Forget messages from other DODAG iterations */
*rpl_dio_pdu_free(neighbor->lastDIOMSG);
*neighbor->lastDIOMSG = NULL;
       330
```


8. Create a user variable with the name of MATLAB_PATH and provide the path of the installation directory of user's respective MATLAB version.



9. Make sure that the following directory is in the PATH(Environment variable)
<Path where MATLAB is installed>\bin\win32




(**Note:** To run this code 32- bit version of MATLAB must be installed in your system. If you are interfacing for the first time then open command window and go to the **<NetSim installed directory>\bin** and type **matlab -regserver**)




- 10. Now Right Click on RPL project and select Rebuild.
- 11. Upon rebuilding, RPL.dll will automatically be updated in the respective bin folder of the current workspace.

Note:


• Based on whether you are using NetSim 32 bit or 64 bit setup you can configure Visual studio to build 32 bit or 64 bit Dll files respectively as shown below:




• While importing the workspace, if the following warning message indicating Software Version Mismatch is displayed, you can ignore it and proceed.



• Go to NetSim home page, click on **Open Simulation**, Click on **DODAG_Visualization_Example**.




Set Velocity to the sensors




Output:

A plot will open, showing the DODAG when the simulation is started and the first route is formed between sink node and the sensor. And the DODAG will be dynamically updated.

Initially formed DODAG





After simulation press any key in the NetSim command window to close the MATLAB.