Manualslib.com - The Global Manuals Library

NINJA FOODI AG301 QUICK START MANUAL

Table of Contents

Tips & Tricks
Here’s What’s in the Box
Cleaning Instructions
Grilling 101
Preheat for Better Results
Bake/Roast
Check Your Food Temp
Using Your Grill’s Functions
Grilling Cheat Sheet
Sneak a Peek
Other ManualsLib Projects

Tips & Tricks

Grill

The oil matters
For less smoke, we recommend using oils with a high smoke point—like canola, coconut, avocado, vegetable, or grapeseed oil—instead of olive oil.

Don't overcrowd
Evenly arrange and space out ingredients in a single layer to ensure consistent browning and even charring.

Batch cooking
Empty the fat/oil from the bottom of the pot if batch cooking more than twice. For best results, allow the unit to run for three minutes between batches to reheat the grill grate.

Check your food temp
The Foodi Grill cooks quickly, so monitor doneness with a food thermometer. Internal food temperature continues to rise as food rests, so remove it 5°F before target temperature is reached.

Air Crisp

Shake, shake, shake
When air fry crisping, check food and shake crisper basket frequently for even browning. Remove food at desired level of brownness.

Use oil for crispiness
For best results with fresh vegetables, use an even, light coating of canola oil.

Don't overcrowd
Evenly arrange and space out ingredients to ensure consistent browning.

Secure your food
Secure light food with toothpicks so it won't be blown around by the fan.

Bake/Roast

Convert traditional recipes
Use the Bake or Roast function to prepare foods typically cooked in the oven. Reduce the temperature by 25°F. Check food often to avoid overcooking.

Dehydrate

Prevent oxidation
Fruits like apples and pears brown quickly when cut. To prevent oxidation, soak them in water with a squeeze of lemon juice for 5 minutes.

Trim the fat
Before dehydrating meat, make sure to trim off all fat, as it does not dry out and could spoil.

Pasteurize jerky
Finish off dehydrated meats and fish by using the Roast function at 330°F for 1 minute.

Cleaning Instructions

Allow base to cool
before moving the unit, as the sides will be hot after cooking.

Use cleaning brush
to help clean the accessories. The opposite end of the brush is a scraper to help remove baked-on food.

Remove splatter shield
after it cools and clean after each use. Soak overnight and use cleaning brush to help remove baked-on grease from the frame and front tabs.

Deep Clean
by stacking the removable parts in the cooking pot and soaking them in the sink prior to handwashing.
All parts, except the main unit, are dishwasher safe.

©2019 SharkNinja Operating LLC.

Please make sure to read the enclosed Ninja® Owner's Guide prior to using your unit.

NINJA® Foodi™ GRILL

The grill that sears, sizzles, and air fry crisps™

Let's get grilling

Here's what's in the box

Recipe Book

Quick Start Guide

Owner's Guide

Foodi Grill

Splatter Shield
Must always be installed when unit is use.

Removable Cooking Pot
Must always be installed when unit is in use. Cook directly in the pot when roasting or baking.

Grill Grate
Use in the cooking pot for best grilling results.

Crisper Basket
Use in the cooking pot for best air crisping results.

Cleaning Brush
with scraper tip

Preheat for better results

For best grilling results, preheat the Foodi Grill before adding food. It may take about 8 minutes. Adding food before or during preheat may lead to overcooking.

APROX 8 MINS

Grilling 101

Use your Ninja Foodi Grill to grill indoors—to get even char, grill marks, and juicy flavor.

Grill Grate
Unique design promotes optimal airflow for even cooking, crisping, and charring.

APPROX. 5 MINS

Want juicier meat?
After grilling, remove meat and let rest at least 5 minutes before cutting it.

Go to ninjakitchen.com for how-to videos

More flavor. Less smoke.

After countless hours of recipe testing, our chefs have paired your favorite foods with a recommended temperature setting that will maximize grill flavors while minimizing smoke. We've also created a list of popular ingredients with our recommended cooking directions.

LOW (400°F)
Best for bacon, sausages, and calzones, and when using thicker barbecue sauces.

MED (450°F)
Best for frozen meats and marinated food.

HIGH (500°F)
Best for steaks, chicken, and burgers.

MAX (up to 510°F)
Best for veggies, fruit, fresh/frozen seafood and pizza.

FOR LESS SMOKE, WE RECOMMEND USING OILS WITH A HIGH SMOKE POINT—LIKE CANOLA, COCONUT, AVOCADO, VEGETABLE, OR GRAPESEED OIL—INSTEAD OF OLIVE OIL. If you choose to cook ingredients at a higher temperature than recommended, it may result in more smoke.

Grilling Cheat Sheet

New York Strip Steaks
2 steaks (14–16 oz. each, 1 ¼ in. thick)
Pat dry. Rub with 1 teaspoon canola oil. Season with salt and pepper.
HIGH 9–11 mins
Frozen: MED 18–24 mins
Flip halfway through cooking.

Boneless Chicken Breasts
4 breasts (7–9 oz. each)
Pat dry. Rub with 1 teaspoon canola oil. Season with salt and pepper.
HIGH 14–18 mins
Frozen: MED 22–26 mins
Flip halfway through cooking.

80% Lean Burgers
4 patties (4 oz. each)
Season with salt and pepper.
Store-bought: HIGH 4–6 mins
Handmade: HIGH 5–9 mins
Frozen: MED 10–15 mins
Flipping not necessary.

Salmon
4 fillets (5–6 oz. each)
Pat dry. Rub with 1 teaspoon canola oil. Season with salt and pepper.
MAX 7–9 mins
Frozen: MAX 10–13 mins
Do not flip during cooking.

Fresh Bone-in Chicken Thighs
4 thighs (7–9 oz. each)
Pat dry. Rub with 1 teaspoon canola oil. Season with salt and pepper.
HIGH 23–26 mins
Frozen: MED 25–28 mins
Flip halfway through cooking.

Boneless Pork Chops
4 chops (8 oz. each)
Pat dry. Rub with 1 teaspoon canola oil. Season with salt and pepper.
HIGH 14–16 mins
Frozen: MED 20–23 mins
Flip halfway through cooking.

Hot Dogs
(4 hot dogs)
Whole
HIGH 3–5 mins
Flip halfway through cooking.

Sausages
6 sausages (3–4 oz. each)
Whole
LOW 8–12 mins
Frozen: LOW 10–14 min
Flip halfway through cooking.

Shrimp
1 lb Jumbo (16–18 count)
Pat dry. Rub with 1 teaspoon canola oil. Season with salt and pepper.
MAX 3–5 mins
Frozen: MAX 4–6 mins
Do not flip during cooking.

Bone-In Marinated/ Barbecue Chicken Thighs
4 thighs (7–9 oz. each)
MED 18–21 mins
LOW 20–25 mins if using a thick sauce
Flip 2 to 3 times while cooking.

Boneless Marinated/ Barbecue Chicken Breast
4 breasts (7–9 oz. each)
MED 16–19 mins
LOW 19–24 mins if using a thick sauce
Flip 2 to 3 times while cooking.

Pineapple
(6–8 slices or spears, 2 in. thick)
MAX 7–9 mins
Flip gently several times during cooking.

Peppers & Onions
(1 pepper, 1 onion)
Cut in 1-in. slices
MAX 11–13 mins
Stir gently several times during cooking.

Yellow or Green Squash
3–4 each
Cut in quarters lengthwise. Toss with canola oil. Season with salt and pepper.
MAX 12–16 mins
Flip several times during cooking.

Fresh Corn on the Cob
(4 ears)
Brush lightly with canola oil. Season with salt and pepper.
MAX 10–13 mins
Flip halfway through cooking.

Fresh Asparagus
(1 bunch)
Toss with canola oil. Season with salt and pepper.
MAX 5–7 mins
Spread evenly on grill grate. Do not flip.

For more charts, please reference the included Inspiration Guide.

Using your grill's functions

FUNCTION	ACCESSORY USED	TEMP	TIME	PREHEAT
GRILL Grill indoors for juicy, charred flavor.		 Adjust temp between Low and Max. Refer to the previous page or the Inspiration Guide for which settings to use.	 Set time, in minutes, and press START/STOP.	
AIR CRISP Crisp without the guilt of deep frying.		 Adjust temp between 300°F–450°F.	 Set time, in minutes, and press START/STOP.	
ROAST Roast your favorite foods right in the pot.		 Adjust temp between 250°F–500°F.	 Set time, in minutes, and press START/STOP.	
BAKE Make cakes and other baked goods easily and quickly.	Not included 	 Adjust temp between 250°F–400°F.	 Set time, in minutes, and press START/STOP.	
DEHYDRATE Create delicious homemade chips and jerky.		 Adjust temp between 105°F–195°F.	 Add food, set time, in hours, and press START/STOP. There is no preheat.	

PRE will appear, and the blinking bars will show preheating progress. Once preheated, "Add Food" will display.

Do not add food before preheating is complete.

Grill preheat can take approximately 8 minutes because of the grill grate's high density.

Air Crisp, Roast, and Bake preheat takes approximately 3 minutes.

If you just used a different function, and the grill grate is at room temperature when you place it in the unit, "Add Food" may appear on the screen immediately. We recommend allowing the grill grate to heat up for at least 6 minutes before placing ingredients on it.

Sneak a Peek

Lift the hood while cooking to check on or flip food. Unit will automatically pause cooking when hood is lifted and resume when it is closed.

Other ManualsLib Projects

www.manualslib.com

www.manualslib.de

www.manualslib.es

www.manualslib.fr

www.manualslib.nl

www.manualslib.mx

www.manualslib.tech 30+ Languages