Nex-Gen Lumina — Sales Mode Guide

Welcome to the Nex-Gen Lumina Sales Mode guide. This document is written for **sales representatives** who use the Lumina app to conduct on-site LED lighting surveys, build zone plans, generate professional estimates, and collect customer signatures — all from a single mobile device.

---

1. Overview

Sales Mode is a dedicated field tool built into the Nex-Gen Lumina app. It gives you everything you need to run a complete site visit without leaving the app:

- **Prospect capture** — record customer contact information and home photos on-site
- **Zone builder** — map LED run lengths, injection points, power mounts, and product types for each area of the home
- **Estimate generation** — automatically build a professional, itemized estimate from your zone measurements
- **Customer signature** — present the estimate and collect a digital signature right on your phone or tablet
- **Materials & checkout** — calculate material lists, pull inventory, and reconcile after installation
- **Job tracking** — follow each job from draft through pre-wire to completed installation

Sales Mode is accessible from the login screen or from Settings within the app. You do not need a customer account to use it — just your Sales PIN.

---

2. Entering Sales Mode

From the Login Screen

1. Open the Nex-Gen Lumina app
2. On the login screen, tap **Sales Mode**

3. You are taken to the **Sales PIN Screen**

From Settings (if already logged in)

1. Navigate to **System** > **Settings**
2. Tap **Sales Mode**

Entering Your PIN

1. The Sales PIN Screen displays a 4-digit numeric keypad
2. Enter your **4-digit Sales PIN**
3. The PIN **auto-submits** as soon as all 4 digits are entered — no need to tap a button
4. If the PIN is valid, you land on the **Sales Landing Screen**

Your PIN is validated against the master sales PIN stored securely in Firestore. The first two digits of your PIN identify your dealer code.

> **Lockout:** After **5 failed PIN attempts**, you are locked out. You must restart the app to reset the attempt counter. If you cannot remember your PIN, contact your dealer admin.

---

3. Session Rules

Sales Mode sessions are time-limited to protect sensitive customer and pricing data.

Rule	Detail
Session length	30 minutes of inactivity
Warning	A dialog appears 5 minutes before timeout
Extend	Tap **Extend** on the warning dialog to reset the timer

Timeout	If the session expires, your progress is **auto-saved**

Any interaction with the app (tapping, scrolling, entering data) counts as activity and resets the inactivity timer. You do not need to worry about losing work — the app saves your progress automatically if you time out.

> **Tip:** If you step away from your device during a visit, keep an eye out for the timeout warning. A quick tap on "Extend" keeps your session alive.

---

4. The Sales Landing Screen

After PIN authentication, you arrive at the **Sales Landing Screen**. This is your home base in Sales Mode. It shows three feature cards summarizing what Sales Mode can do:

- **Home Visit** — Log zones, run lengths, injection points, and power mounts during a site survey
- **Estimate** — Generate a professional estimate with pricing and send it for customer signature
- **Handoff** — Connect the signed job to an installer team for Day 1 pre-wire and Day 2 install

Below the feature cards, you have three action buttons:

Button	What it does
New Visit	Start a brand-new site survey from scratch
My Estimates	View your list of all saved jobs and estimates
Dashboard	Open your dealer dashboard for a high-level view

To **exit Sales Mode**, tap the **Exit** button in the top-right corner of the landing screen.

---

5. The Sales Workflow — Step by Step

A complete site visit follows a five-step flow. Each step builds on the previous one, and your progress is saved along the way.

```
Prospect Info  -->  Zone Builder  -->  Visit Review  -->  Estimate Preview  -->  Customer Signature
  (Step 1)          (Step 2)          (Step 3)            (Step 4)               (Step 5)
```

Step 1: Prospect Information

Screen: ProspectInfoScreen

This is the first thing you fill out when you arrive at a customer's home. Collect their contact details and document the property.

Field	Required	Notes
First Name	Yes	Customer's first name
Last Name	Yes	Customer's last name
Email	Yes	Customer's email address
Phone	Yes	Best contact number
Address	Yes	Street address — start typing and Google Places will suggest matches
City	Yes	Auto-fills from address selection
State	Yes	Auto-fills from address selection
Zip Code	Yes	Auto-fills from address selection
Referral Code	No	If the customer was referred, enter their `LUM-XXXX` code
Notes	No	Any observations about the property or customer preferences

> **Tip:** The address field uses Google Places autocomplete. Start typing the street address and tap a suggestion from the dropdown to auto-fill the city, state, and zip code fields. If autocomplete is not available (no internet), you can type the full address manually.

Home Photos: You can also take or upload photos of the property directly from this screen. Tap the camera icon to capture photos of the home's roofline, fascia, or any areas you plan to include in the estimate. Photos are uploaded and attached to the job record.

Referral Validation: If the customer provides a referral code, the app validates it in real-time. A green checkmark confirms the referral is valid; a red indicator means the code was not found.

When everything looks good, tap **Next** to move to the Zone Builder.

> **Tip:** If you are resuming a previous visit, the fields will be pre-filled with the data you already entered. Just verify and update as needed.

Step 2: Zone Builder

Screen: ZoneBuilderScreen

This is the core of the site survey. You will walk the perimeter of the home and document each LED zone — where the lights will go, how long each run is, and where power needs to connect.

Adding a Zone

Tap the **+** button to add a new zone. A bottom sheet opens where you enter the zone details:

Field	Description
Zone Name	A descriptive label (e.g., "Front Roofline", "Garage Accent", "Side Fascia")

Run Length (ft)	Total linear footage of the LED run for this zone
Product Type	Choose from: Roofline (9" spacing), Diffused rope light, or Custom
Color Preset	RGBW, Warm White, Cool White, or Full RGB
Injection Points	Where power connects along the LED run (see below)
Power Mounts	Where power supplies and controllers are physically mounted
Photos	Take photos of the zone area for reference
Notes	Any special considerations (obstacles, mounting challenges, etc.)

Injection Points

An injection point is a location along the LED run where power is fed into the strip. For each injection point, you record:

- **Position (ft)** — how far along the run this injection sits
- **Served by controller** — whether this point is powered by the main controller or an additional power supply
- **Wire gauge** — automatically calculated based on the wire run distance:

Wire Run Distance	Recommended Gauge
Direct connection	Direct
Up to 30 ft	14/2
Up to 90 ft	12/2
Up to 140 ft	10/2
Over 140 ft	EXCEEDS — requires redesign

- **Wire run (ft)** — distance from the mount to the injection point

- **Architectural note** — any field observations (e.g., "runs behind gutter", "needs conduit")

> **Important:** If the wire gauge calculator shows **EXCEEDS 140ft**, the wire run is too long. You will need to reposition the power mount or add an additional power supply closer to the injection point.

Power Mounts

A power mount is where a controller or power supply is physically installed. For each mount, you record:

- **Position (ft)** — location along the run
- **Is controller** — whether this mount holds the primary controller or just a power supply
- **Supply size** — 350W, 600W, or controller
- **Outlet type** — Existing outlet or New outlet needed
- **Outlet note** — details about the outlet situation
- **Mount location note** — where exactly the mount will go (e.g., "inside attic near soffit vent", "garage wall left of door")

Zone Summary

As you add zones, the Zone Builder screen shows running totals at the top:

- Total linear footage across all zones
- Total controller slots used
- Total injection points
- Estimated total price

When all zones are documented, tap **Next** to proceed to the Visit Review.

> **Tip:** You can tap any existing zone to edit it, or swipe to delete. Take your time getting accurate measurements — they directly affect the estimate.

Step 3: Visit Review

Screen: VisitReviewScreen

Before generating the estimate, this screen gives you a complete summary of everything you have collected:

- **Prospect information** — name, contact details, address
- **Zone details** — each zone with its run length, product type, injection points, and power mounts
- **Totals** — overall footage, pixel count, controller slots, and pricing

Review every section carefully. If anything needs to be corrected, you can go back to the relevant step to make changes.

Scheduling Installation Dates

The Visit Review screen also lets you tentatively schedule:

- **Day 1 (Pre-wire)** — the date for running wires and mounting hardware
- **Day 2 (Install)** — the date for installing the LED strips and commissioning the system

Tap the date fields to open a date picker. Day 2 must be on or after Day 1.

When everything is verified, tap **Generate Estimate** to proceed.

Step 4: Estimate Preview

Screen: EstimatePreviewScreen

The app generates a professional, customer-facing estimate based on your zone measurements and pricing data. This screen shows:

- **Customer name and address** at the top
- **Itemized line items** for each zone — product type, footage, pixel count, and price
- **Total price** for the complete installation
- **Referral credit** (if a valid referral code was entered)

You can:

- **Share the estimate** — copies a link to the estimate to your clipboard, which you can send via text or email
- **Review line items** — verify that quantities and pricing look correct before presenting to the customer

> **Tip:** Walk the customer through the estimate on your screen before asking for a signature. Explain each zone, what product is being used, and what the total includes. Transparency builds trust.

When the customer is ready to approve, tap **Proceed to Signature**.

Step 5: Customer Signature

Screen: CustomerSignatureScreen

This is the final step. Hand your phone or tablet to the customer so they can review and sign the estimate digitally.

1. The screen displays a white signature pad
2. The customer signs with their finger on the pad
3. If they make a mistake, tap **Clear** to reset the pad
4. Once satisfied, tap **Approve & Sign** to submit

After the customer signs:

- The signature is captured as an image and uploaded securely
- The job status updates to **Estimate Signed**
- If a referral code was provided, the referral pipeline is triggered automatically
- The job is saved to Firestore and appears in your **My Estimates** list

> **Important:** Make sure the customer understands what they are signing. The signature constitutes approval of the estimate as presented.

6. Materials & Checkout Lifecycle

After an estimate is signed and installation dates are scheduled, the next phase is preparing the physical materials for the job. The Materials & Checkout system tracks every item from calculation through installation and reconciliation.

Overview

The materials lifecycle has four phases, each with its own screen:

```
Material List  -->  Checkout  -->  Day 1 Check-In  -->  Final Check-In
 (Calculate)      (Pull stock)    (Log usage)          (Reconcile)
```

A phase indicator bar at the top of each screen shows your progress through these stages.

Phase 1: Material List

Screen: JobMaterialListScreen — accessed from the Job Detail screen

When you open a job's material list for the first time, you will see an empty state with a **Calculate Materials** button. Tap it to generate the full bill of materials based on your zone measurements.

The calculation engine analyzes every zone and produces line items for:

Category	Examples
Light Pixel Nodes	1-PCS, 5-PCS, 10-PCS packs (optimized packing)
Rope Lighting	Diffused rope light pieces (5m each)
Rails	1-piece and 2-piece aluminum rails (per color)
Connector Wires	Extension wires in 1ft, 2ft, 5ft, 10ft, 20ft lengths
Accessories	T-connectors, Y-connectors, amplifiers, radar sensors
Controllers	Controller units

Power Supplies	350W and 600W supplies

Each line shows two quantities:

- **Calculated qty** — the exact amount needed based on zone measurements
- **Overage qty** — the amount to actually order, including a buffer (10% for lights, rails, and rope; 15% for connectors)

> **Tip:** The calculation handles corner cuts automatically. Corners require cutting 80mm from rail ends, which loses 2 lights per corner. The engine adds replacement rails and adjusts pixel counts to compensate.

Stock status is shown for each line item:

Chip	Meaning
In Stock	Sufficient inventory available
Low Stock	Some available, but less than the overage qty
Insufficient	Not enough on hand — reorder before checkout
Set qty	Y-connector — your project manager will set the quantity during approval

Summary stats at the top show total run footage, zone count, corner count, and number of line items.

> **Note:** Wire runs and power outlet costs are included in the sales estimate, not the material list. The material list covers physical LED components only.

Approving the list: When the material list looks correct, tap **Approve Material List**. This moves the status from Draft to Approved and enables the Checkout phase.

Phase 2: Checkout

Screen: MaterialCheckoutScreen — accessed via **Go to Checkout** on the material list

This screen lets you adjust the pull quantity for each line item before physically pulling materials from inventory. Every line shows a stepper control where you can increase or decrease the quantity.

For each item, you will see:

- **Suggested qty** — the overage amount (default pull quantity)
- **Available stock** — how many are on hand in your dealer's inventory
- **Stepper** — tap **-** or **+** to adjust

> **Stock guard:** If you try to pull more than what is available, a red warning banner appears at the top listing every item with insufficient stock. You cannot confirm checkout until all quantities are within available limits.

Connector wires are pre-calculated using an optimized packing algorithm that minimizes the number of pieces (preferring longer lengths). The section header notes this.

Y-connectors that were set to 0 by your project manager are dimmed and cannot be adjusted.

When quantities are set, tap **Confirm Checkout**. The system:

1. Deducts pulled quantities from dealer inventory
2. Reserves those materials against the job
3. Advances the job to **Checked Out** status
4. Navigates you to the Day 1 Check-In screen

You can also tap **Export Packing List** to generate a PDF packing slip to accompany the materials.

Phase 3: Day 1 Check-In

Screen: MaterialDay1CheckInScreen — accessed after checkout or from the job detail

After the pre-wire day, log what was actually used. This screen shows every checked-out line item with:

- **Pulled qty** — how many were checked out
- **Used Today** — enter the number consumed during Day 1
- **Remaining** — auto-calculated (pulled minus used)
- **Photo evidence** — tap the camera icon to photograph installed materials

> **Tip:** Take photos as you install. The camera button uploads each photo directly to the job record. A green checkmark confirms the upload succeeded.

Validation: If you enter a "Used Today" value that exceeds the pulled quantity, the field turns red with an error message. You must fix all errors before saving.

Tap **Save Day 1 Report** when complete. Materials remain reserved — nothing returns to inventory yet. After saving, the screen becomes read-only with a **Proceed to Final Check-In** button.

> **Important:** Materials stay reserved in inventory until the Final Check-In is complete. This prevents other jobs from claiming materials that are still on your truck.

Phase 4: Final Check-In

Screen: MaterialFinalCheckInScreen — accessed after Day 1 is saved

This is the reconciliation step after the installation is finished. For each line item, enter:

- **Day 2 Used** — materials consumed on installation day
- **Returned** — materials going back to inventory

The system automatically computes:

- **Waste** = Checked Out - Day 1 Used - Day 2 Used - Returned

Three summary cards at the top show dollar totals:

Card	Color	Shows
Total Used	Cyan	Cost of all materials consumed (Day 1 + Day 2)

Returned	Green	Cost of materials returned to inventory
Waste / Loss	Amber	Cost of unaccounted materials + efficiency percentage

> **Efficiency metric:** The waste card shows your efficiency percentage. For example, 96.5% efficiency means only 3.5% of checked-out materials were lost. Aim for 95%+ efficiency on every job.

Waste color coding:

Waste Level	Color
0% (no waste)	Green
Up to 5% of checkout	Amber
Over 5% of checkout	Red

Validation: Day 2 Used + Returned cannot exceed what was remaining after Day 1. Fix any errors before submitting.

Tap **Complete Job & Reconcile Inventory** to finalize. The system:

1. Returns unused materials to dealer inventory
2. Records waste quantities for reporting
3. Marks the job as **Complete**
4. Navigates you back to the job list

Material Status Summary

Status	Meaning	Who acts
Draft	Calculated but not reviewed	PM reviews
Approved	PM approved — ready for checkout	Installer pulls stock
Checked Out	Materials pulled from inventory	Installer begins work

Day 1 Complete	Day 1 usage logged with photos	Installer completes install
Complete	Inventory reconciled, job closed	Automatic

---

7. Job Tracking

My Estimates Screen

Tap **My Estimates** on the Sales Landing Screen to see all of your jobs. Each job card shows:

- **Job number** (e.g., NXG-0847)
- **Customer name**
- **Status badge**
- **Date created**

You can filter the list by status using the filter chips at the top of the screen.

Job Statuses

Each job progresses through a series of statuses:

Status	Meaning
Draft	Survey started but not yet complete — you can resume and finish it
Estimate sent	Estimate has been generated and presented to the customer
Signed	Customer has signed the estimate — ready for scheduling
Pre-wire scheduled	Day 1 pre-wire work has been scheduled with an installer
Pre-wire complete	Pre-wire work is finished — ready for Day 2
Install complete	Full installation is finished — the job is closed

Job Detail Screen

Tap any job in the list to open its full detail view. From here you can:

- View all customer and prospect information
- Review zone measurements and the itemized estimate
- See the customer's signature (if signed)
- View scheduled Day 1 and Day 2 dates
- **Update the job status** as work progresses (e.g., mark pre-wire as complete)
- **Generate a PDF** of the estimate for printing or emailing
- **Create an install plan** for the installer team

> **Tip:** Keep job statuses up to date. Your dealer admin and the installer team rely on accurate status information to coordinate schedules.

---

8. Best Practices

Before the Visit

- Charge your device fully — a site survey can take 30--60 minutes
- Make sure you have a reliable internet connection (cellular is fine)
- Have your Sales PIN ready

During the Visit

- **Measure twice.** Accurate run lengths are critical for a correct estimate. Walk the full perimeter and measure each zone carefully.
- **Document injection points on-site.** Note where power can realistically be connected — look for nearby outlets, attic access, and conduit paths.
- **Take photos.** Capture the roofline, fascia, soffits, and any tricky areas. Photos help the installer team during pre-wire and install.
- **Record power mount locations in detail.** Note whether existing outlets are available or if new ones are needed. This avoids surprises during installation.
- **Check for obstructions.** Gutters, downspouts, cameras, and decorative trim can affect LED placement. Note these in the zone's special considerations.

Presenting the Estimate

- Walk the customer through each line item before asking for a signature
- Explain what each zone covers and what product type is being used
- If the customer has questions about pricing, refer them to your dealer admin
- Be transparent — customers appreciate knowing exactly what they are paying for

After the Visit

- Verify the job appears in your **My Estimates** list
- Update the job status promptly as work is scheduled and completed
- Follow up with the customer if they did not sign on-site

---

9. Troubleshooting

Problem	Solution
PIN not working	Double-check that you are entering the correct 4-digit PIN. If locked out after 5 attempts, close and reopen the app to reset. If the PIN is still rejected, contact your dealer admin to verify your account is active.
Session expired mid-visit	Your progress is auto-saved. Re-enter Sales Mode with your PIN and your previous work will be restored.
Address autocomplete not showing suggestions	Check your internet connection. Google Places requires connectivity. If suggestions still do not appear, type the full address manually — city, state, and zip can be entered by hand.
Photos not uploading	Ensure you have a stable internet connection. Photos are uploaded to cloud storage and require connectivity. Try again when you have a stronger signal.

Wire gauge shows "EXCEEDS"	The wire run distance is over 140 ft, which is too long. Reposition the power mount closer to the injection point, or add an additional power supply.
Estimate totals look wrong	Go back to the Zone Builder and verify run lengths and product types for each zone. Pricing is calculated automatically from these values.
Cannot find a previous job	Make sure you are logged in with the same Sales PIN. Jobs are associated with the PIN used to create them. Check the filter chips on the My Estimates screen — you may have a status filter active.
Customer signature not saving	Ensure the customer has drawn a visible signature on the pad. The "Approve & Sign" button only activates when a signature is present. Check your internet connection if the upload fails.

---

10. Quick Reference Card

Action	How
Enter Sales Mode	Login screen → Sales Mode → enter 4-digit PIN
Start a new survey	Sales Landing → **New Visit**
View existing jobs	Sales Landing → **My Estimates**
Open dealer dashboard	Sales Landing → **Dashboard**
Add a zone	Zone Builder → tap **+** button
Edit a zone	Zone Builder → tap the zone card
Take a photo	Prospect Info or Zone Editor → tap camera icon

Enter a referral code	Prospect Info → Referral Code field → enter `LUM-XXXX`
Schedule install dates	Visit Review → tap Day 1 / Day 2 date fields
Share an estimate	Estimate Preview → tap **Share** (copies link to clipboard)
Collect signature	Estimate Preview → **Proceed to Signature** → hand device to customer
Calculate materials	Job Detail → **Materials** → **Calculate Materials**
Approve material list	Material List → **Approve Material List**
Check out materials	Material List → **Go to Checkout** → adjust quantities → **Confirm Checkout**
Log Day 1 usage	Day 1 Check-In → enter used quantities + photos → **Save Day 1 Report**
Final reconciliation	Final Check-In → enter Day 2 + returns → **Complete Job & Reconcile Inventory**
Extend session	Tap **Extend** on the timeout warning dialog
Exit Sales Mode	Sales Landing → **Exit** (top-right corner)

Nex-Gen Lumina v2.1 — Sales Mode Guide — April 2026