Nex-Gen Lumina — Dealer & Installer Setup Guide

Welcome to the Nex-Gen Lumina installation program. This guide walks you through setting up your dealer account, registering your installers, and completing customer installations using the Lumina app's Installer Mode.

---

1. Overview

The Lumina installation system uses a two-tier structure:

Role	Description
Dealer	Your company. Each dealer gets a unique 2-digit code (01--99).
Installer	A technician under your dealership. Each installer gets a 2-digit code (01--99).

Every installer receives a **4-digit PIN** combining both codes. For example, if your dealer code is **03** and an installer's code is **12**, their PIN is **0312**.

---

2. Getting Your Dealer Account

Dealer accounts are created by the Nex-Gen administrative team.

What Nex-Gen needs from you:

- Contact person name
- Company name
- Email address
- Phone number

Once created, you will receive:

- Your **2-digit dealer code** (e.g., `03`)
- Access to the **Admin Portal** for managing your installers

---

3. Registering Installers

As a dealer, you can add installers through the Admin Portal in the Lumina app.

Accessing the Admin Portal

1. Open the Lumina app
2. Navigate to **Installer Mode** (from the login screen or Settings)
3. Tap **Admin Access**
4. Enter the admin PIN provided by Nex-Gen

Adding a New Installer

1. Tap **Manage Installers**
2. Tap **Add Installer**
3. Enter the installer's information:
    - Full name
    - Email address
    - Phone number
4. The system auto-assigns the next available installer code
5. Tap **Save**

The installer's 4-digit PIN is generated automatically and displayed on screen.

> **Tip:** Share the PIN securely with your installer. They will need it every time they enter Installer Mode on a job site.

Managing Installers

From the Admin Portal you can:

- **Deactivate** an installer (blocks their PIN immediately)
- **View statistics** (total installations per installer)
- **Edit** contact details

> **Important:** If your dealer account is deactivated, all installers under your account are automatically locked out.

---

4. Installer Mode --- Step by Step

Installer Mode is a guided 6-step wizard that sets up a customer's Lumina system and creates their user account.

Entering Installer Mode

1. Open the Lumina app
2. Tap **Installer Mode** on the main screen
3. Read the overview screen, then tap **Continue**
4. Enter your **4-digit PIN** on the numeric keypad
5. The PIN auto-submits when all 4 digits are entered

> **Security:** You are locked out after 5 failed PIN attempts. Contact your dealer admin if locked out.

Session Rules

- Your session lasts **30 minutes** of inactivity
- A warning appears **5 minutes** before timeout
- You can **extend the session** from the warning dialog
- If the session expires, your progress is **auto-saved** and can be resumed later

---

Step 1: Customer Information

Enter the homeowner's details:

Field	Required	Notes
Full Name	Yes	Customer's name
Email	Yes	Must be unique --- this becomes their login
Phone	No	For contact purposes
Address	No	Start typing and Google Places will suggest matching addresses. Tap a suggestion to auto-fill. You can also type the address manually if needed.
Notes	No	Any special instructions

Tip: The email address is checked for uniqueness in real-time. If the customer already has a Lumina account, you'll see an error --- contact Nex-Gen support to link existing accounts.

Tip: The address field uses Google Places autocomplete for fast, accurate address entry. Just start typing the street address and select from the dropdown suggestions.

Tap **Next** to proceed.

Step 2: Controller Setup

This step connects the physical WLED controllers you've installed.

2a. Discover Controllers

- Make sure your phone/tablet is on the **same WiFi network** as the controllers
- Tap **Scan for Controllers** --- the app uses mDNS to find WLED devices
- Available controllers appear in a list with their IP addresses

2b. Select Controllers

- Check the box next to each controller that belongs to this installation

- At least one controller must be selected

2c. Name Each Controller

- Tap the name field next to each controller
- Give descriptive names (e.g., "Front Roofline", "Garage Accent", "Side Fascia")

2d. Test Connectivity

- Tap the **Test** button next to each controller
- A green checkmark confirms the controller is responding
- A red X means the controller is unreachable --- check power and WiFi

2e. Add New Controllers via Bluetooth (optional)

- If a controller hasn't been configured for WiFi yet, tap **Add via BLE**
- This launches the Bluetooth provisioning wizard
- Walk through WiFi credential entry on the controller

2f. Installation Photo (optional)

- Tap **Capture Photo** to photograph the completed installation
- This photo is stored with the installation record for reference

Tap **Next** to proceed.

Step 3: Roofline Configuration

> **This step is critical.** Incorrect roofline configuration will cause patterns to display incorrectly, colors to appear on wrong sections, chase effects to run the wrong direction, AI recommendations to fail, and anchor point lighting to break. Complete all sub-steps accurately.

The Roofline Wizard has 5 sub-steps.

3a. LED Count & Controller Info

Select Active Channels Controllers support up to 8 output channels. Select which are in use. Most residential installs use **Channel 1 only**.

Enter Total LED Count Enter the **exact** total number of LEDs installed (1--2600). This number must match the physical LED count. Count LEDs at junction boxes if unsure.

Controller Location Describe where the controller is mounted (e.g., "Garage attic", "Basement utility room", "Behind soffit near front door").

LED Start Location (LED #1) Describe where the first LED is physically located (e.g., "Front left corner of house", "Above garage door, left side").

LED Direction Select the overall direction LEDs were installed: Left to Right, Right to Left, Clockwise, or Counter-clockwise.

LED End Location Describe where the last LED is located (e.g., "Front right corner, returning to start").

Architecture Type Select the roof style that best matches:

Type	Description
Ranch	Flat or minimal peaks
Gabled	Single peak/gable
Multi-Gabled	Multiple peaks
Complex	Mixed features, dormers, valleys
Modern	Contemporary, unique shapes
Colonial	Traditional with dormers

3b. Segment Definition

Segments divide the roofline into logical sections. They **must** be added in the order LEDs are physically connected, starting from LED #1.

Segment Types

Type	Use For

Run	Straight horizontal/diagonal section
Corner	90° corner where roofline changes direction
Peak	Roof apex/gable point
Column	Vertical pillar or post
Connector	Transition between sections

For each segment, enter:

1. **Name** — Descriptive label (e.g., "Front Left Eave", "Main Peak")
2. **LED Count** — Exact number of LEDs in this segment (all segments must add up to the total)
3. **Type** — Select from the table above
4. **Direction** — Which way LEDs flow (Left to Right, Right to Left, Upward, Downward)
5. **Location** — Where on the house (Front, Back, Left Side, Right Side)
6. **Is Prominent** — Check if this is a focal point (peaks, front sections)

Example Roofline (200 LEDs)

#	Name	LEDs	Type	Direction
1	Left Eave	45	Run	L→R
2	Left Corner	8	Corner	Upward
3	Left Gable	35	Run	Upward
4	Main Peak	6	Peak	L→R
5	Right Gable	35	Run	Downward
6	Right Corner	8	Corner	Downward
7	Right Eave	45	Run	L→R
8	Return	18	Run	L→R

Total: 45+8+35+6+35+8+45+18 = **200**

3c. Anchor Point Identification

Anchor points are special LEDs where accent effects focus (peaks, corners). The system uses these for voice commands like "Light up the peaks", corner accent patterns, and chase animation reversal points.

For each segment:

1. Review auto-detected anchor points
2. Adjust LED index if the anchor is not centered correctly
3. Set anchor zone size (default: 2 LEDs)

Anchor Types

Type	Description
Peak	Apex of a gable/roof
Corner	Where roofline changes direction
Boundary	Start/end of a segment
Center	Middle of a segment
Custom	User-defined special point

3d. Review & Save

Before saving, verify:

- Total LED count matches physical installation
- All segments add up to total LED count
- Segment order follows physical LED wiring
- Peaks and corners are marked correctly
- Directions are accurate for each segment
- Anchor points are positioned correctly

Tap **Save Configuration** to complete.

3e. Test the Configuration

After saving:

- Turn lights on/off
- Test a pattern and confirm it displays correctly across segments
- Test brightness control
- Verify chase direction is correct

Tap **Next** to proceed.

Step 4: Zone Configuration

Choose how the system is organized:

Option A: Residential Mode (Single Property)

Best for: Single homes with one or more LED runs acting as a unified system.

1. Select **Residential**
2. Choose which controllers to **link together**
3. All linked controllers respond to every command as one system
4. Maximum 5 sub-users (family members) can be added later

Option B: Commercial Mode (Multi-Zone)

Best for: Businesses with independent lighting areas.

1. Select **Commercial**
2. Create zones (e.g., "Storefront", "Patio", "Parking Lot")
3. For each zone:
    - Assign a **primary controller**
    - Optionally add **secondary controllers** (for DDP/UDP sync)
    - Enable DDP sync if needed for multi-controller zones
4. Maximum 20 sub-users can be added later

Tap **Next** to proceed.

Step 5: Customer Preferences (Handoff)

This step configures the customer's initial experience. These settings personalize the Autopilot AI and overall app behavior.

Profile Type

Confirm **Residential** or **Commercial** (carried from Step 3). For commercial accounts, enter the property manager's email.

Favorite Sports Teams

Select any teams the customer follows. Lumina uses these for automatic game-day lighting.

Available teams include: Chiefs, Royals, Sporting KC, KC Current, Cardinals (STL), Blues (STL), Seahawks, Sounders, Mariners, and more.

Favorite Holidays

Select holidays the customer wants automated seasonal lighting for:

Christmas, Halloween, 4th of July, New Year's, St. Patrick's Day, Thanksgiving, Easter, Valentine's Day

Lighting Style (Vibe Level)

Use the slider to set the customer's preferred intensity:

Level	Style
Low (0.0)	Soft and tasteful --- gentle fades, warm whites
Medium (0.5)	Balanced --- seasonal colors and patterns
High (1.0)	Maximum impact --- full animations, celebration mode

Auto-Pilot Autonomy

How much should the AI manage automatically?

Level	Behavior
Ask Me First	Passive --- always waits for user approval
Smart Suggestions	Shows weekly preview, auto-applies if no response in 24 hours
Full Auto-Pilot	Fully automatic, no approval needed

Simple Mode

Toggle this ON for customers who prefer a simplified interface:

- Large, easy-to-tap buttons
- Only Home and Settings tabs visible
- 3--5 favorite patterns for quick access
- Great for older users or first-time smart home owners
- Customers can switch to Full Mode anytime in Settings

Step 6: Complete Setup

When you tap **Complete Setup**, the app:

1. Creates the customer's Firebase account (email + temporary password)
2. Registers the installation in the system (warranty starts: 5 years)
3. Creates the user profile with all preferences
4. Links the selected controllers to their account
5. Increments your installation count
6. Signs you out of the installer session

Customer Credentials Screen

A dialog displays the customer's login credentials:

```
SETUP COMPLETE!

CUSTOMER LOGIN CREDENTIALS
---------------------------
Name:               Jane Smith
Email:              jane@email.com
Temporary Password: Xk9mB2nQ

Customer should change their password after first login.
```

Actions available:

- **Copy Email** --- copies just the email
- **Copy Password** --- copies just the password
- **Copy All** --- copies everything
- **Done** --- finishes the setup

> **Important:** Write down or copy these credentials before tapping Done. The temporary password cannot be retrieved later. If lost, the customer must use "Forgot Password" to reset.

---

5. Handing Off to the Customer

Give the customer their credentials and walk them through:

1. **Download the Lumina app** from the App Store or Google Play
2. **Open the app** and tap **Sign In**
3. **Enter the email and temporary password** you provided
4. **Change their password** when prompted
5. **Complete the Welcome Wizard** (permissions + white selection)
6. **Dashboard appears** --- their system is ready to use

> **Bridge Health Check:** When the customer first opens the app (and on every subsequent launch), Lumina automatically runs a bridge health check. The app pings the ESP32 bridge via Firestore and waits for an acknowledgment. The result appears as a status indicator on the home screen --- a green icon means the bridge is online and

> reachable, while a grey icon means the bridge did not respond. If the bridge shows as unreachable after a fresh install, verify that the bridge is powered on and connected to the customer's WiFi network.

> **Pro Tip:** Take 2 minutes to show the customer the dashboard. Toggle a preset, adjust brightness, and say "Try asking Lumina to set the lights to warm white." This builds confidence and reduces support calls.

---

6. Configuring Remote Access

For customers who want to control their lights away from home, Remote Access must be configured before you leave the job site. This requires a **Lumina Bridge** --- a small ESP32 device that stays plugged in at the customer's home and relays commands from the cloud to the WLED controller.

Setting Up the Lumina Bridge

Before configuring remote access in the app, the bridge device itself must be set up:

1. **Flash the Lumina Bridge firmware** onto an ESP32 using PlatformIO (see the [ESP32 Bridge Setup Guide]() for detailed instructions)
2. **Connect to the bridge's WiFi AP** (`Lumina-XXXX`) from your phone
3. **Walk through the 3-step setup wizard:**
   - **Step 1:** Connect the bridge to the customer's home WiFi
   - **Step 2:** Enter the bridge's Firebase credentials (email/password)
   - **Step 3:** Enter the customer's Lumina user ID and WLED controller IP
4. The bridge reboots and begins polling Firestore for commands

After setup, you can verify the bridge is working by opening `http://<bridge-ip>/` in a browser to see the bridge dashboard. All three status indicators (WiFi, Firebase Auth, User Paired) should show green.

Configuring Remote Access in the App

1. Open the **System** tab (gear icon in the bottom navigation)

2. Tap the **Remote Access** tab along the top
3. The tab shows a quick status summary (enabled/disabled, bridge status, home WiFi SSID)
4. Tap the **Set Up Remote Access** button (or **Remote Access Settings** if already enabled) to open the full configuration screen

On the Remote Access settings screen:

- **Enable Remote Access** toggle
- **Home WiFi SSID** --- tap **Detect Home Network** while connected to the customer's WiFi (used to detect whether the customer is home or away)
- **Bridge connection** --- confirm the Lumina Bridge is online (the bridge health indicator should show green)
- **Webhook URL** (if applicable) --- for advanced/DIY integrations only

> **Tip:** The bridge health check runs automatically on every app launch. If the bridge shows as unreachable during setup, check the bridge dashboard at `http://<bridge-ip>/` to diagnose the issue. Power-cycle the ESP32 and wait 30 seconds before retrying.

---

7. Resuming an Incomplete Setup

If you exit the wizard before completing, your progress is saved automatically.

Next time you enter Installer Mode:

1. Enter your PIN
2. A dialog appears: **"Resume Previous Setup?"**
3. Shows the customer name, current step, and when it was saved
4. Choose **Resume Setup** to continue where you left off
5. Or **Start Fresh** to begin a new installation

---

8. Warranty & Installation Records

Each completed installation automatically creates a warranty record:

Field	Value
Warranty Start	Date of installation
Warranty Duration	5 years
Installer	Your name and PIN
Dealer	Your company name and code
Controllers	Serial numbers of all installed devices
Address	Customer's installation address

These records are accessible to the Nex-Gen support team for warranty claims.

---

9. Quick Reference

PIN Format

`[Dealer Code (2 digits)][Installer Code (2 digits)]` Example: Dealer 03 + Installer 12 = **0312**

Setup Steps

1. Customer Information (name, email, address)
2. Controller Setup (discover, select, name, test)
3. Roofline Configuration (segments, anchors, directions)
4. Zone Configuration (residential or commercial)
5. Customer Preferences (teams, holidays, vibe, autonomy)
6. Complete & Hand Off (credentials screen)

Support

Email: support@nexgenled.com

For troubleshooting, see the separate **Lumina Troubleshooting Guide**.

Nex-Gen Lumina v2.1 --- Dealer & Installer Guide --- March 2026