Lumina Sales Mode — Complete Guide

Audience: Dealers and sales reps running site visits.

Sales Mode is the app you live in on a home visit. Walk the perimeter, build a complete priced estimate in 15 minutes, collect a signed contract before you leave. Every signed job flows straight into your dealer's Day 1 Queue — no paperwork, no double entry, no lag. Permanent residential and commercial lighting that works as hard as you do, and Sales Mode is how you close faster and hand off cleaner.

What you'll need

- The Lumina app on your phone or tablet
- Your **4-digit Sales PIN** (first 2 digits = dealer code, last 2 = salesperson code)
- The customer's address and contact info
- A working camera and a measuring wheel or laser for channel lengths
- Phone signal or Wi-Fi on-site — estimates save to the cloud continuously

---

1. Getting in

Sales Mode is gated behind a 4-digit PIN. First two digits identify your **dealer**; last two identify you as the **salesperson**.

1. Open the Lumina app
2. Tap the **Lumina logo** 5 times on the login screen to open the Staff PIN screen
3. Type your 4-digit code. The first two dots turn **violet** (dealer) and the last two turn **cyan** (salesperson) so you can see which half you're typing.
4. The session starts automatically as soon as the 4th digit is entered

Lockout

- **5 attempts.** The 5th miss locks the keypad and you'll need to restart the app.
- The screen tells you exactly how many attempts you have left after each miss.

Session timeout

- Sessions run **30 minutes** of activity
- A warning appears **5 minutes before** the session ends so you can extend without losing work
- Tap any button or scroll to reset the timer
- Timing out logs you out cleanly. Drafts are saved to the cloud — sign back in to pick up where you left off.

---

2. The Sales Landing screen

After you log in, the Sales Mode home screen gives you three primary actions:

Button	What it does
New Visit	Start a brand-new prospect from scratch — how every estimate begins.
My Estimates	Your job list. Use it to find existing prospects, check job status, or resume a draft.
Dashboard	Opens your Dealer Dashboard (inventory, messaging settings, etc.).

Three informational cards below (Home Visit, Estimate, Handoff) summarize the workflow for new salespeople.

To leave Sales Mode any time, tap **Exit** in the top-right.

---

3. Creating a new prospect

Tap **New Visit**. This opens **Step 1 of 3 — Customer info** with a progress bar at the top.

Customer fields (all required unless noted)

Field	What it's used for
First Name	Used in every customer email and SMS
Last Name	Shown on the estimate, signed contract, and job cards
Email	Where the booking confirmation, account invite, and "system is live" emails go. Validated for proper email format. Stored as lowercase.
Phone	Where every SMS reminder goes (Day 1 confirmation, Day 1 reminder, Day 2 confirmation, Day 2 reminder, "wiring complete" notification). Auto-formatted as `(123) 456-7890`.
Address	Type the street address — an autocomplete dropdown pops up. Tap a suggestion and **City**, **State**, and **Zip** fill in for you.
City	Auto-filled. Editable.
State	2-letter abbreviation, auto-filled. Editable.
Zip	5 digits, auto-filled. Editable.
Referral code *(optional)*	If the customer was referred, type the LUM-XXXX code. The app checks it in real time — green checkmark = valid, red X = not found. The referrer gets credit automatically once the customer signs.
Salesperson Notes *(optional)*	Free text for gate codes, dog warnings, "park in driveway," etc. The install crew sees these.

Home photos

Below the form, a horizontal **Home photos** strip lets you add up to **6 photos** of the home exterior.

- Tap **Add photo** to open the gallery picker
- Each photo uploads immediately to the job's secure cloud folder
- Remove a photo by tapping the **X** in its corner
- Photos taken here become part of the prospect record. The blueprint background photo is captured separately in the wizard.

Continuing

Tap **Continue to zones** →. The app will:

1. Validate every required field
2. Save the prospect to a new draft job in the cloud
3. If you typed a valid referral code, mark the referral as "visit scheduled"
4. Open the Estimate Wizard

4. The Estimate Wizard — 5 steps

The wizard is the heart of every site visit. It collects everything the install crew needs to do their job and everything the customer needs to see on their estimate.

Leave the wizard any time and resume later — progress is saved continuously.

Step 1 — Home photo

Goal: capture the primary photo of the front of the home.

This photo becomes the **blueprint background** that the Day 1 electrician and Day 2 install team work from. The channel runs you draw later will be overlaid on this image.

1. Tap **Capture or choose photo**
2. Pick a clean, well-framed shot showing the **entire front of the home** with the rooflines clearly visible
3. The photo uploads automatically. A green **Saved** checkmark confirms it's stored.
4. Tap **Continue** →. (If you skip the photo, the button reads **Skip for now** → — you can add it later from the job detail screen, but the install crew prefers having it.)

Step 2 — Controller placement

Goal: tell the electrician exactly where the controller will mount.

This is where the brain of the lighting system lives. The Day 1 electrician runs all wiring back to this single point.

Fields:

Field	Notes
Location description	**Required.** Be specific: "Garage left interior wall, 3 feet from breaker panel" beats "garage" every time. The electrician relies on this.
Mount type	**Interior** or **Exterior**. Interior is the default and is preferred whenever possible.
Distance to nearest outlet (ft)	Optional but helpful. The electrician uses this to plan whether a new outlet is needed.

Photo:

- Tap **Capture photo** (or **Replace photo**) to take a picture of the proposed mount location
- A photo makes Day 1 dramatically faster — the electrician can verify the spot before they arrive

Tap **Continue** → when done. The button is disabled until you've entered a location description.

Step 3 — Channel setup

Goal: define every continuous LED strip run on the home.

What is a channel?

A **channel** is one continuous LED strip wired to one output port on the controller. A typical home has 1–4 channels:

- Channel 1: Front roofline
- Channel 2: Garage roofline
- Channel 3: Side accent

- Channel 4: Back patio

Each channel must be a single unbroken physical run. If the LEDs turn a corner, that's still one channel. If they restart somewhere else on the house, that's a separate channel.

Adding a channel

1. Tap **Add channel** — a bottom sheet opens
2. Fill in the fields:

Field	What it means
Channel number	Auto-assigned (1, 2, 3…). Read-only.
Label	A human-readable name like "Front Roofline" or "Garage Eaves".
Linear feet	The total length of this run, in feet. Round up.
Start description	Where this run begins — "Left corner of house, ground level".
End description	Where this run ends — "Right corner above garage".
Direction	Which way the strip is fed when installed. Pick **Left** → **Right**, **Right** → **Left**, **Top** → **Bottom**, or **Bottom** → **Top**. The Day 2 install team relies on this.
Start photo *(optional)*	A close-up of the starting point.
End photo *(optional)*	A close-up of the ending point.

3. Tap **Save**

The new channel appears as a card. You can:

- **Tap a card** to edit it
- **Swipe a card left** to delete it

Add **at least one channel** to continue. The **Continue** → button stays disabled until you have one.

Step 4 — Power injection points

Goal: add power injection points for any channel longer than 100 feet.

What is power injection?

LED strips lose voltage as the run gets longer — the LEDs at the far end will be dimmer or color-shifted than those near the controller. To fix it, you "inject" extra power partway down the run via a separate wire from the controller (or a supplemental power supply).

The 100-foot rule

Any channel longer than 100 feet must have at least one injection point. The wizard will warn you in Step 5 if any channel is over 100 feet without injection.

General guideline:

- **100–200 ft** — 1 injection point at the midpoint
- **200–300 ft** — 2 injection points (1/3 and 2/3)

- **300+ ft** — 3+ injection points

Adding an injection point

1. Find the channel section you want to add an injection to
2. Tap **Add injection point** under that channel — a bottom sheet opens
3. Fill in the fields:

Field	What it means
Channel run	Read-only — confirms which channel this injection belongs to.
Location description	Where on the run the injection lives. "Corner of deck, behind downspout"
Distance from start	How many feet from the start of the run. The wizard uses this to compute the wire gauge.
Outlet status	**Has nearby outlet** if there's an existing outlet within reach, or **New outlet needed** if the electrician will need to run one.
Distance to outlet	Only shown if you picked "Has nearby outlet".
Photo *(optional)*	A picture of the injection location.

4. The **wire gauge** field auto-calculates based on distance from the controller mount:
    - **Direct** — 0 feet
    - **14/2** — up to 30 ft
    - **12/2** — up to 90 ft
    - **10/2** — up to 140 ft
    - **EXCEEDS 140ft** — over 140 ft (warning — the electrician may need to relocate the controller)
5. Tap **Save injection**

Each injection appears as a card under its channel. Tap to edit, swipe to delete.

Tap **Continue** → to move on. Injection points are technically optional, but the Step 5 review will flag any over-100ft channels that don't have one.

Step 5 — Summary and generate estimate

Goal: review everything and generate the priced estimate.

Read-only summary cards for:

- **Home photo** — captured or not captured
- **Controller location** — description, interior/exterior, distance to outlet
- **Channels & footage** — total channels, total linear feet, total injections
- **Channel breakdown** — every channel listed with its footage, direction, and injection count

Warnings appear in amber if anything is missing or out of spec:

- "No home photo — blueprint will be text-only"
- "No controller mount location set"
- "Controller location has no photo"

- "Channel N (X ft) is over 100ft and has no injection point"

Scroll back and fix any of these by tapping the corresponding step at the top of the screen.

When you're satisfied, tap **Generate Estimate** →. The app will:

1. Save your wizard work to the cloud
2. Pull your dealer's pricing rules
3. Build the priced line items (LED strip, controller, power, hardware, labor)
4. Open the **Estimate Preview** screen

---

5. Reviewing the estimate with the customer

The **Estimate Preview** screen is what you show the customer. Designed to look like a professional quote.

What's on the screen

- **Header** — "NEX-GEN LED — Custom lighting estimate", with the job number and a "Valid 30 days" note
- **Customer name and address** in bold at the top
- **Referral badge** (cyan with a gift card icon) if the customer was referred — shows who referred them
- **Line items grouped by category:**
  - **LED STRIP** — strip footage and per-foot price
  - **CONTROLLER** — the brain of the system
  - **POWER** — wire, supplies, injection connectors
  - **HARDWARE** — mounting clips, brackets
  - **LABOR** — install labor
- **Subtotals** for materials and labor
- **Total estimate** in very large bold text at the bottom
- **What's included** — static feature list: Permanent mount, App-controlled, Holiday-ready, Dusk to dawn, 1-year warranty

Walking the customer through it

Take your time. Highlight the line items so the customer understands what they're paying for. Point out the **What's included** section — the included app, dusk-to-dawn automation, and warranty are usually the strongest differentiators.

Sharing the estimate

Tap **Share with customer** to copy a unique estimate link to your clipboard. Paste it into a text or email if the customer wants a copy before signing.

When the customer is ready to sign, continue forward to the signature screen, or use the dedicated signature route from the bottom of the preview.

---

6. Customer signature

The **Signature** screen is where the customer formally approves the job.

What the customer sees

- A large **Approve your estimate** heading
- Their name and the **grand total** in cyan
- A scrollable summary of the estimate

- A **signature canvas** (white box) where they draw their signature with a finger
- Boilerplate terms text below the canvas

Capturing the signature

1. Hand the device to the customer
2. Have them sign in the canvas area
3. If they make a mistake, tap **Clear** and try again
4. **Approve & confirm** only becomes active once a signature is present
5. The customer (or you) taps **Approve & confirm**

What happens next (automatically)

The moment the signature is approved, the app:

1. Saves the signature image to the job's cloud folder
2. Moves the job status to **Signed (** `estimateSigned` **)**
3. Records the timestamp of the signature
4. If the job had a valid referral code, marks the referral as "confirmed" — the referrer's credit is locked in
5. Sends the customer a **booking confirmation email** explaining the 2-day install process
6. Drops the job into your dealer's **Day 1 Queue** so the electrician can pick it up
7. Returns you to the Sales Landing screen

You'll see a green confirmation: **"Estimate approved — install is confirmed"**.

---

7. The job status pipeline

Every job moves through a sequence of statuses. Here's the full pipeline.

Status	Plain English	Who owns it next
Draft	Estimate is being built but not generated or signed	The salesperson — finish the wizard
Estimate sent	Estimate generated and shared with the customer but not yet signed. *(Legacy; the wizard usually goes straight to Signed.)*	The salesperson — follow up
Signed	Customer has signed. Job is booked. Booking email goes out.	The Day 1 electrician — schedule the visit
Pre-wire scheduled	Day 1 has a date. Day 1 confirmation SMS goes out.	The Day 1 electrician — show up and do the work
Pre-wire complete	Day 1 is done. Wires are run. "Wiring complete" SMS goes out.	The Day 2 install team — schedule the visit
Install scheduled	Day 2 has a date. Day 2 confirmation SMS goes out.	The Day 2 install team — show up and install
Install complete	Job is fully done. Customer welcome email with download links goes out. Customer's Lumina account is created.	Nobody — the job is closed

Each status moves the job between queues automatically. You don't manually advance statuses unless something goes wrong (the **Job Detail** screen has manual buttons for those rare cases).

---

8. The My Estimates screen

Tap **My Estimates** from the Sales Landing screen (or the **+** floating action button to start a new visit from this screen).

Filter chips

A horizontal row of chips narrows the list:

- **All** — every job for your dealer
- **Draft** — gray
- **Sent** — violet
- **Signed** — cyan
- **Pre-wire** — amber
- **Complete** — green

Tap a chip to filter. Tap **All** to clear.

What each card shows

Element	Meaning
Customer name (bold, large)	Who the job is for
Job number (right-aligned)	Auto-generated — looks like `NXG-20260409-001`
Address	Street + city, ellipsized if long
Status pill (left, color-coded)	Where the job is in the pipeline
Total price (right, green)	The signed estimate total
Progress bar (bottom)	Visual fill from 0% (draft) to 100% (install complete)

Tap any card to open the **Job Detail** screen — full job info with manual status-advance buttons (only use if a job is stuck — see the Full Job Lifecycle doc for recovery procedures).

Empty state

No jobs yet? You'll see a large receipt icon and a **Start a new visit** button.

Quick reference — first-visit checklist

When you arrive at a new prospect's home, this is the order:

1. **Take exterior photos** — at least one clean shot of the front, plus close-ups of any tricky areas
2. **Walk the perimeter** with the customer. Identify which surfaces will get LEDs.
3. **Find the controller location** — near an outlet, ideally interior, ideally in the garage
4. **Measure each channel** with a wheel or laser. Round up.
5. **Note injection point candidates** for any run clearly over 100 feet
6. **Sit down with the customer** and walk them through the wizard live. Show them the price as it builds.
7. **Hand them the device** to sign
8. Done. The booking email goes out automatically.

What success looks like

- You finish the wizard on-site in 15 minutes or less
- The customer signs before you leave the home
- The job appears in the dealer's Day 1 Queue within seconds of signature
- The customer receives the booking confirmation email while you're still in the driveway
- The channel count, footage, injection points, and controller location on the estimate match what the install crew will actually find when they arrive

If something isn't working

"My PIN won't work." Confirm all 4 digits. Check that your dealer is active and that your salesperson account hasn't been deactivated — contact your dealer admin if unsure. 5 failed attempts locks the keypad; restart the app.

"Photos aren't uploading." Check your phone signal or Wi-Fi. Photos upload the moment you capture them. If the upload icon keeps spinning, move to better coverage and retry — the app holds the capture until it succeeds.

"The referral code shows red X." The code isn't valid. Double-check with the customer — LUM-XXXX format, 4 characters after the dash. If they insist the code is right, proceed without it and contact your dealer admin to investigate.

"The Continue button is disabled." Every required field on the current step needs a value. Scroll through and look for amber warnings or empty required fields. Step 3 needs at least one channel. Step 2 needs a controller location description.

"I can't get a clean signature on the canvas." Tap **Clear** and try again. A shaky line is fine — the signature just needs to be non-empty to unlock the **Approve & confirm** button.

"I generated the estimate but the price looks wrong." Your dealer's pricing defaults fell back to something unexpected. Check the dealer pricing config in the Dealer Dashboard. If it still looks off, contact your dealer admin or Nex-Gen LED LLC — they can audit the pricing rule.

"I left mid-wizard and lost my work." You didn't. Drafts save continuously to the cloud. Open **My Estimates**, find the customer, tap to resume.

Need help? Reach out to your Nex-Gen LED LLC corporate contact or check the support resources in the Dealer Dashboard.