서식 있음: 들여쓰기: 왼쪽 0 글자

# Demo Application UI Guide (NxQuickRearCam)

Version <u>01</u>.60.0

## **Display Audio**

Solution Team



#### Release information

The following changes have been make to this document.

**Change History** 

Date	Change	4-
28 Feb. 201904- Dec. 2017	First release for v1.0.0First release for v0.6.0	

#### **Proprietary Notice**

Information in this document is provided solely to enable system and software implementers to use Nexell products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Nexell reserves the right to make changes without further notice to any products herein.

Nexell makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Nexell assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters which may be provided in Nexell data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals" must be validated for each customer application by customer's technical experts. Nexell does not convey any license under its patent rights nor the rights of others. Nexell products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Nexell product could create a situation where personal injury or death may occur. Should Buyer purchase or use Nexell products for any such unintended or unauthorized application, Buyer shall indemnify and hold Nexell and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Nexell was negligent regarding the design or manufacture of the part.

Copyright© 2017 Nexell Co.,Ltd. All rights reserved.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electric or mechanical, by photocopying, recording, or otherwise, without the prior written consent of Nexell.

#### Contact us

[11595] BundangYemiji Bldg. 12F, 31 Hwangsaeul-ro 258 beon gil, Bundang-gu, Sungnam-city, Gyeonggi-do, Korea.

TEL: 82-31-698-7400 FAX:82-31-698-7455 http://www.nexell.co.kr 서식 있는 표

# Contents

Chap 1.	Overview	<u> </u>
	1.1 Overview	<u>1</u>
	1.2 Block Diagram	1
	1.3 Application UI	
	1.4 Configuration File	
Chap 2.	Camera Library	<u>65</u>
	2.1 Overview	6 <del>5</del>
	2.2 APIs	6 <del>5</del>
Chap 3.	History	1310
	3.1 Known Issue	13 <del>10</del>
	3.2 To do list	13 <del>10</del>
Chap 1.	<u>Overview</u>	1
	1.1 Overview	1
	1.2 Block Diagram	1
	1.3 Application UI	1

Chap 2.	Camera Library
	2.1 Overview
	2.2 APIs
Chap 3.	History
	3.1 Known Issue

### Chap 1. Overview

#### 1.1 Overview

이 문서는 Display Audio 의 Demo Application 인 NxQuickRearCam 에 대해서 설명한\* 문서이다. NxQuickRearCam 은 Kernel Layer 의 NxQuickRearCam Camera application 의 동작을 이어받아서 동작하도록 되어있다.

Demo Application 에서는 차량용 Rear Camera System 을 modeling 하기 위하여 GPIO pin 한 개를 후방 기어로 modeling 하였으며, 이를 통하여 application 이 <u>camera 영상은 display 하도록 되어 있으며 software deinterlace engine 을 실행되도록 구성되어있다.포함하고 있다.</u>


\* NxQuickRearCam : booting 완료(NxLauncher 실행을 포함) 전, backgear 와 연동되는 camera service 를 제공하기 위한 application.

#### 1.2 Block Diagram

NxQuickRearCam 은 아래와 같이 구성되어있다. Application 시작시에 kernel layer 의 CameraQuickRearCam Application 으로부터 제어권을 얻어 오기 위한 signal 을 발생시킨다. 이로부터 NxRearCamapplication 은 자체적으로 back gear 롤 detection 하며 NxQuickRearCamcamcra 영상을 display 하도록 구성되어 있다.이 실행되도록 구성되어있다.

**서식 있음:** 양쪽

**서식 있음:** 양쪽



**서식 있음:** 가운데

#### 1.3 Application UI

Application 화면은 다음과 같으며 화면상에 Camera 영상과 Parking Guideline 이 같이← 주사된다. 서식 있음: 양쪽



**서식 있음:** 가운데

Overview

Draw Parking Guideline

**서식 있음:** 왼쪽

#### 1.4 Configuration File

Configurationfile(rearcam\_config.xml)은 camera 및 display 를 위한 configuration 값들이포함되어 있다.Configuration file 은 "/nexell/daudio/NxRearCam/"에 위치한다 파일이존재하지 않을 경우, application 은 default value 들로 실행된다.

Configuration file 의 형식은 다음과 같다.

[rearcam\_config.xml]

<?xml version="1.0" encoding="UTF-8"?</pre> <map> <string name="module">1</string> <string name="use\_intercam">1</string> <string name="cam\_width">704</string> <string name="cam\_height">480</string> <string name="video\_layer\_idx">0</string> <string name="crtc\_idx">0</string> <string name="cam\_display\_x">0</string> <string name="cam\_display\_y">0</string> <string name="cam\_display\_width">1024</string> <string name="cam\_display\_height">600</string> <string name="deinterlace\_engine">1</string> <string name="deinter\_param">3</string> <string name="lcd\_width">1024</string> <string name="lcd\_height">600</string> <string name="pgl\_enable">1</string> <string name="backgear\_enable">1</string> <string name="gpioIdx">163</string> <string name="quick\_running">1</string>

**서식 있음:** 양쪽

#### </map>


| Configuration      | <u>Description</u>  |
|--------------------|---|
| module             | Camera senor module number  |
| use_intercam       | Interlace camera 사용 여부  0: not use interlace camera  1: use interlace camera  |
| cam_width          | Camera image width  |
| cam_height         | Camera image height   |
| video_layer_idx    | Camera image가 rendering될 layer index. 본 application에서는 video layer에 rendering되므로 0으로 setting되어야 함   |
| crtc_idx           | 몇 번째 crtc를 사용할 것인지에 대한 index로 하나의 displaydevice만 지원되면 0으로 setting되어야 하며 두 개 이상의 displaydevice를 사용할 경우 선택적으로 원하는 display device의 index를setting |
| cam display x      | Camera image를 display할 위치의 시작 x position  |
| cam_display_y      | Camera image를 display할 위치의 시작 y position  |
| cam_display_width  | Camera image display width  |
| cam display height | Camera image display height   |
| deinterlace engine | Interlace camera를 사용할 경우 적용할 deinterlace engine 0: none 1: Nexell deinterlace engine 2. TS deinterlace engine                                 |
| deinter param      | Motion detect sensitivity. TS deinterlace engine을 사용할 경우 적용되<br>는 parameter   |
| <u>lcd_width</u>   | display device ☐ display width  |
| lcd_height         | display device display height   |
| pgl enable         | Parking guide line을 drawing할 것인지 결정  0 : parking guide line을 그리지 않음  1 : parking guide line을 그림   |
| backgear_enable    | Backgear 연동을 할 것인지 결정   |

#### Overview

|               | 0:backgear 연동하지 않음                  |
|---------------|-------------------------------------|
|               | 1:backgear 연동 함                     |
| gpioIdx       | Backgear와 mapping되어 있는 gpio의 number |
|               | QuickRearCam의 사용 여부                 |
| quick_running | 0:QuickRearCam을 사용하지 않음             |
|               | 1:QuickRearCam을 사용함                 |

서식 있음

아래는 display position 및 size 와 관련된 configuration parameter 들을 설명하기 위한 그림이다.



**서식 있음:** 들여쓰기: 왼쪽 2.13 글자

Camera image 가 display 되는 region 은 display device 가 지원하는 full 영역을 사용할 수도 있고, camera image 의 aspact ratio 를 고려하여 camera image 가 display 되는 region 을 설정할 수도 있다.

**서식 있음:** 들여쓰기: 왼쪽 5.67 글자

## Chap 2. Camera Library

#### 2.1 Overview

Camera 의 동작을 제어하기 위한 <u>library</u> libnxrearcam<u>.so 가</u>의 제공되며, <mark>사용방법은</mark>\_ <u>API 들은</u> 아래와 같다.

#### 2.2 APIs

#### 2.2.1 NX RegisterBackGearEventCallBack()

void NX RegisterBackGearEventCallBack(void \*pAppData, void (\*callback)( int32 t))

Description

Register callback function for action when backgear is detected.

<u>Parameter</u>

void \*pAppData : pointer of app data

void (\*callback)( int32\_t) : callback function

Return Value

<u>None</u>

**서식 있음:** 글꼴: 굵게 없음

**서식 있음:** 글꼴: 굵게 없음

**서식 있음**: 표준

#### 2.2.2 NX StartBackGearDetectService ()

int32 t NX StartBackGearDetectService( int32 t nGpio, int32 t nChkDelay )

Description

Start backgear detection service.

Parameter

int32 t nGpio : index of gpio for backgear

int32\_t nChkDelay: interval time for checking gpio status

Return Value

Zero is successful, -1 is failed

**서식 있음**: 표준

#### 2.2.3 NX\_StopBackGearDetectService()

void NX StopBackGearDetectService()

Description

Stop backgear detection service

Parameter
None
Return Value
None

<u>2.2</u>

**서식 있음:** 표준

#### 2.2.4 NX RearCamInit()

int32 t NX QuickRearCamInit

(NX REARCAM INFO \*p VipInfo, DISPLAY INFO\* p dspInfo, DEINTERLACE INFO \*p deinterInfo)

Description

Initialization

<u>Parameter</u>

NX\_REARCAM\_INFO\* p\_VipInfo : configuration for camera

DISPLAY\_INFO\* p\_dspInfo : configuration for display

DEINTERLACE\_INFO\* p\_deinterInfo : configuration for deinterlace

Return Value

Zero is successful, -1 is failed.

#### - NX\_REARCAM\_INFO

| typedef struct NX_REARCAM_II | <u>FO{</u>                   |
|------------------------------|------------------------------|
| int32_t iType;               | //camera type : CAM_TYPE_VIP |
| int32_t iModule;             | //camera module index        |
| int32_t iSensor;             | //sensor                     |
| int32_t iClipper;            | //clipper                    |
| int32_t bUseMipi;            | //using mipi                 |
| int32_t bUseInterCam;        | //using interlace camera     |
| int32_t iFpsNum;             | //frame per sec              |
| int32_t iFpsDen;             | //denominate value of fps    |
| int32_t iNumPlane;           | //number of plane            |
| int32_t iWidth;              | //camera input width         |
| int32_t iHeight;             | //camera input height        |
| int32_t iCropX;              | //crop x position            |
| int32_t iCropY;              | //crop y position            |
| int32_t iCropWidth;          | //crop width                 |
| int32_t iCropHeight;         | //crop height                |
| int32_t iOutWidth;           | //decimator width            |
| int32_t iOutHeight;          | //decimator height           |
| } NX_REARCAM_INFO;           |                              |

#### - DISPLAY\_INFO

| int32 t iPlaneIdx;    | //drm plane index  |
|-----------------------|--|
| int32 t iCrtcIdx;     | //drm crtc indexc  |
| uint32 t uDrmFormat;  | //drm data format  |
| int32 t iSrcWidth;    | //width of input image   |
| int32 t iSrcHeight;   | //height of input image  |
| int32 t iCropX;       | //crop x position  |
| int32 t iCropY;       | //crop y position  |
| int32 t iCropWidth;   | //crop width   |
| int32 t iCropHeight;  | //crop height  |
| int32 t iDspX;        | //display position   |
| int32 t iDspY;        | //crop start x position  |
| int32 t iDspWidth;    | //crop start y position  |
| int32 t iDdspHeight;  | //crop width   |
| int32 t iCropHeight;  | //crop height  |
| int32 t iPlaneId PGL; | //plane ID for drawing parking guide line                      |
| int32 t uDrmFormat PG | L; //data format for drawing parking guide line                |
| void* m pNativeWin    | ndow; //only for surface view rendering at android application |
| } DISPLAY_INFO;       |  |

#### - DEINTERLACE\_INFO

| typedef struct tagDEINTERLACE_INFO{  |
|--|
| int32_t iWidth; //width of input image   |
| int32_t iHeight; //height of input image   |
| int32_t iEngineSel; //deinterlace engine - 0 : none 1:nexell deinterlace 2: Thunder soft deinterlace |
| int32_t iCorr: // correlation value of motion detection sensitivity for Thunder soft deinterlace     |
| _} DEINTERLACE_INFO;   |
| int32_t NXDA_ShowRearCam(  |
| — CAMERA_INFO *pComInfo,   |
| —DISPLAY_INFO *pDspInfo );   |
| Description  |
| -Show Rear Camera.   |
| Parameter  |
| -pCamInfo : Camera Information   |
| pDspInfo : Display Information   |
| Return Value   |
| Please describe return value.  |

**서식 있음:** 들여쓰기: 첫 줄: 4 글자

#### 2.2.5 NX\_RearCamDeInit ()

int32\_t NX\_RearCamDeInit()

Description

**서식 있음:** 다단계 번호 매기기 + 수준:3 + 번호 스타일: 1, 2, 3, ... + 시작 번호: 1 + 맞춤: 왼쪽 + 맞춤 위치: 0 cm + 들여쓰기 위치: 2.5 cm

**서식 있음:** 표준, 글머리 기호 또는 번호 없이

None Return Value Zero is successful, -1 is failed. NX\_RearCamStart() int32 t NX QuickRearCamStart() Description Start rendering rear camera images. **Parameter** None Return Value Zero is successful, -1 is failed. NXDA\_HideRearCam() void NXDA\_HideRearCam( void <del>);</del> Description -Hide Rear Camera. Parameter Return Value None NX RearCamGetStatus int32 t NX QuickRearCamGetStatus() Description Get status <u>Parameter</u> Return Value <u>0 : stop</u> 1 : init 2 : running 2.2.2 NXDA\_RegRenderCallback()

void NXDA\_RegRenderCallback(

Rear cam deinit Parameter

2.2.6

2.2.1

2.2.7

```
void *pApp
int32_t (callback)(void *, int32_t, void*, int32)

};

Description
Register Rear Camera render callback.

Parameter
.pApp : private handle.
.callback : redering callback.
int32_t callback(void* pApp, int32_t type, void* data, int32_t dataSize)
.pApp : private handle.
.type : callback function type. (CB_TYPE_BUFFER, CB_TYPE_HIDE, CB_TYPE_SHOW)
.data : send data for callback.
.dataSize : size of data

Return Value
None
```

#### 2.2.8 NX RearCamGetVersion

```
int32 t NX QuickRearCamGetVersion()

Description

Get NxQuickRearCam version information

Parameter

None

Return Value

Version information

Major : ((return value) & 0xFF000000) >> 24

_Minor : ((return value) & 0x00FF0000) >> 16

_Revision : ((return value) & 0x000FF000) >> 8

_Reservation : ((return value) & 0x00000FF)
```

#### 2.2.3 NXDA\_RegControlCallback()

```
void *pApp,
_____int32_t (callback)(void *, int32_t, void *, int32_t)
);

Description
_____Register Rear Camera control callback.

Parameter
___pApp _____: private handle.
_____. callback _____: redering callback.
int32_t callback(void* pApp, int32_t type, void* data, int32_t dataSize)
______. pApp _____: private handle.
_____. type _____: callback function type. (CB_TYPE_BUFFER, CB_TYPE_HIDE, CB_TYPE_SHOW)
```

2.2.4

서식 있음

서식 있음: 들여쓰기: 첫 줄: 0.5 글자

#### 2.2.52.2.9 NX\_RearCamSetDisplayPosition\_ NXDA\_StartBackGearDetectService()

```
int32_t NXDA_StartBackGearDetectService(
```

```
int32_t aGpiox,
int32_t aChkDelayy,
int32_t w.
int32_t h
);

Description

Set display position of camera images-Start-back-gear-detection-service:
```

Parameter

-: nGpiox :\_ : GPIO port numberstart x-position.

-- nChkDelayy : start y-position

- w : display width.

- h : display heightGPIO check delay (mSec)

Return Value
Zero is returned.

#### 2.2.6 NXDA\_StopBackGearDetectService()

```
void NXDA_StopBackGearDetectService(
void
);

Description
Start back gear detection service.

Parameter
-None.

Return Value
None.
```


#### 2.2.7 NXDA\_RegisterBackGearEventCallback()

```
void NXDA_RegisterBackGearEventCallback(

void *pAppData,

void (*callback)(void *pAppData, int32_t nOnOff)
```

NEXELL



# Chap 3. History

#### 3.1 Known Issue

-. Not yet.

#### 3.2 To do list

-. Audio Focus 전환 시나리오 적용.

