PRECAUTIONS FOR USE

- This device is intended exclusively for INDOOR USE
- Any operation must be carried out solely by qualified and authorized technical personnel.
- Before operating inside the device, unplug the power cord from the electricity network.
- The device is not intended for use by persons (including children) whose physical, sensory or mental capabilities are reduced, who lack experience or knowledge, unless they have been given supervision or instructions regarding the use of the device through the intermediation of a person responsible for their safety
- Avoid knocking over the device or violent shocks as glass and screens are present.
- The keys for lock opening of device's access doors to internal compartments must be kept by the appliance's operator only.

ATTENTION!

Any other use of the device and operation not expressly permitted in this user manual is strictly forbidden. If the safety precautions are not observed, there is danger of death.

WARNINGS FOR USE

A This electronic device is intended to be used exclusively as a machine that provides a service (automatic cash handling machine); any other use will be considered illegitimate

B Any modification to the device that is not madeby the manufacturer, in addition to making the brand invalid and creating hazardous situations, implies the manufacturer's declination of responsibility and is also considered as an action in conflict with the existing law.

C Before cleaning, unplug the device from the power socket (pull on the plug and not on the cable).

D Do not commit any action that could cause the device to fall. The device must be installed on a fixed, horizontal base and must not be put in conditions that can cause it to fall.

E In case of fall, immediately unplug the device from the power socket (pulling on the plug and not on the cable); but first make sure that the cable and the plug have not been damaged. In such case cut out the electricity from the main power supply system to which the device is connected. If any faults are detected, immediately unplug the device from the power socket (pulling on the plug and not on the cable) and ask for repair by qualified personnel only.

F When cleaning the electronic device turn it off and unplug it from the power socket by pulling on the plug. Do not use gasoline or flammable solvents as detergents; always use authorized commercial, non-flammable and non-toxic detergents only. Do not directly spray liquids (water, solvents etc.) that could dampen live parts.

G For a correct cleaning, dampen a cloth with the previously listed products and at the end wipe off with a dry cloth in order to eliminate humidity that could damage the device.

Be careful never to leave any wet parts after cleaning. In case of doubt do not plug the device to the power socket for at least 24 hours. If the device has been exposed to an excessive amount of liquid, do not plug it to the power socket and contact your dealer.

H Never use liquids near the power socket where the device is plugged.

I Never use liquids near the power point of the power supply system of the premises where the device is installed.

L Make sure that the electrical safety labels (see "Safety Precautions") and device's data label on the rear of the device are not removed.

DISPOSAL PRECAUTIONS

MANDATORY INFORMATION FOR USERS

- According to the WEEE Directive, the appliance must be disposed of separately from the municipal waste. Therefore, separate WEEE collection systems must be used, or the device can be returned to the distributor when purchasing a new one.

- Illegal or improper disposal of the device, or of parts of the device, may have potentially harmful effects on the environment and on human health
.
- The symbol below is placed on the device toindicate that disposal must follow the WEEE separate collection system, and that sanctions will be applied in case of illegal disposal.

INFORMATION FOR USERS

Pursuant to Directive 2002/95/CE, 2002/96/CE and 2003/108/CE, "on the restriction of the use of certain hazardous substances in electrical and electronic equipment and on waste electrical and electronic equipment":

The crossed-out wheelie bin symbol on the equipment or on its packaging indicates that this product at the end of its working life must be collected separately from other waste.
An adequate separate collection of the discarded appliance and the subsequent start of the recycling, treatment and environmentally compatible disposal processes help to avoid possible negative effects on the environment and on health and promotes the reuse and/or recycling of the materials of which the equipment is composed. The abusive disposal of the product by the holder involves the application of administrative sanctions provided for by current legislation.

This symbol applied on the device indicates that:

- This electrical or electronic equipment must not be disposed of as solid municipal waste;
- A separate collection must be made;
- It can be returned to distributor when purchasing a new appliance;
- Improper disposal of the device may cause environmental pollution and have harmful effects on human health;
- Non-compliance with the above mentioned indications is sanctioned in accordance with the current regulations

In particular:

- The outer casing and mechanical components are made of plastic and/or metallic materials;
- Inside the casing there are printed circuit boards with electronic components;
- There may be Ni-Cd or Lithium batteries on the cards;
- The electrical connections are made with insulated copper conductors;