Macro Microcontroller 2 Datasheet




Fig 1: Top View of Macro Microcontroller 2

Contents

[Contents](#)
[Overview](#)
[Specifications](#)
[Precautions](#)
[Enclosure](#)
[Schematics](#)
[PCB Routing and Layout](#)
[Block Diagram](#)
[Pinout](#)
[Built-in IO Devices](#)
[Bill of Materials](#)
[Macro Microcontroller DOS](#)
- [Installation](#)
- [Commands and Programs](#)
- [Predefined Values for Parameters](#)

[Macro Microcontroller BASIC](#)
- [Installation](#)
- [Statements](#)
- [Predefined Values](#)

[Version History](#)
[Legal](#)

Overview

Macro Microcontroller 2 is an RP2040 microcontroller development board with an integrated macropad that lets you control GPIOs with keyboard keys on a single PCB, plus a custom BASIC interpreter and disk operating system.

Specifications

Microcontroller Unit: RP2040
Power: 5V input via data port or barrel jack, 3.3V input via GPIO pin headers, maximum logic voltage is 3.3V.
Dimensions: 96.52 × 35.56 mm
Flash Memory: 16 MB
Mounting Hole Dimensions: 2.5mm diameter

Precautions

- Do not apply logic voltages exceeding 3.3V to any GPIO or inputs. This may cause onboard components to be damaged.
- Use only one power source at a time, either via the data port, barrel jack or 3V3 and GND pins to power the board.
- Only the data port and barrel jack accepts a maximum voltage of 5V. Onboard Low Dropout (LDO) Regulators provide regulated 3.3V when powered by either inputs only. The 3V3 pin provides a separate power connection and bypasses these input regulators.
- This is an electrostatic-sensitive device. Handle the board only by the sides and avoid touching components and pins.
- Do not handle with wet hands.

Enclosure




Fig 2: 3D Model of Macro Microcontroller 2 Enclosure

This enclosure is 3D-printable and is available for download from https://github.com/Nicholas1023/macro-microcontroller-2/releases/download/v0.0.1/macro-microcontroller-2-enclosure.stl

Schematics




Fig 3: Schematics of Macro Microcontroller 2

PCB Routing and Layout




Fig 4: Copper traces and Silkscreen of Macro Microcontroller 2

Block Diagram




Fig 5: Block Diagram of Macro Microcontroller 2

Pinout

Macro Microcontroller 2 provides a few IO pinouts for connecting peripherals.

- DC Motor (MOTOR)
- 2.54mm GPIO pin headers (IO3, IO2, IO1, 3.3V, GND)

Macro Microcontroller 2 Pin #	Corresponding RP2040 Pin #
IO1	GPIO3
IO2	GPIO4
IO3	GPIO5

Built-in IO Devices

- 3 Key switches (SW1, SW2, SW3)
- 3 LEDs (LED1, LED2, LED3)
- 1 Buzzer (BELL)
- 1 DC motor port (MOTOR)
- 3 General purpose IO pins (IO1, IO2, IO3)

Bill of Materials

Qty	Reference Designator	Manufacturer Part #
1	BZ1	HMB1206-03
1	J3	DC-005 2.0
1	SW5	DS-02RP
1	M1	2.54 1x2 Pin Header
1	J4	2.54 1x5 Pin Header
1	J1	473460001
9	C1, C10, C11, C2, C3, C4, C5, C6, C7	0.1µF 0402
1	U1	RP2040
1	U3	XC6206P332MR
1	U2	TLV71311PDBVR
4	R2, R4, R5, R7	220Ω 0402
1	D4	NCD0603B1
2	C8, C9	8pF 0402
1	U4	W25Q128JVPIQ
3	D1, D2, D3	333-2SURD/S530-A3
1	U6	TPS76350DBVR
1	Y1	NX3225SA-12MHz-STD-CSR-6
2	R1, R6	27Ω 0402
3	R3, R8, R9	5kΩ 0402
2	RV1, RV2	T73YP202KT20
3	SW1, SW2, SW3	MX1A-E1NA
2	SW4, SW6	SKRKAEE020

Macro Microcontroller DOS

Macro Microcontroller Disk Operating System (DOS) is a simple command-line operating system providing basic programs for Macro Microcontroller 2.

Installation

1. Download macro-microcontroller-dos-0.0.3.uf2. This release includes Macro Microcontroller BIOS, A basic BIOS-like firmware, which performs POST routines, reports information on the device and boot the DOS.

   SHA-256 Checksum:
   `e0ba748dbac0241309680e81cc556e139e9c126062bc54f37d4ad093bcaae639`
2. Plug in Macro Microcontroller 2 while holding the Boot button. A storage drive will appear on your computer.
3. Move macro-microcontroller-dos-0.0.3.uf2 into the storage drive. Your development board is now running Macro Microcontroller BIOS and DOS.
4. Install a serial terminal application on your computer and connect it to the board. If successful, you should see the following:

```
 _ _
| \/ | Macro Microcontroller BIOS Version 0.0.2.
|_\/_| Copyright (C) 2025-2026 Nicholas Lim.

Device: Macro Microcontroller 2 (RP2040 @ 125MHz)
Serial Number: ****************
RAM Free: 254K OK
Serial Status: Connected

Press SW1 to enter Macro Microcontroller BASIC.
Press SW2 to enter BOOTSEL mode.

Booting system...

Macro Microcontroller Disk Operating System Version 0.0.3.
Copyright (C) 2026 Nicholas Lim.
Drive A>
```

Commands and Programs

- `HELP`: Launches the help guide.
- `CALCULATE`: Performs basic operations on 2 numbers. Usage: `CALCULATE [Number] [+ - * / ^ root] [Number]`
- `ECHO`: Echoes text.
- `PROGLIST`: Show program listing.
- `SYSTEM`: Starts another Macro Microcontroller DOS console.
- `EXIT`: Stops all processes for power off.
- `OUT`: Turns on a specified GPIO for 1 second. Usage: `OUT [LED# IO# BELL MOTOR]`
- `VERSION`: Shows the release version.
- `BOOT`: Reboots the system. Usage: `BOOT -m [BASIC BOOTSEL]*`
- `DEVINFO`: Displays device and memory information.
- `UPTIME`: Shows device uptime.

Predefined Values for Parameters

- `IO*`: Set GPIO pins 1, 2 or 3 to high.
- `LED*`: Set LEDs 1, 2 or 3 to high.
- `BELL`: Sounds the builtin buzzer.
- `MOTOR`: Sets motor pins to high.
- `BASIC`: Reboot in BASIC interpreter mode.
- `BOOTSEL`: Reboot in BOOTSEL mode.

Macro Microcontroller BASIC

Macro Microcontroller BASIC is a custom BASIC interpreter written in C with low-level hardware communication, providing a programming environment via a serial terminal.

Installation

1. Download macro-microcontroller-basic-0.0.3.uf2.

   SHA-256 Checksum:
   `96d4aa58d61d796067c1668cc37896fa968a55dceea188e50f26e067d116e99f`
2. Plug in Macro Microcontroller 2 while holding the Boot button. A storage drive will appear on your computer.
3. Move macro-microcontroller-basic-0.0.3.uf2 into the storage drive. Your development board is now running Macro Microcontroller BASIC.
4. Install a serial terminal application on your computer and connect it to the board. If successful, you should see the following:
   ```
   Macro Microcontroller BASIC Version 0.0.3.
   Copyright (C) 2025-2026 Nicholas Lim.
   ****** bytes of RAM free.
   Ready.
   10
   ```
5. If not, try sending `PRINT "It works!"`. If "It works!" is sent back to the serial terminal, you have successfully installed Macro Microcontroller BASIC.

Statements

- `PRINT`: Outputs text to the serial terminal.
- `LET`: Assigns a value (integer, float or string) to a variable.
- `INPUT`: Assigns a value (integer, float or string) to a variable via user input.
- `GPIO`: Turns on a specified GPIO pin for 1 second.
- `LSVAR`: Outputs variable name and their value to the serial terminal.
- `END`: Clears variable and reset line numbers.
- `EXIT`: Puts the device into sleep/power off mode.
- `KEY`: Pass GPIO controls to the macropad.
- `REM`: Add comments to your program.

Predefined Values

- `IO*`: Set GPIO pins 1, 2 or 3 to high.
- `LED*`: Set LEDs 1, 2 or 3 to high.
- `BELL`: Sounds the builtin buzzer.
- `MOTOR`: Sets motor pins to high.
- `RND`: Generates a random floating-point integer less than 1.

For more information on Macro Microcontroller 2, visit:
https://github.com/Nicholas1023/macro-microcontroller-2 (Repository)
https://nicholas1023.github.io/macro-microcontroller-2 (Documentation site)

Version History

Ver 3, Rev A: Add disclaimer and modify formatting
Ver 2, Rev F: Rephrase precaution section
Ver 2, Rev E: Update command listing for Macro Microcontroller DOS
Ver 2, Rev D: Change SHA-256 checksum for Macro Microcontroller BIOS
Ver 2, Rev C: Change overview and licensing section
Ver 2, Rev B: Update schematics
Ver 2, Rev A: Change overview and specification section and add Macro Microcontroller DOS section
Ver 1, Rev B: Change in page number and URLs
Ver 1, Rev A: Initial revision

Legal

Copyright © 2026 Nicholas Lim.

Hardware files ("PCB Files", "Printing Files", "Production Files", "schematics.pdf") are licensed under the terms of the CERN-OHL-W-2.0 License from 9 September 2026 onwards. Versions prior to this date remain available under the terms of the CERN-OHL-P-2.0 License. See LICENSE.txt.

Documentation files ("docs", "Assets", "JOURNAL.md" and this datasheet) are licensed under the terms of the MIT License. See docs/LICENSE.txt.

macro-microcontroller-basic.c, macro-microcontroller-bios.c, macro-microcontroller-bios+dos.c are licensed under the terms of the MIT License. firmware-template.c is licensed under the terms of the MIT-0 License. example.bas is marked CC0 1.0.

For further details on legal information and attribution, please refer to the Legal section in README.md.

DISCLAIMER: This project, the Macro Microcontroller device and all associated files are provided “as is”, without warranties of any kind, whether express or implied, including but not limited to warranties of merchantability, fitness for any particular purpose, and noninfringement.

To the maximum extent permitted by law, in no event shall the author be liable for any claims, damages, or other liabilities, whether in contract, tort, or otherwise, arising from, out of, or in connection with the project, its use, or any other dealings involving the device and its associated files.