PWR_FLAG +5V Board Layout Numbering:

00 is top left
01 is top right
06 is bottom left
16 is bottom right





































