

DAY 3

1. List 5 common issues users face with USB keyboards or mice on laptops, and write one possible solution for each.

Issue	Possible Solution
1. USB keyboard or mouse is not detected.	Unplug the device and reconnect it to another USB port.
2. Keyboard or mouse stops responding.	Restart the laptop and reconnect the device.
3. USB port is not working.	Try a different USB port or update the USB drivers.
4. Mouse cursor is lagging or freezing.	Clean the mouse sensor and use it on a proper surface.
5. Keyboard keys or mouse buttons do not work properly.	Check for physical damage, clean the device, or replace it if necessary.

2. Simulate a troubleshooting flow: Your Bluetooth headphones are not connecting to your phone. Write the exact step-by-step actions you would take to diagnose and fix the issue, mentioning any settings or indicators you would check.

1. Power and Device Check

- **Battery Level:** Verify your headphones have sufficient charge, as low battery can prevent Bluetooth broadcasting or stable pairing.
- **Disconnect from Others:** Check if the headphones are currently connected to another phone, tablet, or PC. Turn off Bluetooth on those alternate devices.
- **Distance:** Move the headphones within 3 feet of your phone to rule out signal interference from Wi-Fi routers or other electronics.

2. Physical Reset and Pairing Mode

- **Full Power Cycle:** Turn off your headphones completely. Wait 10 seconds, then turn them back on.
- **Enter Pairing Mode:** Do not just turn the headphones on. Press and hold the **Power/Bluetooth button** (or the button on the charging case for true wireless earbuds) for 5-7 seconds
- **Verify Indicator:** Look for a flashing LED light (usually alternating red/blue) or listen for a voice prompt indicating the device is "Ready to pair"

3. Phone Bluetooth Settings

- **Toggle Connection:** On your phone, go to **Settings > Bluetooth**. Turn the toggle off, wait 10 seconds, and turn it back on.
- **Forget the Device:** If the headphones are listed under "Paired" or "My Devices" but won't connect, tap the gear or (i) icon next to them and select **Forget This Device** or **Unpair**.

4. Clearing Cached Data

- If the headphones still refuse to show up on your phone's "Available Devices" list, navigate to your phone's **Settings > Apps > Bluetooth > Storage > Clear Cache**.
- Alternatively, perform a **Reset Wi-Fi and Mobile/Bluetooth Settings** in your system reset options to clear corrupted Bluetooth network data

3. A user reports that their external webcam is not detected during a Zoom call on Windows 10. Write a checklist of 6 things to check or try to resolve the problem. Hint : Consider device manager, privacy settings, and app permissions.

>>>

Checklist to Fix an External Webcam Not Detected in Zoom (Windows 10)

1. Check the USB Connection

- Ensure the webcam is securely connected to the computer.
- Try a different USB port if the webcam is not detected.

2. Check Device Manager

- Open Device Manager (Win + X → Device Manager).
- Expand Cameras or Imaging Devices.
- Make sure the webcam is listed and has no yellow warning icon.
- Update or reinstall the webcam driver if needed.

3. Verify Windows Privacy Settings

- Go to Settings → Privacy → Camera.
- Make sure Camera access for this device is turned On.
- Enable Allow apps to access your camera.

4. Check Zoom Camera Settings

- Open Zoom → Settings → Video.
- Select the correct external webcam from the Camera drop-down list.
- Confirm the camera preview is displayed.

5. Close Other Applications Using the Camera

- Exit apps such as Microsoft Teams, Skype, Discord, or the Camera app.
- Restart Zoom and check if the webcam is detected.

6. Restart the Computer and Update Software

- Restart Windows 10.
- Install the latest Windows updates, Zoom updates, and webcam drivers.
- Test the webcam again after restarting.

4. You are helping a friend whose printer is showing 'offline' status on their PC. Describe how you would use the Windows Troubleshooter tool to try to fix the issue, and explain what information the tool provides during the process.

1. Open Settings
 - Press Windows + I on the keyboard to open the Settings app.
2. Go to Troubleshoot
 - In Windows 11, click System → Troubleshoot.
 - In Windows 10, click Update & Security → Troubleshoot.
3. Open Other Troubleshooters
 - Click Other troubleshooters (Windows 11) or Additional troubleshooters (Windows 10).
4. Run the Printer Troubleshooter
 - Find Printer in the list.
 - Click the Run button next to it.
5. Select the Printer
 - Windows will display a list of installed printers.
 - Choose the printer that is showing Offline and click Next.
6. Wait for Windows to Scan
 - The troubleshooter checks for common problems, including:
 - Printer connection (USB or network)
 - Printer driver issues
 - Print Spooler service
 - Print queue errors
 - Offline printer settings
 - Default printer settings
7. Allow Windows to Apply Fixes
 - If a problem is found, Windows may automatically fix it.
 - If prompted, click Apply this fix.
8. Review the Results
 - After the scan is complete, Windows displays a report showing:
 - Problems found
 - Problems fixed
 - Problems that could not be fixed

- Recommended actions, if any

9. Restart the Printer (if recommended)

- Turn the printer off, wait a few seconds, and turn it back on.
- Restart the computer if Windows suggests doing so.

10. Test the Printer

- Print a test page or any document.
- Check if the printer status has changed from Offline to Online and confirm that it prints correctly.