

21 SINGLE NUMBER VARIABLE FUNCTIONS



21.1 Absolute Value

ABS(_E)

FX5S FX5UJ FX5U FX5UC

21

These functions output the absolute value of an input value.

| Ladder diagram, FBD/LD | Structured text |
|---|--|
| [Without EN/ENO]  | [With EN/ENO]  [Without EN/ENO] <code>d:=ABS(s);</code> [With EN/ENO] <code>d:=ABS_E(EN,ENO,s);</code> |

Setting data

■ Descriptions, types, and data types

| Argument | Description | Type | Data type |
|------------|--|-----------------|-----------|
| EN | Execution condition (TRUE: Execution, FALSE: Stop) | Input variable | BOOL |
| s(IN) | Input | Input variable | ANY_NUM |
| ENO | Output status (TRUE: Normal, FALSE: Abnormal) | Output variable | BOOL |
| d(ABS(_E)) | Output | Output variable | ANY_NUM |

Processing details

■ Operation processing

- These functions output the absolute value of the INT, DINT, or REAL type data input to (s) in the same data type as (s) from (d).
- These functions are expressed as follows when the input value is "A" and the output operation result is "B".
 $B=|A|$
- A value input to (s) is the INT, DINT, or REAL type data value.
- When -32768 is input while the data type of (s) is INT, -32768 is output from (d).
- When -2147483648 is input while the data type of (s) is DINT, -2147483648 is output from (d). (An operation error does not occur. "ABS_E" outputs "TRUE" from output variable ENO.)

■Operation result

1. Function without EN/ENO

The following table lists the operation results.

| Operation result | (d) |
|-----------------------------|------------------------|
| No operation error occurred | Operation output value |
| An operation error occurred | Indefinite value |

2. Function with EN/ENO

The following table lists the execution conditions and operation results.

| Execution condition | Operation result | |
|---------------------------|--|------------------------|
| EN | ENO | (d) |
| TRUE (Executes operation) | TRUE (Operation error did not occur) | Operation output value |
| | FALSE (Operation error occurred) ^{*1} | Indefinite value |
| FALSE (Stops operation) | FALSE ^{*1} | Indefinite value |

*1 When FALSE is output from ENO, data output from (d) is undefined. In that case, modify a program so that the data output from (d) is not used.

Operation error

- When (s) is REAL

| Error code (SD0/SD8067) | Description |
|----------------------------|--|
| 3402H | The data specified by (s) is -0, denormalized number, NaN (not a number), or $\pm\infty$. |
| 3403H | (d) exceeds the following range. (An overflow has occurred.) $ d < 2^{128}$ |