Ghost L2 Stage 2 - Modern UI + Automatic ESP-NOW Channel

Full updated CYD console firmware based on the working Ghost L2 Stage 2 project.

Changes

- Replaced the radar-target display with a node list and selected-node status panel.
- Added tap-to-select for radar / combined nodes on the NODES page.
- Alarm chips show active RADAR, TAMPER, LOSS, SENSOR FAULT, and LOW BATTERY states.
- Renamed the bottom-right button from ACK ALARM to ALARM.
- ESP-NOW now automatically uses the connected router's Wi-Fi channel.
- The manual ESP-NOW channel setting was removed from the configuration page.
- All existing ESP-NOW, UDP, Wi-Fi, OTA, web, calibration, PIN, and alarm functionality is preserved.

Automatic channel behaviour

- If no router is connected, the console uses the configured/default mesh channel.
- When it connects to a router, it reads `WiFi.channel()` and uses that channel for ESP-NOW.
- If the configuration AP was on another channel, it restarts the AP on the router channel.
- Stage 1 nodes must therefore also be operating on the router channel for direct ESP-NOW communication.

Build

1. Open this folder in VS Code / PlatformIO.
2. Connect the CYD board.
3. Run: PlatformIO: Upload.
4. Open Serial Monitor at 115200 baud.