

TH-D75 Command codes**Radio Serial Information****READ**

• Command	AE
• Return	AE AAAAAAAA,BBB

Parameter	Characters	Description
A	8	Full Serial Number
B	3	Last 3 Digits of Serial Number

Audio Volume**READ**

• Command	AG
• Return	AG AAA

SET

• Command	AG AAA
• Return Success	AG AAA

Parameter	Characters	Description
A	3	Audio Volume 000-099

Output Commands**READ**

• Command	AI
• Return	AI A

SET

• Command	AI A
• Return Success	AI A

Parameter	Characters	Description
A	1	Output Commands (0 = Off; 1 = On)

?**READ**

• Command	AS
• Return	AS A

SET

• Command	AS A
• Return Success	AS A

Parameter	Characters	Description
A	1	?

Band Control

READ

- | | |
|------------------|--|
| • Command | BC |
| • Return | BC A Returns value of which band has control |

SET

- | | |
|-------------------------|------|
| • Command | BC A |
| • Return Success | BC A |

Parameter	Characters	Description
A	1	CTRL/PTT Band (0 = A Band; 1 = B Band)

Battery Level Information

READ

- | | |
|------------------|------|
| • Command | BL |
| • Return | BL A |

Parameter	Characters	Description
A	1	3=Full Green, 2=2/3 full Green, 1=1/3 full Yellow, 0 = Empty Red

Bluetooth

READ

- | | |
|------------------|------|
| • Command | BT |
| • Return | BT A |

SET

- | | |
|-------------------------|------|
| • Command | BT A |
| • Return Success | BT A |

Parameter	Characters	Description
A	1	Bluetooth (0 = Off; 1 = On)

Squelch Status Information

READ

- | | |
|------------------|--------|
| • Command | BY A |
| • Return | BY A,B |

Parameter	Characters	Description
A	1	Band (0 = A Band; 1 = B Band)
B	1	Squelch Status (0 = Closed; 1 = Open)

Callsign

READ

• Command	CS
• Return	CS AAAAAAAAAA
SET	
• Command	CS AAAAAAAAAA
• Return Success	CS AAAAAAAAAA

Parameter	Characters	Description
A	1-9	Callsign

Dual/Single Band Mode

READ

• Command	DL
• Return	DL A
SET	
• Command	DL A
• Return Success	DL A

Parameter	Characters	Description
A	1	Dual/Single Band (0 = Dual; 1 = Single) Band Displayed in Single Mode is based on where CTRL/PTT set

Down

SET

• Command	DW
• Return	DW

Description

Tunes Frequency down by step size set or goes to next lower Memory location .

Band Settings

READ

• Command	FO A
• Return	FO A,BBBBBBBBBB,CCCCCCCCC,D,E,F,G,H,I,J,K,L,M,N,OO,PP,QQQ,R,SSSSSSSS,T,UU

SET

• Command	FO A,BBBBBBBBBB,CCCCCCCCC,D,E,F,G,H,I,J,K,L,M,N,OO,PP,QQQ,R,SSSSSSSS,T,UU
• Return Success	FO A,BBBBBBBBBB,CCCCCCCCC,D,E,F,G,H,I,J,K,L,M,N,OO,PP,QQQ,R,SSSSSSSS,T,UU

Parameter	Characters	Description
A	1	Band (0 = A Band; 1 = B Band)
B	10	Frequency in Hz (Left padded with zeros) RX Frequency when Offset Frequency or Split Frequency is set
C	10	Offset or TX Frequency
D	1	RX Step Size see table C
E	1	TX Step Size see table C
F	1	Mode (0-7) see TABLE D
G	1	Fine Tuning (0=Off, 1=On)
H	1	Fine Step Size (0-3) see TABLE E
I	1	Tone (0=Off, 1=On)
J	1	CTCSS (0=Off, 1=On)
K	1	DCS (0=Off, 1=On)
L	1	Split Tone (0=Off, 1=On)
M	1	Reverse (0=Off, 1=On)
N	1	Shift (0-8) see TABLE F
O	2	Tone frequency (00-31) see TABLE A
P	2	CTCSS Frequency (00-31) see TABLE A
Q	3	DCS Code (000-67) See TABLE B
R	1	Split Tone Combination (0-3) see TABLE H
S	0-8	UR Field
T	1	Digital Squelch (0=Off,1=Code Squelch,2=Callsign Squelch)
U	2	Digital Code (00-99)

RX Frequency

READ

• Command	FQ A
• Return	FQ A,BBBBBBBBBB

SET

• Command	FQ A,BBBBBBBBBB
• Return Success	FQ A,BBBBBBBBBB

Parameter	Characters	Description
A	1	Band (0 = A Band; 1 = B Band)
B	10	RX Frequency in Hz (Left padded with zeros)

FM Radio

READ

- | | |
|------------------|------|
| • Command | FR |
| • Return | FR A |

SET

- | | |
|-------------------------|------|
| • Command | FR A |
| • Return Success | FR A |

Parameter	Characters	Description
A	1	FM Radio (0 = Off; 1 = On)

Fine Step

READ

- | | |
|------------------|------|
| • Command | FS |
| • Return | FS A |

SET

- | | |
|-------------------------|------|
| • Command | FS A |
| • Return Success | FS A |

Parameter	Characters	Description
A	1	Fine Step see TABLE E.

Fine Tune

READ

- | | |
|------------------|------|
| • Command | FT |
| • Return | FT A |

SET

- | | |
|-------------------------|------|
| • Command | FT A |
| • Return Success | FT A |

Parameter	Characters	Description
A	1	Fine Tune (0 = Fine Tune Off; 1 = Fine Tune On) Only works with AM modulation and B Band.

Firmware Version Information

READ

- | | |
|------------------|------|
| • Command | FV |
| • Return | FV A |

Parameter	Characters	Description
A	4	Firmware version of radio.

GPS

READ

- **Command** GP
- **Return** GP A,B

SET

- **Command** GP A,B
- **Return Success** GP A,B

Parameter	Characters	Description
A	1	Built-in GPS (0=Off, 1=On)
B	1	PC Output (0=Off, 1=On)

? Information

READ

- **Command** GW
- **Return** GW A

Parameter	Characters	Description
A	1	?

Radio ID Information

READ

- **Command** ID
- **Return** ID AAAAAA

Parameter	Characters	Description
A	6	Radio Description or ID.

AF/IF/Detect

READ

- **Command** IO
- **Return** IO A

SET

- **Command** IO A
- **Return Success** IO A

Parameter	Characters	Description
A	1	USB Out (0=AF, 1=IF, 2=Detect)

Memory Channel

READ

• Command	ME AAA
• Return	ME AAA,BBBBBBBBBB,CCCCCCCCC, D,E,F,G,H,I,J,K,L,M,N,OO,PP,QQQ,R,SSSSSSSS,T,UU,V

SET

• Command	ME AAA,BBBBBBBBBB,CCCCCCCCC, D,E,F,G,H,I,J,K,L,M,N,OO,PP,QQQ,R,SSSSSSSS,T,UU,V
• Return Success	ME AAA,BBBBBBBBBB,CCCCCCCCC, D,E,F,G,H,I,J,K,L,M,N,OO,PP,QQQ,R,SSSSSSSS,T,UU,V

Parameter	Characters	Description
A	1	Band (0 = A Band; 1 = B Band)
B	10	Frequency in Hz (Left padded with zeros) RX Frequency when Offset Frequency or Split Frequency is set
C	10	Offset or TX Frequency
D	1	RX Step Size see table C
E	1	TX Step Size see table C
F	1	Mode (0-7) see TABLE D
G	1	Fine Tuning (0=Off, 1=On)
H	1	Fine Step Size (0-3) see TABLE E
I	1	Tone (0=Off, 1=On)
J	1	CTCSS (0=Off, 1=On)
K	1	DCS (0=Off, 1=On)
L	1	Split Tone (0=Off, 1=On)
M	1	Reverse (0=Off, 1=On)
N	1	Shift (0-8) see TABLE F
O	2	Tone frequency (00-31) see TABLE A
P	2	CTCSS Frequency (00-31) see TABLE A
Q	3	DCS Code (000-67) See TABLE B
R	1	Split Tone Combination (0-3) see TABLE H
S	0-8	UR Field
T	1	Digital Squelch (0=Off,1=Code Squelch,2=Callsign Squelch)
U	2	Digital Code (00-99)
V	1	Lock out (0=Off,1=On)

Mode

READ

• Command	MD A
• Return	MD A,B

SET

• Command	MD A,B
• Return Success	MD A,B Cannot set DR mode 7 only A band Only (0-1) and only 0-6 on B

Parameter	Characters	Description
A	1	Band (0=A Band, 1=B Band)
B	1	Mode see TABLE D

Memory Location Information

READ

• Command	MR A
• Return	MR BBB

Parameter	Characters	Description
A	1	Band (0 = A Band; 1 = B Band)
B	3	Memory Location on band

? Info

READ

• Command	MS
• Return	MS A

Parameter	Characters	Description
A	1	?

Transmit Power

READ

• Command	PC A
• Return	PC A,B

SET

• Command	PC A,B
• Return Success	PC A,B

Parameter	Characters	Description
A	1	Band (0 = A Band; 1 = B Band)
B	1	Power(0=High,1=Medium,2=Low,3=Extra Low)

Receive

SET

• Command	RX
• Return Success	RX

Description

Put radio in receive mode (turns off transmit).

Step Size

READ

• Command	SF A
• Return	SF A,B

SET

• Command	SF A,B
• Return Success	SF A,B

Parameter	Characters	Description
A	1	Band (0 = A Band; 1 = B Band)
B	1	Step Size see TABLE C

N=cannot set value or ?=syntax error

RX Filter

READ

• Command	SH A
• Return	SH A,B
SET	
• Command	SH A,B
• Return Success	SH A,B

Parameter	Characters	Description
A	1	Filter Bandwidth (2 = AM High Cut; 0 = SSB High Cut; 1=CW Band Width)
B	1	For Bandwidths see TABLE J. TABLE K, and TABLE L

Signal Meter Info

READ

• Command	SM A
• Return	SM A,B

Parameter	Characters	Description
A	1	Band (0 = A Band; 1 = B Band)
B	1	Signal Strength(0-5)

Squelch

READ

• Command	SQ A
• Return	SQ A,B

SET

• Command	SQ A,B
• Return Success	SQ A,B

Parameter	Characters	Description
A	1	Band (0 = A Band; 1 = B Band)
B	1	Squelch (0-6)

Radio Reset

SET

• Command	SR A
• Return Success	None because Radio reboots

Parameter	Characters	Description
A	1	(0=VFO Reset,1=Partial Reset,2=Full Rest)

ATT

READ

- **Command** RA A
- **Return** RA A,B

SET

- **Command** RA A,B
- **Return Success** RA A,B

Parameter	Characters	Description
A	1	Band (0 = A Band; 1 = B Band)
B	1	ATT(0=Off, 1=On)

Time

READ

- **Command** RT
- **Return** RT AAAAAAAAAAAAA

SET

- **Command** RT AAAAAAAAAAAAA
- **Return Success** RT AAAAAAAAAAAAA

Parameter	Characters	Description
A	12	Time YYMMDDHHMMSS

TNC

READ

- **Command** TN
- **Return** TN A,B

SET

- **Command** TN A,B
- **Return Success** TN A,B

Parameter	Characters	Description
A	1	TNC (0 = Off, 1 = APRS, 2= KISS)
B	1	Band (0 = A Band; 1 = B Band) Sets TNC Band

Transmit

SET

- **Command** TX
- **Return Success** TX

Description

Puts radio into transmit mode.

Market Code		
READ		
• Command	TY	
• Return	TY A,B	
SET		
• Command	TY A,B	
• Return Success	TY A,B	

Parameter	Characters	Description
A	1	Market Code (K=USA and Canada, E=Europe, J=Japan, M=General)
B	1	?

UP		
SET		
• Command	UP	
• Return	UP	

Description
Tunes Frequency up by step size set or goes to next higher Memory location.

VFO/Memory/Call/Repeaters		
READ		
• Command	VM A	
• Return	VM A,B	
SET		
• Command	VM A,B	
• Return Success	VM A,B	

Parameter	Characters	Description
A	1	Band (0 = A Band; 1 = B Band)
B	1	(0=VFO,1=Memory,2=Call,3=Repeaters)

TABLE A

Tone/CTCSS Frequency							
DEC	Value	DEC	Value	DEC	Value	DEC	Value
00	67.0	16	114.8	32	177.3	48	250.3
01	69.3	17	118.8	33	179.9	49	254.1
02	71.9	18	123.0	34	183.5		
03	74.4	19	127.3	35	186.2		
04	77.0	20	131.8	36	189.9		
05	79.7	21	136.5	37	192.8		
06	82.5	22	141.3	38	196.6		
07	85.4	23	146.2	39	199.5		
08	88.5	24	151.4	40	203.5		
09	91.5	25	156.7	41	206.5		
10	94.8	26	159.8	42	210.7		
11	97.4	27	162.2	43	218.1		
12	100.0	28	165.5	44	225.7		
13	103.5	29	167.9	45	229.1		
14	107.2	30	171.3	46	233.6		
15	110.9	31	173.8	47	241.8		

TABLE B

DCS Value													
DEC	Value	DEC	Value	DEC	Value	DEC	Value	DEC	Value	DEC	Value	DEC	Value
00	023	16	114	32	174	48	266	64	411	80	506	96	703
01	025	17	115	33	205	49	271	65	412	81	516	97	712
02	026	18	116	34	212	50	274	66	413	82	523	98	723
03	031	19	122	35	223	51	306	67	423	83	526	99	731
04	032	20	125	36	225	52	311	68	431	84	532	100	732
05	036	21	131	37	226	53	315	69	432	85	546	101	734
06	043	22	132	38	243	54	325	70	445	86	565	102	743
07	047	23	134	39	244	55	331	71	446	87	606	103	754
08	051	24	143	40	245	56	332	72	452	88	612		
09	053	25	145	41	246	57	343	73	454	89	624		
10	054	26	152	42	251	58	346	74	455	90	627		
11	065	27	155	43	252	59	351	75	462	91	631		
12	071	28	156	44	255	60	356	76	464	92	632		
13	072	29	162	45	261	61	364	77	465	93	654		
14	073	30	165	46	263	62	365	78	466	94	662		
15	074	31	172	47	265	63	371	79	503	95	664		

TABLE C

Step Size HEX	Value
0	5.00 kHz
1	6.25 kHz
2	8.33 kHz
3	9.00 kHz
4	10.00 kHz
5	12.50 kHz
6	15.00 kHz
7	20.00 kHz
8	25.00 kHz
9	30.00 kHz
A	50.00 kHz
B	100.00 kHz

TABLE D

Mode HEX	Value
0	FM
1	DV
2	AM
3	LSB
4	USB
5	CW
6	NFM
7	DR

TABLE E

Fine Step Size HEX	Value
0	20 Hz
1	100 Hz
2	500 Hz
3	1,000 Hz

TABLE F

Tone/CTCSS/DCS HEX	Value
0	No Tone
1	Cross Tone
2	DCS
4	CTCSS
8	Tone

TABLE G

Tone/CTCSS/DCS HEX	Value
0	Simplex
1	Plus Shift
2	Minus Shift

TABLE H

D/O Options HEX	Value
0	DCS/Off
1	Tone/DCS
2	DCS/CTCSS
3	Tone/CTCSS

TABLE I

Digital Squelch HEX	Value
0	Off
1	Code
2	Callsign

TABLE J

Digital Squelch HEX	Value
0	0.3 kHz
1	0.5 kHz
2	1.0 kHz
3	1.5 kHz
4	2.0 kHz

Program

SET

• Command	0M PROGRAM [0x0D]
• Return	0M [0x0D]

Description

Put Radio in program mode

End of Write

READ

• Command	0x06
• Return	0x06

Description

Done reading or writing.

Exit Programming

SET

• Command	E
• Return	0x06

Description

End programming radio.

Write Data

READ

• Command	WAAAAB
• Return	RAAAB

Parameter	bytes	Description
W	1	Write
A	3	Memory Location to start writing.
B	1	Bytes to write. (0 = 256)

Read Data

SET

• Command	RAAAB
• Return	WAAAAB

Parameter	bytes	Description
W	1	read
A	3	Memory Location to start reading.
B	1	Bytes to read. (0 = 256)

Radio Serial Information	
READ	
• Command	0M KENWOOD
• Return	

Description
Put Radio in program mode