

4-1 Motor Pre-start Inspection

You must use fasteners made of the right material and apply the right tightening torque, otherwise the current transfer may be deterred or connecting parts may become loose and fasteners may loosen. This may result in a lower than required minimum electrical gap, possibly resulting in the formation of sparks.

The electrical connections are subject to the following precautions.

- Tighten the threaded connection using the specified fastening torque.
- Follow the material specifications of the fasteners.
- Check the connection when inspecting.
- Use the correct cable specifications.

The cable specifications should be noted as follows.

- Rated current
- Rated voltage
- Number of service factors that may be required
- Equipment-related conditions, such as ambient temperature, wiring method, and cable length.