

Rotation Direction

- a. Delta motor runs forward and reversely (dual rotation)
- b. If you need to change the rotation direction, you need to wait for the motor to stop completely and then exchange any two phases of the three-phase outlet wires.

Power Supply, Voltage and Current

- a. Power supply and the voltage have to be the same as the rated voltage marked on the motor's nameplate.
- b. The voltage is within $\pm 10\%$ of the rated voltage (rated frequency). Make sure also the three phases are balanced.
- c. Measure the current of each phase without load. The difference between the unloaded current and its average value shall not exceed $\pm 5\%$.

Frequency

Frequency variation is within $\pm 1\%$ of the rated value (at rated voltage).

Lubricating ring on the bearing

Sliding bearings that need lubricating oil use oil rings to drive the lubricating oil.

Therefore, during operation of the motor, you must always verify if the rotation of the oil ring is smooth and whether the oil is flowing normally.

Temperature rising on the stator

The motor winding temperature rising protection uses PTC-130/ KTY84-130 thermistor as the motor overheating protection device, which is installed inside the motor stator winding. The allowable temperature value: KTY84-130 (130°C derating, 145°C strip).