

4.7 Tool Frame

The Tool Frame includes a Tool Center Point (TCP) and the Tool Frame directions. The default TCP is defined on the flange center at the end of the robotic arm. As shown in the figures at the bottom of this page, the Tool Frame rotates when the end of the robotic arm rotates.

