

The **Tool Frame** tab in the Point management page contains two areas:

- Tool Size: for setting the TCP.
- Tool Orientation: for setting the rotating directions of the Tool frame.

Tool Frame

ID : 1

Tool Size

Input :

(1) Enter the tool size

Width (mm)	Height (mm)	Angle (degree)
68.000	1.000	-1.000

(2) Determine the tool size by teaching

Determine

Tool Size Set

Get

Tool Orientation

Input :

(1) Enter the tool orientation data (Unit : Degree)

Roll (RX)	Pitch (RY)	Yaw (RZ)
0.000	0.000	0.000

(2) Determine the tool orientation data by teaching

Determine

Tool Orientation Set

Area	Name	Description
-	ID	Select the Tool Frame ID (ranges 1 to 9); the default setting is 0.
Tool Size	Enter the tool size	Displays the current tool size. You can also directly input the tool size to the table.
	Determine	Calculate the tool size by teaching; refer to Section 4.7.1 for details.
	Tool Size Set	Directly input the Width, Height, and Angle to the table, and then click Tool Size Set to write the parameters for the selected Tool Frame ID to the controller.
	Get	Displays the Width, Height, and Angle parameters set for the selected Tool Frame ID.
Tool Orientation	Enter the tool orientation data (Unit: Degree)	Displays the current rotating directions of the Tool Frame. You can also directly input the directions to the table.
	Determine	Calculate the Tool Frame directions by teaching; refer to Section 4.7.3 for details.
	Tool Orientation Set	Directly input the Roll (RX), Pitch (RY), and Yaw (RZ) to the table, and then click Tool Orientation Set to write the parameters for the selected Tool Frame ID to the controller.

4-30