

- The Error column shows the difference between the points and the calculated TCP in units of mm. Make sure the difference is within the application specification.

ID : 5

Input : Enter data of each axis and Height by teach, and then calculate.

X (mm)	Y (mm)	Z (mm)	Error	Select
423.318	244.237	-66.658	1.353	☒
528.176	119.872	-72.487	1.873	☒
376.553	27.968	-73.97	1.242	☒
0	0	0	0	☐
0	0	0	0	☐
n	n	n	n	☐

- Click **Set** to write the calculated tool size (Width, Height, and Angle) to the controller.

Tool size calculation

ID : 5

Input : Enter data of each axis and Height by teach, and then calculate.

X (mm)	Y (mm)	Z (mm)	Error	Select
423.318	244.237	-66.658	1.353	☒
528.176	119.872	-72.487	1.873	☒
376.553	27.968	-73.97	1.242	☒
0	0	0	0	☐
0	0	0	0	☐
0	0	0	0	☐
0	0	0	0	☐
0	0	0	0	☐

Output :

Height (mm): 123.405

Width (mm): -117.149

Angle (degree): 6.403

Buttons: Back, Save, Teach, Clear, Calculate, **Set**

Dialog: DRAstudio Set Tool Translation-Data? YES NO

- Click **Save** to save the points displayed in the Tool size calculation screen.

Tool size calculation

ID : 5

Input : Enter data of each axis and Height by teach, and then calculate.

X (mm)	Y (mm)	Z (mm)	Error	Select
423.318	244.237	-66.658	1.353	☒
528.176	119.872	-72.487	1.873	☒
376.553	27.968	-73.97	1.242	☒
0	0	0	0	☐
0	0	0	0	☐
0	0	0	0	☐
0	0	0	0	☐
0	0	0	0	☐

Output :

Height (mm): 123.405

Width (mm): -117.149

Angle (degree): 6.403

Buttons: Back, **Save**, Teach, Clear, Calculate, Set