

4.8 Work Space

The **Work Space** tab in the Point management page allows you to define the workspace of the robot as a working area or restricted area as needed to protect the robot and the peripheral devices.

Work Space

ID

1

Type

Rectangle

Status

Disable

☒ Show Alarm

Area

Working Area

Restricted Area DO

Disable

DO1

ON

Work Space is Closed

Rectangle

	X (mm)	Y (mm)	Z (mm)
PO	0	0	0
PX	0	0	0
PY	0	0	0

Reset

Get

Set

Name	Description
ID	Set the Work Space ID (ranges 1 to 9).
Type	Set the workspace as a Rectangle or Cylinder . Refer to the following two pages for details.
Status	Enable or Disable the selected workspace.
Area	Set the workspace as a Working Area or Restricted Area .
Work Space is Closed / Work Space is Opened	Displays the status of the workspace function. Click to enable or disable all workspace.
Restricted Area DO	Enable or Disable outputting the DO status of the restricted area. You can set to have one of the DOs among DO1 - DO12 be triggered to ON (light on) once the robot enters the restricted area.
Reset	Clear all the setting values of the current workspace.
Get	Read the setting values of the current workspace from the controller and refresh the page.
Set	Write the setting values of the selected Work Space ID to the controller.