

I/O Control (I/O)

The  **I/O** page in the menu of DRAStudio provides the System DI/O for monitoring and the User DI/O for applications. This chapter describes the definition of each DI/O signal. Before using the DI/Os, make sure the robot is properly wired. For wiring details, refer to the Controller User Manuals for Delta robots.

6.1	System IO	6-2
6.1.1	System DI	6-5
6.1.2	System DO	6-9
6.2	User IO	6-12
6.3	Remote IO	6-15
6.4	MonitorAddress (Memory address mapping)	6-17