

■ Operation Mode

The operation mode includes T1, T2 and Auto, which is switched with the System DI4 and DI5. The current mode is displayed on the Operation mode icon in the Quick access toolbar (marked with a red box as follows).



Mode	DI4	DI5	Description
T1	4 On	5 Off	■ Jog speed: the TCP (Tool Center Point) linear speed is limited under 225 mm/sec. ■ Moving speed during project execution: when the set moving speed in the project is above 225 mm/sec, the speed is limited at 225 mm/sec. For example, when the moving speed is set to 500 mm/sec in the program, the actual moving speed is 225 mm/sec. ■ Functional pause (System DI2): whether the System DI2 is On or Off does not trigger the functional pause.
T2	4 On	5 On	■ Jog speed: the TCP (Tool Center Point) linear speed is limited under 225 mm/sec. ■ Moving speed during project execution: based on the maximum speed of the model. ■ Functional pause (System DI2): when the System DI2 is Off, the functional pause is triggered and WA001 is displayed. To clear the warning, set both the System DI2 and DI3 to On.
Auto	4 Off	5 On	■ Jog speed: the TCP (Tool Center Point) linear speed is limited under 225 mm/sec. In the Auto mode, the JOG function is only operable in the DRASudio but not on the TP. ■ Moving speed during project execution: based on the maximum speed of the model. ■ Functional pause (System DI2): when the System DI2 is Off, the functional pause is triggered and WA001 is displayed. To clear the warning, set both the System DI2 and DI3 to On.

Important: when the System DI4 and DI5 are both Off, the system displays E1.998, indicating that the operation mode is disabled. To clear the alarm, properly wire System DI4 and DI5, and then cycle power on the controller.

Alarm / Warning	E1.998 (Operation mode has not been activated)
Probable Cause	The operation mode is not enabled
Recommended Action	Make sure both the contacts of System DI4 and DI5 are connected, and then restart the controller.