

6.2 User IO

Click  **User IO** in the  **I/O** page. It is suggested that you use the User DI/O by connecting the standard DI/O conversion module and connection cable (optional purchases) to the STD.DIO connector on the controller. For wiring details, refer to the Controller User Manual for each robot model.



There are two areas in  **User IO**:

- User DI: provides 24 digital inputs.
- User DO: provides 12 digital outputs.

Green circle  indicates that the DI/O is On; orange circle  indicates that the DI/O is Off.

