

7. Return to the **Modbus R/W** subtab of the **Function** subpage and set the value of 0x1002 to 1.

6

The screenshot shows the 'Function' subpage with the 'Modbus R/W' subtab selected. The 'Number of groups' is set to 2, and the 'dec' radio button is selected. The 'Write' button is highlighted with a red box. Below the buttons, there is a table with columns: All, Address, Value, Word. The first row is highlighted with a red box and contains the following data: ☒ All, 0x1, 1, 2. The 'Value' field is highlighted with a red box.

8. Since you have set to map 0x1002 to 0x02FE^{*Note} in step 1, the User DO1 is now On.

The screenshot shows the 'User DO' subtab. It contains a table with two rows. The first row has a green circle with the number '1' and the text 'DMV_trigger'. The second row has an orange circle with the number '2' and the text 'vision trigger_01'. The '1' in the first row is highlighted with a red box.

Note: 0x02FE is the address for setting the User DOs. Set 0x02FE to 1 to switch the User DO1 to ON; set 0x02FE to 2048 to switch the User DO12 to ON.