

7.3 Hardware Limit

The **Hardware Limit** tab displays the motor encoder value (unit: PUU) at the hardware limit of each robot axis. When a robot collision occurs, move the robot to the hardware limit and click **Get Value** to check whether the home position is lost. Either Default1 or Default2 should contain the encoder values of all applicable axes (except J4 and J6); otherwise, contact Delta.



■ Drop-down list box

In the drop-down list box (marked with a red box in the preceding figure), you can choose from the following three sets of hardware limit postures.

Name	Description
Default1	First set of default hardware limit posture
Default2	Second set of default hardware limit posture
User	User-defined hardware limit posture