

This chapter describes the Arm, Payload, Lead & Collision, and Gravity settings for the robot in the **Arm** page in the menu of DRASudio.

|       |                                          |      |
|-------|------------------------------------------|------|
| 8.1   | Arm .....                                | 8-2  |
| 8.2   | Payload .....                            | 8-4  |
| 8.2.1 | Setting the Mass .....                   | 8-4  |
| 8.2.2 | Setting the Distance .....               | 8-5  |
| 8.2.3 | Setting the Inertia .....                | 8-6  |
| 8.2.4 | Calculating the inertia .....            | 8-7  |
| 8.3   | Lead & Collision .....                   | 8-8  |
| 8.3.1 | Collision Setting .....                  | 8-8  |
| 8.4   | Gravity .....                            | 8-9  |
| 8.4.1 | Descriptions of Gravity parameters ..... | 8-10 |
| 8.4.2 | How to use the Gravity function .....    | 8-11 |