

8.1 Arm

In the **Arm** tab, you can read and write the software limits for each axis. DRASudio allows the user to define the software limits for each axis on the premise of being within the specifications.

■ Read Arm parameters

1. Click  (download) to download the Arm parameters to the PC.

Menu << Arm

Download/Upload Arm Parameter



JointName	PositiveLimit (PUU)	NegativeLimit (PUU)	PositiveLimit (degree/mm)	NegativeLimit (degree/mm)
J1	5216581	-5216581	170	-170
J2	4537501	-3529167	135	-105
J3	1823612	-5751390	65	-205
J4	3559947	-3559947	190	-190
J5	2493334	-2493334	120	-120
J6	5080755	-5080755	360	-360

2. Then, the table lists all the axis limits in PUU*Note and the auto-converted values in degree or in mm.

Note: PUU (Pulse of User Unit) is a unit scaled by the E-Gear ratio.

■ Write Arm parameters

1. Click  (download) to download the Arm parameters to the PC.

Menu << Arm

Download/Upload Arm Parameter



JointName	PositiveLimit (PUU)	NegativeLimit (PUU)	PositiveLimit (degree/mm)	NegativeLimit (degree/mm)
J1	5216581	-5216581	170	-170
J2	4537501	-3529167	135	-105
J3	1823612	-5751390	65	-205
J4	3559947	-3559947	190	-190
J5	2493334	-2493334	120	-120
J6	5080755	-5080755	360	-360