

8.4.1 Descriptions of Gravity parameters

Gravity

Set Gravity

☒ Enabled

☒ Normal ☐ Ceiling

Mass(kg) :

X(mm) :

Y(mm) :

Z(mm) :

SET

Get Gravity

Mode : Normal

Mass(kg) : 0

X(mm) : 0

Y(mm) : 0

Z(mm) : 0

GET

Item	Description
Enabled	Select this check box to enable gravity compensation.
Normal (table-mount) / Ceiling (ceiling-mount)	Select the mounting type of the robot as table-mount or ceiling-mount.
Mass (kg) (payload)	Enter the end effector weight. The robot's payload capacity differs from models. Refer to Section 8.2.1 for details.
X (mm), Y (mm), Z (mm) ^{*Note}	Enter the X-, Y-, and Z-axis distances from the tool's center of gravity to the end of the robotic arm, which can be determined by CAD software tools. Refer to Section 8.2.2 for details.

Important: in the **Gravity** tab, the distances are in units of mm; in the **Payload** tab, the distances are in units of meters. Pay attention when converting between units.