

8.4.2 How to use the Gravity function

■ Set Gravity

- 1. Click  (Servo control) in the Quick access toolbar to switch all the motors to the Servo Off state.
- 2. Enter the end effector weight, and the X-, Y-, and Z-axis distances from the tool's center of gravity to the end of the robotic arm.
- 3. Click **SET**.

Set Gravity

☒ Enabled

☒ Normal

☐ Ceiling

Mass(kg) :

X(mm) :

Y(mm) :

Z(mm) :

SET

- 4. Go to the **Status** subpage, click **Update**, and you can find that “Gravity Compensation Deformation” is ON.

Status

Update

| Status | Content                          |
|--------|----------------------------------|
| ON     | Gravity Compensation Deformation |
| ON     | Gravity Compensation Torque      |
| OFF    | Thermal Compensation             |
| OFF    | FigureAngle Compensation(SCARA)  |
| OFF    | System Reservation               |
| OFF    | System Reservation               |
| OFF    | System Reservation               |
| OFF    | FigureLength Compensation(SCARA) |
| OFF    | Collision Detect                 |

■ Get Gravity

- 1. Click **GET**.

Get Gravity

Mode :

Normal

Mass(kg) :

5

X(mm) :

12

Y(mm) :

6

Z(mm) :

22

GET

- 2. Check the Gravity parameters read by the system.