

This chapter introduces the system settings, such as system backup and communication setup, for DRASstudio and the robot controller.

10.1	EtherNet IP	10-2
10.2	RS232/485	10-3
10.3	Language	10-4
10.4	Backup	10-5
10.5	Recovery	10-6
10.6	Options	10-7