

10

The **System** page in the menu provides the settings of the robot system, including **EtherNet IP**, **RS232/485**, **Language**, **Backup**, **Recovery**, and **Options**.

The screenshot shows the DRASudio System menu. The 'Menu' bar at the top contains tabs for 'EtherNet IP', 'RS232/485', 'Language', 'Backup', 'Recovery', and 'Options'. The 'EtherNet IP' tab is selected and highlighted with a red border. Below the menu, the 'Set Controller EtherNet' form is visible. It contains three rows of input fields: 'IP' (192, 168, 1, 1), 'SubNet Mask' (255, 255, 255, 0), and 'Default Gateway' (255, 255, 255, 255). A large orange 'Set' button is on the right. At the bottom left, there is a gear icon and the word 'System'.

10.1 EtherNet IP

This tab is for setting the Ethernet IP address, SubNet Mask, and Default Gateway of the robot controller. Enter the parameters in the fields and then click **Set** to complete the setting.

This block shows a detailed view of the 'EtherNet IP' settings form. At the top, the text 'EtherNet IP' is followed by five empty input fields. Below this, the 'Set Controller EtherNet' form is shown. It has three rows of input fields: 'IP' (192, 168, 1, 1), 'SubNet Mask' (255, 255, 255, 0), and 'Default Gateway' (255, 255, 255, 255). A large orange 'Set' button is on the right.