

1

T2 (Test mode 2)

For project testing. In this mode, you can operate the robot at high speed.

■ Jog speed

The TCP (Tool Center Point) linear speed is limited under 225 mm/sec.

■ Moving speed during project execution

Based on the maximum speed of the model.

■ Functional pause (System DI2)

When the System DI2 is Off, the functional pause is triggered. To clear the warning, set both the System DI2 and DI3 to On.

Auto (Auto mode)**■ Jog speed**

The TCP (Tool Center Point) linear speed is limited under 225 mm/sec.

In Auto mode, the JOG function is only operable in DRASstudio but not on the TP.

■ Moving speed during project execution

Based on the maximum speed of the model.

■ Functional pause (System DI2)

When the System DI2 is Off, the functional pause is triggered. To clear the warning, set both the System DI2 and DI3 to On.