

2. Select a point data in the point list, and then select an external axis in the drop-down list box of the Motion Command area. Click **Ext Teach** to save the current position of the external axis to the corresponding field of the row (J1 corresponds to the X field, J2 corresponds to the Y field, and so on). For the points of the external axis, the CoordinateStr field displays "Ext".

Global										
	Check	Name	X (mm)	Y (mm)	Z (mm)	RZ (deg.)	Hand	UserID	ToolID	CoordinateStr
▶ 16	☒	GL_16	59,984.000	0.000	0.000	0.000	0	0	0	Ext
17	☐	GL_17	0.000	0.000	0.000	0.000	0	0	0	PCS
18	☐	GL_18	0.000	0.000	0.000	0.000	0	0	0	PCS

Global Point

Refresh Clear

Motion Command(mm)

Please choose one point

File: Global

Name: GL_1

Motion: MovP

Teach

Ext Teach

Ext J1

Ext J1

Go

☐ Check All

Maximum Top

Rise height

Drop height

3. To move the external axis to a point, select the point data you have taught, select the external axis*2 in the drop-down list box, and then press and hold **Go**. You can only move one external axis at a time.

Global										
	Check	Name	X (mm)	Y (mm)	Z (mm)	RZ (deg.)	Hand	UserID	ToolID	CoordinateStr
▶ 16	☒	GL_16	59,984.000	0.000	0.000	0.000	0	0	0	Ext
17	☐	GL_17	0.000	0.000	0.000	0.000	0	0	0	PCS
18	☐	GL_18	0.000	0.000	0.000	0.000	0	0	0	PCS

Global Point

Refresh Clear

Motion Command(mm)

Please choose one point

File: Global

Name: GL_1

Motion: MovP

Teach

Ext Teach

Ext J1

Ext J1

Go

☐ Check All

Maximum Top

Rise height

Drop height

Note:

- *1. You need to click **Scan** in the **External** page before operating in the **External** page or the **ExternalAxis** subpage.
- *2. If the servo of the external axis displays the alarm E1.801 (All-axis homing is not carried out) after the external axis is specified, refer to Delta's servo drive user manuals to clear the alarm and then execute homing.